QUIK-REVIEW: Connecting to a Platform



To connect to a platform on a local or remote (folder) icon on the host, click the Open Toolbar.

in the Nav Tree and select Open on the host IP (for remote hosts) platform from the pop-up menu. You can also right-click directly

Complete the fields in dialog box as follows: the Open Platform

OK button

Click the

Enter IP address of JACE

all settings. to accept

- Set to whichever port Is used for the platform daemon. (Port 3011 is default.)
 - user name & password Type in a valid station
- remember the user name and If you want Workbench to password, leave this checkbox checked.

established, its icon view displays in the platform's container Nav Tree, and the is displayed in the connection is **The Platform** Jiew Pane.

> the platform icon in the Nav Tree and select platform icon on the Nav Tree, right-click on To disconnect from a platform and dim the "Disconnect" from the resulting pop-up.

click on the platform icon in the Nav Tree and To disconnect from a platform and remove the platform icon from the Nav Tree, rightselect "Close" from the resulting pop-up.