

RS485 Wiring on Cat5 UTP

Pin 4 - DB Pin 5 - DA Pin 7 - 5V Pin 8 - GND Pin 2 - 3.3V Pin 1 - GND



