

--

Driver

Indication

Current_Sensor


--

NTC

Reset

4

4





Title:		
Size A4	Date:	Rev:
KiCad E.D.A. 9.0.1		Id: 1/7


Size: A4	Date:	Rev:
KiCad E.D.A. 9.0.1		Id 1/7

KiCad E.D.A. 9.0.1	Id: 1/7
--------------------	---------


	Id 1/7
--	--------

Id: 1/7





Sheet: /Indication/ File: Indication.kicad_sch			0
Title:			
Size: A4	Date:	Rev:	
KiCad E.D.A. 9.0.1		Id: 3/7	



Sheet: /Power_Supply/
File: Power_Supply.kicad_sch

Title:


Size: A4

Date:

Rev:

KiCad E.D.A. 9.0.1

Id: 4/7




Sheet: /Current_Sensor/
File: Current_Sensor.kicad_sch

Title:

Size: A4
KiCad E.D.A. 9.0.1

Date:

Rev:
Id: 5/7



Sheet: /NTC/
File: NTCkicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 9.0.1

Rev:

Id: 6/7



Sheet: /Reset/
File: Reset.kicad_sch

Title:

Size: A4
KiCad E.D.A. 9.0.1

Date:

Rev:
Id: 7/7