Amplifier

Input Parameters

 \bullet setAmplification

 \bullet setNoiseAmplitude

Functional Description

This block accepts one real signal and outputs one real signal built from multiplying the input signals by a predetermined value. This block also adds random gaussian distributed noise with a user defined amplitude. The multiplying factor and noise amplitude are defined by the values of *Amplification* and *NoiseAmplitude* respectively.

Input Signals

Number: 1

Type: Real signal (ContinuousTimeContiousAmplitude)

Output Signals

Number: 1

Type: Real signal (ContinuousTimeContiousAmplitude)