


Operator side

Located at at least 1m from the fusor.
All the cables between the variac and the operator will be centralized
into a single ombilical, the emergency stop is independent

The button is normally off,
when activated, the MX coil triggers
and turns off the system.
If one of the doors is open
the coil is also triggered

Fusor Structure



Electrical & Vacuum Wiring for a demo fusor inspired from Makezine
Vacuum circuit in blue
Electrical wires in green

ENSEA Quantum, (Alexeï Douillard's Maker Project 2026)

Sheet: /

File: schematic fusor.kicad_sch

Title: Demo fusor : Electrical & Vacuum Wiring

Size: A4

Date:

Rev: V1

KiCad E.D.A. 9.0.8

Id: 1/1