
STAND MIXER JH-350A-5L EXPLODED DIAGRAM AND PARTS LIST



1. fixing bolt	41. cable with plug
2. sealed cap	42. locking level
3. motor cap	43. stop screw
4. decorative ring	44. bearing
5. bevel gear	45. gear
6. speed control switch	46. sealed pad
7. back cover	47. motor housing stand
8. washer	48. adjustment screw
9. nut	49. screw
10. speed control knob	50. stop screw
11. stop screw	51. internal gear
12. screw	52. screw
13. screw	53. pin
14. rubber washer	54. elastic ring
15. separator	55. pin
16. carbon brush	56. major axis
17. fan blade	57. washer
18. motor cover	58. bearing
19. stator	59. pin
20. bearing	60. external gear
21. rotor	61. bearing
22. bearing	62. gear case cover
23. motor cover	63. pin
24. screw	64. spring
25. motor bracket	65. washer
26. rubber washer	66. cover ring
27. pin	67. pin
28. screw	68. beater shaft
29. screw	69. bottom feet
30. screw	70. screw
31. bracket	71. fixing plate
32. bearing	72. pin
33. washer	73. bottom stand
34. gear	74. stainless steel bowl
35. pin	75. flat beater
36. washer	76. meat grinder attachment
37. gear stand	77. wire whip
38. bearing	78. dough hook
39. gear with rod	79. pouring shield
40. screw	