SIGN IN () HOME (//WWW.ARDUINO.CC) BUY SOFTWARE

Reference Language (//www.arduino.cc/en/Reference/HomePage) | Libraries (//www.arduino.cc/en/Reference/Libraries) | Comparison (//www.arduino.cc/en/Reference/Comparison) | Changes (//www.arduino.cc/en/Reference/Changes)

Wire.setClock()

Description

This function modifies the clock frequency for I2C communication. I2C slave devices have no minimum working clock frequency, however 100KHz is usually the baseline.

Syntax

Wire.setClock(clockFrequency)

Parameters

clockFrequency: the value (in Hertz) of desired communication clock. Accepted values are 100000 (standard mode) and 400000 (fast mode). Some processors also support 10000 (low speed mode), 1000000 (fast mode plus) and 3400000 (high speed mode). Please refer to the specific processor documentation to make sure the desired mode is supported.

Returns

None

Reference Home (//www.arduino.cc/en/Reference/HomePage)

Corrections, suggestions, and new documentation should be posted to the Forum (http://arduino.cc/forum/index.php/board,23.0.html).

The text of the Arduino reference is licensed under a Creative Commons Attribution-ShareAlike 3.0 License (http://creativecommons.org/licenses/by-sa/3.0/). Code samples in the reference are released into the public domain.

Share









NEWSLETTER

ENTER YOUR EMAIL TO SIGN UP

SUBSCRIBE

Terms Of Service (//www.arduino.cc/e@/AWa&hATduinscO(fS/ewwive)arduino.cc/en/Main/CopyrightNotice)

Privacy Policy (//www.arduino.cc/en/Main/PrivacyPolicy)

Contact Us (//www.arduino.cc/en/Main/ContactUs)

About Us (//www.arduino.cc/en/Main/AboutUs)

Careers (//www.arduino.cc/Careers)

(https://https