
PENDANT INTERFACE GUIDANCE

PENDANT INTERFACE



MAPPING RUNNING MENU			
KEY	FUNCTION	VALUE	
F1	Change mapping menu	-	
F2	Set control mode	Position ctrl Angle Control	
F3	Move cursor	-	
F4	Set change value mode	Continues mode Step mode	
↑	Increase move value	-	
1	Decrease move value	-	
←	Next point	-	
→	Previuous point	-	
Esc	Back to home menu	-	
Ent	Save pattern	-	

	HOME MENU	J		
KEY	FUNCTION	VALUE		
F1	Auto home	-		
F2	Set control mode	Position ctrl Angle Control		
F3	Move cursor	-		
F4	Set change value mode	Continues mode Distance mode Step mode		
Num	Set distance value	-		
↑	Increase move value	-		
\	Decrease move value	-		
←	Delete	-		
\rightarrow	ОК	-		
Esc	Insert coma	-		
Ent	Move to preparation menu	-		
PREPARATION MENU				
KEY	FUNCTION	VALUE		
F1	Change running mode	Welding, Mapping, Preview		
F2	Change running speed	LOW, MED, HIGH		
↑	Increase preview point	-		
\	Decrease preview point	-		
Esc	Back to home menu	-		
Ent	Start running	-		
WELDING RUNNING MENU				
KEY	FUNCTION	VALUE		
F1	Pause	-		
F2	Hold Icd information	-		
←	Previous running menu	-		
→	Next running menu	-		
Esc	Stop	-		
	Continue	1		

PERANCANGAN INTERFACE PENDANT			
HALAMAN	: 1/3	TANGGAL : 12 Juli 2024	
DIGAMBAR	: ALFONSUS GIOVANNI MAHENDRA P.	NIM : 40040621650042	

UNTUK WELDING ARM MANIPULATOR 6 DOF

STR - TEKNIK LISTRIK INDUSTRI SEKOLAH VOKASI UNIVERSITAS DIPONEGORO SEMARANG