#### NUL

NULL 00

### **ENQ**

**ENQUIRY** 

05

#### SOH

START OF HEADING

01

#### ACK

**ACKNOWLEDGE** 

06

#### STX

START OF TEXT

02

#### BEL

**BELL** 

07

#### ETX

**END OF TEXT** 

03

#### BS

**BACKSPACE** 

80

#### **EOT**

**END OF TRANSMISSION** 

04

#### HT

HORIZONTAL TABULATION

### LF

LINE FEED

0A

## SI

SHIFT IN

0F

#### **VT**

**VERTICAL TABULATION** 

0B

#### DLE

DATA LINK ESCAPE

10

#### FF

**FORM FEED** 

0C

DC1

**DEVICE CONTROL 1** 

11

#### CR

**CARRIAGE RETURN** 

0D

DC2

**DEVICE CONTROL 2** 

12

#### SO

SHIFT OUT

0E

DC3

**DEVICE CONTROL 3** 

DC4

**DEVICE CONTROL 4** 

14

EM

**END OF MEDIUM** 

19

#### NAK

**NEGATIVE ACKNOWLEDGE** 

15

SUB

SUBSTITUTE

1A

#### SYN

SYNCHRONOUS IDLE

16

**ESC** 

**ESCAPE** 

1B

#### ETB

**END OF TRANSMISSION BLOCK** 

17

FS

**FILE SEPARATOR** 

1C

#### CAN

CANCEL

18

GS

**GROUP SEPARATOR** 

1D



NUMBER SIGN

23

US

**UNIT SEPARATOR** 

1F

\$
DOLLAR SIGN

SP

**SPACE** 

20

%

24

PERCENT SIGN

25

**EXCLAMATION POINT** 

21

8

**AMPERSAND** 

26

"

**QUOTATION MARK** 

22

**APOSTROPHE** 



**DIGIT SEVEN DIGIT TWO** 32 37 **DIGIT THREE DIGIT EIGHT** 33 38 **DIGIT NINE DIGIT FOUR** 34 39 COLON **DIGIT FIVE** 3A 35

**SEMICOLON** 

3B

**DIGIT SIX** 







CAPITAL LETTER B

EQUALS SIGN



GREATER-THAN SIGN

CAPITAL LETTER C

42



QUESTION MARK

CAPITAL LETTER D



CAPITAL LETTER E

40



CAPITAL LETTER K

CAPITAL LETTER G

CAPITAL LETTER L

CAPITAL LETTER H

CAPITAL LETTER M

CAPITAL LETTER I
49

CAPITAL LETTER N
4E

CAPITAL LETTER J


CAPITAL LETTER O


# CAPITAL LETTER P

## CAPITAL LETTER U 55

# CAPITAL LETTER Q 51

# CAPITAL LETTER V 56










CAPITAL LETTER T

CAPITAL LETTER Y
59





C SMALL LETTER c























S SMALL LETTER s



SMALL LETTER t




SMALL LETTER u



SMALL LETTER v

SMALL LETTER r

SMALL LETTER w



#### ASCII CARD https://github.com/Alignof/ASCII\_CARD

**VERTICAL LINE** 

7C