
- 1. Assembling the corresponding car requires downloading the corresponding program to the microbit motherboard
- 2. After downloading the program, open the car switch, open the mobile APP and click car



3. Allow bluetooth control. Click the bluetooth icon in the upper right corner of the screen to connect to the microbit motherboard (the bluetooth icon is red to indicate disconnection and reconnection is required).



4. Click the corresponding BBC microbit to connect (different microbit motherboards have different microbit information in square brackets)



5. When the bluetooth icon in the upper right corner turns blue, it means that the bluetooth connection is successful. At this time, you can control the car by using the super fast car

