- sprintf: نحوه کار کرد و آرگومانهای ورودی این تابع بسیار به تابع printf شباهت دارد، هر دو یک رشته فرمت شده را ایجاد می کنند؛ با این تفاوت که در تابع printf حاصل تابع در خروجی استاندارد نشان داده می شود؛ اما در sprintf رشته فرمت شده؛ در آرگومان اول آن که از نوع *rhar است قرار می گیرد.
- strcmp: هدف این تابع مقایسه دو رشته است و دو آرگومان از نوع *char (رشته در زبان C) میپذیرد. نحوه کارکرد و مقایسه این دو رشته به این صورت است که اختلاف کد اسکی اولین کارکتر غیر مساوی دو رشته را بازمیگرداند. اگر تمام کارکترهای دو رشته با یکدیگر برابر بودند (یعنی مقدار دو رشته برابر بود) خروجی برابر خواهد بود.

(۲

به نظر میرسد که اگر بخواهیم روی یک پورت چیزی بنویسیم و سپس مقدار ریخته شده روی آن پورت را بخوانیم به دلیل اینکه سیگنال SYNC به نظر میرسد که اگر بخوانیم به دلیل اینکه سیگنال PIN در لبه بالارونده ۱ میشود؛ میبایست در کلاک بعدی یک دستور nop اجرا کرد تا مقدار روی PIN تغییر کند و سیس آن را خواند.

When reading back a software assigned pin value, a *nop* instruction must be inserted as indicated in Figure 25. The *out* instruction sets the "SYNC LATCH" signal at the positive edge of the clock. In this case, the delay t_{pd} through the synchronizer is one system clock period.

SYSTEM CLK

r16

Oxff

INSTRUCTIONS

out PORTx, r16

nop

in r17, PINx

SYNC LATCH

PINxn

r17

Ox00

Oxff

Figure 25. Synchronization when Reading a Software Assigned Pin Value

مثال آن در تصویر صفحه بعد آمده.

Assembly Code Example(1) ; Define pull-ups and set outputs high ; Define directions for port pins ldi r16, (1<<PB7) | (1<<PB6) | (1<<PB1) | (1<<PB0) r17, (1<<DDB3) | (1<<DDB2) | (1<<DDB1) | (1<<DDB0) PORTB, r16 out out DDRB, r17 ; Insert nop for synchronization nop ; Read port pins r16, PINB C Code Example(1) unsigned char i; /* Define pull-ups and set outputs high */ /* Define directions for port pins */ PORTB = (1<<PB7) | (1<<PB6) | (1<<PB1) | (1<<PB0); DDRB = (1<<DDB3) | (1<<DDB2) | (1<<DDB1) | (1<<DDB0); /* Insert nop for synchronization*/ _NOP(); /* Read port pins */ i = PINB;

Note: 1. For the assembly program, two temporary registers are used to minimize the time from pull-ups are set on pins 0, 1, 6, and 7, until the direction bits are correctly set, defining bit 2 and 3 as low and redefining bits 0 and 1 as strong high drivers.