Module Interface Specification for 2D Localizer

Aliyah Jimoh

April 18, 2025

1 Revision History

Date	Version	Notes
2025/03/19	1.0	Initial Draft
2025/04/18	1.1	Implement Feedback

2 Symbols, Abbreviations and Acronyms

See SRS Documentation at https://github.com/AliyahJimoh/2D-Localizer/blob/main/docs/SRS/SRS.pdf. The symbols used in this document are mentioned below.

Symbol	Description
map	String of the map image's name
N	Number of beacons used
M	Number of FMs used
p	Number of positions the robot has in its trajectory
$\mathbf{path}$	$\mathbb{R}^{p\times 3}$ matrix of the ground truth trajectory
$\mathbf{a}$	$\mathbb{R}^{N\times 2}$ matrix of beacon coordinates
$\mathbf{C}$	$\mathbb{R}^{2\times 2}$ CRLB
$\boldsymbol{\mathcal{I}}(\hat{\mathbf{x}})$	$\mathbb{R}^{2\times 2}$ FIM
$\mathbf{T}_{mf}$	$\mathbb{R}^{M\times 3}$ pose of fiducial marker in map frame (x, y, θ)
$\mathbf{T}_{rf}$	$\mathbb{R}^{3}$ pose of fiducial marker in robot frame (x, y, θ)
$\tilde{\mathbf{d}}$	$\mathbb{R}^{N}$ vector of a set of range measurements
$\tilde{\mathbf{D}}$	$\mathbb{R}^{p\times N}$ matrix of range measurements in all positions
$\hat{\mathbf{x}}$	$\mathbb{R}^{3}$ estimated robot pose
i	Index of fiducial marker
j	Index of beacon
t	Index of robot position along the trajectory
x	$\mathbb{R}$ x coordinate of robot
y	$\mathbb{R}$ y coordinate of robot
θ	$\mathbb{R}$ orientation of robot (radians)
η	Gaussian sensor noise
ϕ	Angle of FM relative to robot (used for FOV filtering)
$\boldsymbol{\sigma^2}$	$\mathbb{R}^{N}$ vector of range noise variances

Table 1: Symbol Definitions Used in Access Routines

Contents

3 Introduction

The following document details the Module Interface Specifications for 2D Localizer, a program that implements various sensors to help localize mobile robots on a 2D plane in enclosed environments.

Complementary documents include the System Requirement Specifications and Module Guide. The full documentation and implementation can be found at https://github.com/AliyahJimoh/2D-Localizer.

4 Notation

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol := is used for a multiple assignment statement and conditional rules follow the form $(c_1 \Rightarrow r_1|c_2 \Rightarrow r_2|...|c_n \Rightarrow r_n)$.

The following table summarizes the primitive data types used by 2D Localizer.

Data Type	Notation	Description
boolean	$\mathbb{B}$	a true or false value True, False
character	char	a single symbol or digit
dictionary	dict	a key-value data structure where keys map to values of different types
integer	$\mathbb{Z}$	a number without a fractional component in (-∞, ∞)
list	list	An ordered collection of items of different or similar types
real	$\mathbb{R}$	any number in (-∞, ∞)
string	String	more than one symbol put together

The specification of 2D Localizer uses some derived data types: sequences, strings, and tuples. Sequences are lists filled with elements of the same data type. Strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, 2D Localizer uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

5 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1	Level 2
Hardware-Hiding Module	
Behaviour-Hiding Module	Input Format Module Simulation Module Output Module Localization Module Control Module Accuracy Evaluation Module
Software Decision Module	GTSAM Module Plotting Module

Table 2: Module Hierarchy

6 MIS of Control Module

6.1 Module

main

6.2 Uses

- Input Format Module (Section 8)
- Localization Module (Section 10)
- Accuracy Evaluation Module (Section 11)
- Plotting Module (Section 13)
- Output Module (Section 12)
- Python multiprocessing Library (Queue, Process)

6.2.1 Exported Constants

None

6.2.2 Exported Access Programs

Name	In	Out	Exceptions
main	-	-	-

6.3 Semantics

6.3.1 State Variables

- data_queue: Queue that stores the estimated pose of the current position and passes it to the Output Module's environmental variable.

6.3.2 Environment Variables

None

6.3.3 Assumptions

None

6.3.4 Access Routine Semantics

main():

- transition: Modifies the shared queue ('data_queue') with each set of range and camera measurements.

 # Get Data

input = InputData() *# Abstract Data Type from Input Format Module*

 # Start the Output Data

data_queue = Queue() *# Part of multiprocessing library*

process = Process(target=run_gui, args=[data_queue]) *# Runs the GUI (Output Module). It is created with run_gui as the target function and data_queue as its input argument.*

process.start()

m = p *# Number of positions the robot has in the map*

 # Getting estimated pose for each set of measurements

for t in range(1,m):

$\hat{\mathbf{x}}$:= localize($\mathbf{a}$, T_{mf}, $\tilde{\mathbf{D}}[t,:]$, $\mathbf{path}[t,:]$)

 # Computing FIM & CRLB

fim = compute_fim($\hat{\mathbf{x}}$, $\mathbf{a}$, variances($\boldsymbol{\sigma}^{\mathbf{2}}$))

crlb = compute_crlb(fim) *# Will be printed*

update_trajectory($\hat{\mathbf{x}}$)

data_queue.put((t, $\hat{\mathbf{x}}$.x(), $\hat{\mathbf{x}}$.y(), $\hat{\mathbf{x}}$.theta()))

 # Plot on the map

plot_localization_live($\mathbf{a}$, T_{mf}, map, $\mathbf{path}$, map_size)

7 MIS of GTSAM Module

The GTSAM Module provides wrapper access the Georgia Tech Smoothing and Mapping (GTSAM) library using simplified and consistent Python interfaces. GTSAM is used for solving estimation problems using factor graphs which are a way to represent relationships between variables using "factors"(pieces of information gotten from sensors). More information about the API can be found at https://gtsam.org/doxygen/index.html

7.1 Module

gtsam_wrapper

7.2 Uses

None

7.3 Syntax

7.3.1 Exported Constants

None

7.3.2 Exported Types

Data Type	Notation	Description
factor	Factor	a constraint in a factor graph that relates variables
factor graph	Graph	a collection of factors defining an optimization problem
noise model	Model	a model that defines uncertainty in a measurement
values	Values	a container that stores variable estimates in a factor graph

7.3.3 Exported Access Programs

Name	In	Out	Exceptions
Pose2	$x : \mathbb{R}, y : \mathbb{R}, \theta : \mathbb{R}$	$\mathbb{R}^3$	-
Point2	$x : \mathbb{R}, y : \mathbb{R}$	$\mathbb{R}^2$	-
symbol	char: char, int: $\mathbb{Z}$	String	-
NonlinearFactorGraph	-	Graph	-
PriorFactorPose2	$key : \mathbb{Z}, \textbf{pose} : \mathbb{R}^3, noise : Model$	Factor	-
PriorFactorPoint2	$key : \mathbb{Z}, \textbf{pose} : \mathbb{R}^2, noise : Model$	Factor	-
RangeFactor2D	$key1 : \mathbb{Z}, key2 : \mathbb{Z}, d : \mathbb{R}, noise : Model$	Factor	-
BetweenFactor	$key1 : \mathbb{Z}, key2 : \mathbb{Z}, between : Pose2, noise : Model$	Factor	-
noiseModel_Isotropic_Sigma	$dim : \mathbb{Z}, \sigma : \mathbb{R}$	Model	-
LevenbergMarquardtOptimizer	$graph : Graph, values : Values$	Values	-
Values	-	Values	-
insert	$values : Values, key : \mathbb{Z}, value :$ Pose2 or Point2	-	-
atPose2	$result : Values, key : \mathbb{Z}$	$\mathbb{R}^3$	-
compose	$T_{mf} : \mathbb{R}^3, T_{rf} : \mathbb{R}^3$	$\mathbb{R}^3$	-
inverse	$T_{rf} : \mathbb{R}^3$	$\mathbb{R}^3$	-

7.4 Semantics

7.4.1 State Variables

None

7.4.2 Environment Variables

None

7.4.3 Assumptions

None

7.4.4 Access Routine Semantics

Pose2(x, y, θ):

- output: $out := [x, y, \theta]$ (A 2D pose with orientation)
- exception: None

Point2(x, y):

- output: $out := [x, y]$ (2D position)

- exception: None

symbol($char, int$):

- output: $out := x1(pose), a1, a2, a3(beacons)$
- exception: None

NonlinearFactorGraph():

- output: $out :=$ An empty factor graph
- exception: None

PriorFactorPose2($key, pose, noise\_model$):

- output: $out :=$ Factor (A prior factor on a 2D pose)
- exception: None

PriorFactorPoint2($key, point, noise\_model$):

- output: $out :=$ Factor (A prior factor on a 2D point)
- exception: None

RangeFactor2D($key_1, key_2, measured, noise\_model$):

- output: $out :=$ Factor (A range factor between two keys)
- exception: None

BetweenFactor($key_1, key_2, measured, noise\_model$):

- output: $out :=$ Factor (A factor that enforces a relative transformation between two variables)
- exception: None

noiseModel_Isotropic_Sigma(dim, σ):

- output: $out :=$ Model (An isotropic noise model)
- exception: None

LevenbergMarquardtOptimizer($graph, values$):

- output: $out :=$ Values (Optimized results from factor graph)
- exception: None

Values():

- output: $out :=$ Values (An empty values container)
- exception: None

insert($Values, key, value$):

- transition: Adds point/pose into a Values variable according to its id (key)
- exception: None

atPose2($result, key$):

- output: $out := \hat{\mathbf{x}}$
- exception: None

compose(T_{mf}, T_{rf}):

- output: $out := T_{mr}$ (The composition of two poses)
- exception: None

inverse(T_{rf}):

- output: $out := T_{fr}$
- exception: None

8 MIS of Input Format Module

8.1 Module

input_format

8.2 Uses

- Simulation Module (Section 9)

8.3 Syntax

8.3.1 Exported Constants

None

8.3.2 Exported Access Programs

These functions are methods of the 'InputData' class instance, which must be initialized before use (example shown in section 6.3.4).

Name	In	Out	Exceptions
load_input	self	-	FileNotFoundError, ValueError
get_beacons	self	$\mathbb{R}^{N\times 2}$	-
get_fmMap	self	$\mathbb{R}^3$	-
get_mapSize	self	$\mathbb{R}^2$	-
get_trajectory	self	$\mathbb{R}^{p\times 3}$	-
get_map	self	String	-
get_ranges	self	$\mathbb{R}^N$	-
get_variances	self	$\mathbb{R}^N$	-

8.4 Semantics

8.4.1 State Variables

- input_file: String (represents the path to the user input file 'user_input.yaml')
- data: dict (storing parsed input data from YAML file).

8.4.2 Environment Variables

None

8.4.3 Assumptions

- The module will call on a pre-existing YAML file

8.4.4 Access Routine Semantics

load_input():

- transition: Reads the YAML input file and stores it in 'self.data'.
- exception: FileNotFoundError if the input file is not detected and ValueError if the YAML file is formatted incorrectly

input.get_beacons():

- output: $out := \mathbf{a}$
- exception: None

get_fmMap():

- output: $out := \mathbb{R}^{M \times 3}$
- exception: None

get_map():

- output: out:= String of picture's name
- exception: None

get_mapSize():

- output: out := [length, width] of map in meters (from user input)
- exception: None

get_trajectory():

- output: $out := \mathbb{R}^{p \times 3}$ matrix containing the robot's full trajectory over each position (x, y, θ)
- exception: None

get_ranges():

- output: $out := \tilde{\mathbf{D}}$
- exception: None

get_variances():

- output: $out := \boldsymbol{\sigma^2}$
- exception: None

9 MIS of Simulation Module

9.1 Module

simulation

9.2 Uses

None

9.3 Syntax

9.3.1 Exported Constants

None

9.3.2 Exported Access Programs

Name	In	Out	Exceptions
noisy_range	beacons: $\mathbb{R}^{N\times 2}$, variances: $\mathbb{R}^N$, trajectory: $\mathbb{R}^{p\times 3}$	$\tilde{d} : \mathbb{R}^{p\times N}$	None
fm_robot	trajectory: $\mathbb{R}^3$, fm_map: $\mathbb{R}^3$	$T_{rf} : \mathbb{R}^3$	None
visible_fms	robot_pose:$\mathbb{R}^3$, fm_map:$\mathbb{R}^{M\times 3}$	list $(i : \mathbb{Z}, T_{rf} : \mathbb{R}^3)$	None

9.4 Semantics

9.4.1 State Variables

None

9.4.2 Environment Variables

None

9.4.3 Assumptions

None

9.4.4 Access Routine Semantics

noisy_range(beacons, variances, trajectory):

 # extract robot positions
path := trajectory[:, :2] *# x, y positions only*

 # compute distances and apply Gaussian noise
r = path[:, None, :] - beacons[None, :, :]

$\eta = \sqrt{\text{variances}} * \mathcal{N}(0, 1)$

$\tilde{d} = \|r\| + \eta$

- output: $out := \tilde{d} \in \mathbb{R}^{p \times N}$ (noisy range measurements from robot to each beacon)
- exception: None

fm_robot(trajectory, fm_map):

 # extract robot and FM pose in map frame
(x_r, y_r, θ_r) = trajectory
$(x_f, y_f, \_)$ = fm_map

 # transform FM pose to robot frame
dx := $x_f - x_r$
dy := $y_f - y_r$
$x_{rel} := \cos(\theta_r) \cdot dx + \sin(\theta_r) \cdot dy$
$y_{rel} := -\sin(\theta_r) \cdot dx + \cos(\theta_r) \cdot dy$
$\phi := \arctan 2(y_{rel}, x_{rel})$

- output: $out := T_{rf} \in \mathbb{R}^3$ (relative FM pose in robot frame)
- exception: None

visible_fms(robot_pose, fm_map, max_range, fov_angle):

 # initialize list of visible FMs
visible := [ ]

 # check distance and FOV for each FM
for each (i, fm) in fm_map:
    $(x_{rel}, y_{rel}, \phi) := fm\_robot(robot\_pose, fm)$

    if $\|[x_{rel}, y_{rel}]\| \leq$ max_range and $0 \leq \phi \leq$ fov_angle:

        visible.append((i, (x_{rel}, y_{rel}, ϕ)))

- output: $out :=$ visible of (index, $T_{rf} \in \mathbb{R}^3$) (visible FMs in robot frame)
- exception: None

10 MIS of Localization Module

10.1 Module

localization

10.2 Uses

- GTSAM Module (Section 7)
- Simulation Module (Section 9)

10.3 Syntax

10.3.1 Exported Constants

None

10.3.2 Exported Access Programs

Name	In	Out	Exceptions
localize	$\mathbf{a} : \mathbb{R}^{N\times 2}, \mathbf{T}_{mf} : \mathbb{R}^3, \mathbf{T}_{rf} : \mathbb{R}^3, \tilde{\mathbf{d}} : \mathbb{R}^N$	$\mathbb{R}^3$	-

10.4 Semantics

10.4.1 State Variables

None

10.4.2 Environment Variables

None

10.4.3 Assumptions

None

10.4.4 Access Routine Semantics

localize($\mathbf{a}$, $\mathbf{T}_{mf}$ $\tilde{\mathbf{d}}$, initial_guess):

 # initialize factor graph and robot symbol
graph = NonlinearFactorGraph()
robot_id = symbol("x", 1)

 # add prior on robot pose
graph.add(PriorFactorPose2(robot_id, x_0, prior_noise))

 # add range factors to visible beacons
for each (j, position, d_j) in visible_beacons:
graph.add(RangeFactor2D(robot_id, symbol("a", j+1), d_j, range_noise))

 # fix one beacon position for stability
graph.add(PriorFactorPoint2(symbol("a", 1), position_1, beacon_noise))

 # add between factors from visible fiducial markers
for each fiducial i:
graph.add(BetweenFactor(robot_id, symbol("f", i+1), T_{rf}, pose_noise))
graph.add(PriorFactorPose2(symbol("f", i+1), T_{mf}, pose_noise))

 # initialize estimates
insert robot, beacon, and fiducial guesses into Values()

 # optimize with LM
result = LevenbergMarquardtOptimizer(graph, initial_estimates)
$\hat{x}$:= result.atPose2(robot_id)

- output: *out* := $\hat{\mathbf{x}} \in \mathbb{R}^3$
- exception: ValueError if estimation fails or result is not computable

11 MIS of Accuracy Evaluation Module

11.1 Module

accuracy

11.2 Uses

- Localization Module (Section 10)

11.3 Syntax

11.3.1 Exported Constants

None

11.3.2 Exported Access Programs

Name	In	Out	Exceptions
compute_fim	$\hat{\mathbf{x}} : \mathbb{R}^3, \mathbf{a} : \mathbb{R}^{N\times 2}, \boldsymbol{\sigma^2} : \mathbb{R}^N$	$\mathbb{R}^{2\times 2}$	-
compute_crlb	$\boldsymbol{\mathcal{I}}(\hat{\mathbf{x}}) : \mathbb{R}^{2\times 2}$	$\mathbb{R}^{2\times 2}$	-

11.4 Semantics

11.4.1 State Variables

None

11.4.2 Environment Variables

None

11.4.3 Assumptions

- Noise variances are positive

11.4.4 Access Routine Semantics

compute_fim($\hat{\mathbf{x}}, \mathbf{a}, \boldsymbol{\sigma^2}$):

- output: *out* := $\boldsymbol{\mathcal{I}}(\hat{\mathbf{x}})$ where $\boldsymbol{\mathcal{I}}(\hat{\mathbf{x}})$ is a 2×2 Fisher Information Matrix (FIM) of the estimated pose, computed as:

$$\mathcal{I}(\hat{\mathbf{x}}) = \sum_{j=1}^{N} \frac{1}{\sigma_j^2} \frac{(\hat{\mathbf{x}} - \mathbf{a}_j)(\hat{\mathbf{x}} - \mathbf{a}_j)^T}{\|\hat{\mathbf{x}} - \mathbf{a}_j\|^2}$$

where $\hat{\mathbf{x}}$ only contains x and y (making it $\mathbb{R}^2$ so it can subtract)

- exception: None

compute_crlb($\boldsymbol{\mathcal{I}}(\hat{\mathbf{x}})$):

- output: *out* := A 2×2 CRLB matrix, computed as:

$$\boldsymbol{\mathcal{C}} = \boldsymbol{\mathcal{I}}^{-1}$$

- exception: None

12 MIS of Output Module

12.1 Module

output

12.2 Uses

- Localization Module (Section 10)
- Python multiprocessing Library (Queue)

12.3 Syntax

12.3.1 Exported Constants

None

12.3.2 Exported Access Programs

Name	In	Out	Exceptions
update_table	-	-	-
run_gui	queue: Queue	-	-

12.4 Semantics

12.4.1 State Variables

- root: Tkinter root window
- tree: Treeview widget for table display
- data_queue: Shared queue received from Control Module

12.4.2 Environment Variables

- data_queue: A queue storing tuples of estimated pose data (time, x, y, theta).
- display_env: The OS-level display environment variable required to render the Tkinter GUI (e.g., '$DISPLAY' for Unix-based systems).

12.4.3 Assumptions

- The function 'run_gui()' is executed in a separate process to prevent a stalled execution.

12.4.4 Access Routine Semantics

update_table():

- transition: Retrieves the latest pose estimates from the queue and updates the Graphical User Interface (GUI) table.

run_gui(queue):

- transition: Initializes and runs the Tkinter GUI while continuously checking for pose updates.

 # Start GUI loop

root = tk.Tk() *# Root GUI window*

tree = ttk.Treeview(. . .) *# Table structure for displaying (pose_num,*x, y, θ*)*

 # Periodically check the shared queue

root.after(100, update_table) *# 100 ms update interval*

root.mainloop()

13 MIS of Plotting Module

13.1 Module

plot

13.2 Uses

- Localization Module (Section 10)

13.3 Syntax

13.3.1 Exported Constants

None

13.3.2 Exported Access Programs

Name	In	Out	Exceptions
plot_localization_live	$\mathbf{a} : R^{N\times 2}, \mathbf{T}_{mf} : R^3$, map: String (filepath), show: $\mathbb{B}$	-	-
update_trajectory	$\hat{\mathbf{x}} : R^3$	-	-

13.4 Semantics

13.4.1 State Variables

- trajectory: Global sequence updated by 'update_trajectory()' from Control Module (section 6).

13.4.2 Environment Variables

- plot_env: The Matplotlib interactive rendering backend required to run real-time plotting.

13.4.3 Assumptions

- 'plot_localization_live()' is run in an interactive Matplotlib session.
- 'update_trajectory()' is only called when valid estimated poses exist.
- 'plot_env' supports 'plt.ion()' and 'plt.pause()' for animation updates.
- localize()(Section 10) either returns a valid pose or raises an exception.

13.4.4 Access Routine Semantics

plot_localization_live($\mathbf{a}, \mathbf{T}_{mf}$, map, **path**, map_size, show=True):
 # render map background and plot fixed elements
img = plt.imread(map)
plt.imshow(img, extent=[0, map_size[0], 0, map_size[1]])
plt.plot(a[:, 0], a[:, 1], 'o') *# beacons*
plt.plot(T_{mf}[:, 0], T_{mf}[:, 1], 'x') *# fiducial markers*
plt.plot(path[:, 0], path[:, 1], '–') *# ground truth trajectory*

 # initialize plot elements
robot_trajectory, = plt.plot([], [], 'r-')
triangle_patch = Polygon([], closed=True, color='red')
plt.gca().add_patch(triangle_patch)

 # begin animation loop
ani = FuncAnimation(fig, update, interval=200)
if show: plt.show()

- transition: Initializes and continuously updates a real-time localization plot.
- output: None (renders a live plot in Matplotlib)
- exception: RuntimeError if the Matplotlib backend does not support animation

update_trajectory($\hat{\mathbf{x}}$):

- transition: Called repeatedly by Matplotlib's 'FuncAnimation' to retrieve and render the latest estimated pose from the global 'trajectory'

13.4.5 Local Functions

update(frame):
 # update robot path and triangle orientation
x, y, θ := trajectory[frame]
robot_trajectory.set_data(... up to frame ...)
triangle_patch.set_xy(...) *# rotated triangle*

- transition: Retrieves the latest estimated pose from the trajectory and updates the visualization.

References

Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. *Fundamentals of Software Engineering*. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.

Daniel M. Hoffman and Paul A. Strooper. *Software Design, Automated Testing, and Maintenance: A Practical Approach*. International Thomson Computer Press, New York, NY, USA, 1995. URL http://citeseer.ist.psu.edu/428727.html.