AVR Extended Mode Wiring Diagram

In order to get the "impossible" combinations to work, these switches are wired backwards with the NO contacts connected to ground and the COM connected to the encoder or previous switch.

