
MICROCONTROLLER
AUTO RESET
TFT DISPLAY
INPUT
STORAGE
ESP32-WROVER-I
PCF8574
MICROSD-PUSH-OUT
ESD0402
JP Bootstrap
ESPLAY MICRO
26/09/2019 14:58
FUJI PEBRI
Sheet: 1/2
Rev: 2.1


POWER SUPPLY & CHARGER
USB TO SERIAL
AUDIO
*note Y1 doesn't need if using CH340C
LTC4054LES5-4.2#TRPBF
PAM8403
PAM84031
UDA1334ATS
I2C Audio DAC'
Op. Temp: -40~85°C'
MIC5219 3.3V
ESPLAY MICRO
26/09/2019 14:58
FUJI PEBRI
Sheet: 2/2
Rev: 2.1