

Installation Guide: Mounting the Array

Begin by fixing the base rail to the concrete pad using the four anchor bolts supplied in the kit. Torque each bolt in a diagonal sequence so the rail seats evenly.

Slide the sensor carriage onto the rail and engage the locking cam. The cam handle must point toward the cable tray when locked.

Finally, route the harness through the strain-relief loop before connecting it to the junction box; leave a full hand-width of slack at the connector.

SAFETY NOTE

De-energize the junction box before routing the harness.

TOOLS

Torque wrench, 8 mm hex bit, cable ties.

SUPPORT

Quote the rail serial number when opening a ticket.