



Djekrev Model: iKSTD-W11

ANTI-THEFT iPad KIOSK STAND

Wall & Desk Mount · Adjustable Tilt & Swivel · Keyed Lock

Thank you for your purchase. This secure enclosure locks an iPad to a wall or counter as a self-service kiosk, POS terminal, or check-in display. The dual-pivot arm lets you set the perfect viewing angle, and the keyed lock keeps the tablet protected at all times.

WHAT'S IN THE BOX

- 1 × Tablet Enclosure (front frame + back tray)
- 1 × Adjustable Mounting Bracket (with wall/desk plate)
- 1 × Set of EVA Foam Pads (for fit adjustment)
- 2 × Keys
- 4 × Mounting Screws (self-tapping)
- 4 × Wall Anchors
- 1 × Open-End Wrench



FITS THESE iPad MODELS

iPad Model	Screen	Back Model No. (US)
iPad Air 11" (M4)	11"	A3459 / A3460
iPad Air 11" (M3)	11"	A3266 / A3267
iPad Air 11" (M2)	11"	A2902 / A2903
iPad (A16)	11"	A3354 / A3355
iPad 10th gen (A14)	10.9"	A2696 / A2757

How to check: read the A-model number on the back of your iPad. EVA foam pads are included to fine-tune the fit.

SPECIFICATIONS

Material	Aluminum enclosure + powder-coated steel base plate	Mounting	Wall or flat desk / counter
Angle	Dual-pivot tilt + swivel	Security	Keyed cam lock, 2 keys
Access	Camera, button & charging cut-outs	Color	Black / Silver

INSTALLATION


STEP 1 MARK THE HOLES

- Hold the bracket plate against the wall or desktop and mark the 4 hole positions.
- Tip: detach the plate if necessary and use it as a drilling template.



STEP 2 DRILL & FIX

- Drill the 4 marked holes with an electric drill.
- On wood walls, studs, or solid-wood desktops, drive the self-tapping screws straight in — no anchors needed.
- On drywall, concrete, brick, or tile, insert the supplied wall anchors first, then drive the screws.



STEP 3 FIX THE BRACKET

- Secure the mounting bracket to the wall or desk with the 4 screws.
- Make sure it is firm and level before mounting the tablet.



STEP 4 INSERT THE IPAD

- Open the enclosure.
- If you have the iPad Air (the thinner of the two supported models), or the iPad doesn't sit snugly / moves after mounting, stick the included EVA foam pads onto the empty areas inside the tray for a tighter fit.
- Place the iPad into the back tray, then close the cover — it should sit firm and rattle-free.



STEP 5 CLOSE & LOCK

- Close the front cover and lock it with key.
- Keep both keys in a safe place — the iPad cannot be released without a key.



SAFETY & CARE

- Mount only on a solid, load-bearing surface.
- Keep keys away from customers — they are required to release the iPad.
- Do not overtighten the screws or force the lock.
- Clean with a dry or lightly damp cloth only; avoid solvents.
- For indoor use.

Theft deterrent, not theft-proof. This enclosure and lock are intended to discourage casual, opportunistic theft. They cannot prevent destructive tampering, forced entry with tools, or removal of the entire bracket from the wall or desktop. For high-risk locations, use additional security measures and do not leave the device unattended.