


Trident Premier DF STICK SIGN CABINET LIGHTING INSTALLATION GUIDE


CHANNEL LETTER LED LIGHTING

TRIDENT PREMIER DF STICK INSTALLATION DIAGRAM

Put Trident Premier DF Stick in sign bow(or sign cabinet), use VHB or screw to fix brackets, both add silicone for fastness and security, please pay attention to measure the spacing.(see Figure)



Wiring and installation diagram




Trident Premier DF Stick



INSTALLATION GUIDE

LED LIGHTING

WIRING DIAGRAM





LED LIGHTING

TRIDENT SF/DF STICKS PLICING GUIDE **Trident Premier DF Stick**


Regular Size


Part NO.	Size	Power Consumption
Trident DF Premier Stick 18IN	386mm(15.2in)	6.5W
Trident DF Premier Stick 42IN	994mm(39.2in)	26W
Trident DF Premier Stick 64IN	776mmX2(30.6inX2)	32.5W
Trident DF Premier Stick 2FT	537.5mm(21.2in)	13W
Trident DF Premier Stick 4FT	1147mm(45.2in)	26W
Trident DF Premier Stick 6FT	877mmX2(34.5inX2)	39W
Trident DF Premier Stick 8FT	1180.5mmX2(46.5inX2)	52W
Trident DF Premier Stick 10FT	1498mmX2(59inX2)	65W


Part NO.	Size	Power Consumption
Trident DF Premier Stick 3FT	1 FT add on parts + Stick 2FT	19.5W
Trident DF Premier Stick 5FT	1 FT add on parts + Stick 4FT	32.5W
Trident DF Premier Stick 7FT	1 FT add on parts + Stick 6FT	45.5W
Trident DF Premier Stick 9FT	1 FT add on parts + Stick 8FT	58.5W

Part NO.	Size	Power Consumption
1 FT add on parts	12IN	6.5W

How to make a 5FT











LED LIGHTING

RETROFIT INSTALLATION-1

- 1, Cut off power supply
- 2, Take down the tubes



Put aluminum rod in the mounting head







LED LIGHTING

RETROFIT INSTALLATION-2

If the T8 tube's support base like "Diagram A" You need to use HO sockets to install Trident Premier DF Stick.



In this condition, you can make the Trident Premier DF Stick face to The acrylic board correctly with the HO sockets.





INSTALLATION GUIDE


CHANNEL LETTER LED LIGHTING

NEW INSTALLATION


Fix the upper bracket and lower bracket



Put aluminum rod into bracket from side



Please pay more attention to The spacing when you install it



64In,6Ft,8Ft and 10Ft aluminum rod need to use the middle connector



