



What ros2 run controller_manager spawner leg_controller does internally

1. Calls the service `/controller_manager/load_controller`
 - controller_manager reads `controllers.yaml`, finds `leg_controller.type`
 - loads `forward_command_controller/ForwardCommandController` via `dlopen`
2. Calls the service `/controller_manager/configure_controller`
 - controller reads its joints list from `controllers.yaml`
 - requests `r_hip_roll/position`, `r_hip_pitch/position` ... from `ResourceManager`
 - `ResourceManager` checks no other controller owns them → grants claim
3. Calls the service `/controller_manager/switch_controller (activate)`
 - controller subscribes to `/leg_controller/commands`, enters `update()` loop