Piezo Speaker

 Connect to a Pulse Width Modulation (PWM) pin onthe Touch or Robotics Board to program a tone.



Generate several tones in sequence to play a song.

CrazyCircuits.com

Play Tones Pur + Touch Board 23 VIN 3.3V 0/TX 1/RX

CrazyCircuits.com