

Experimental Procedures

Step 1: Build the circuit (please be sure the pins are connected correctly. Otherwise, characters will not be displayed properly):

LCD1602	T-Extension Board
VDD	5V
VSS	GND
OV	Connect to the middle pin of potentiometer
RS	B27
R/W	GND
E	B22
D0-D3	Not connected
D4	B25
D5	B24
D6	B23
D7	B18
A	3.3V
K	GND

