

Preparing for the

STM32U5 Azure IoT

Hands-on Workshop

Contents

All steps must be completed BEFORE Starting the Hands-On Workshop

1 Workshop Prerequisites

2 Installing and Verifying Dependencies



Workshop Prerequisites



Workshop Prerequisites

- This hands-on training is a working session and requires a PC or laptop running the 64-bit version of Windows® 10 or later
- Administrator rights are needed for software and driver installation
- One spare USB port will be required
- You will need the following hardware for the workshop:
 - B-U585I-IOT02A Discovery Kit (provided)
 - USB-A to Micro-B cable (provided)



Workshop - Preparation

HW Platform: B-U585I-IOT02A



Software Content

Name	Date modified	Туре	Size
📙 .git	9/29/2022 2:58 PM	File folder	
docs	9/29/2022 3:15 PM	File folder	
scripts	9/28/2022 1:03 PM	File folder	
gitignore	9/28/2022 1:03 PM	Text Document	1 KB
AzCheckPrereq.bat	9/29/2022 2:57 PM	Windows Batch File	5 KB
CODE_OF_CONDUCT.md	9/28/2022 1:03 PM	MD File	4 KB
CONTRIBUTING.md	9/28/2022 1:03 PM	MD File	1 KB
credentials.txt	9/28/2022 1:03 PM	Text Document	1 KB
LICENSE.md	9/28/2022 1:03 PM	MD File	1 KB
SECURITY.md	9/28/2022 1:03 PM	MD File	2 KB



Software Prerequisites

- Python 3: Object oriented open-source programming language
 - Pip: Python package installer
 - <u>Pyserial</u>: Python library used for Serial Communication
- Azure Command Line Interface (AZ CLI): set of commands used to create and manage Azure resources
- <u>STM32CubeProgrammer</u>: all-in-one multi-OS software tool for programming STM32 products
- X-CUBE-AZURE: Expansion Package that consists of a set of libraries and application examples for STM32U5 Series microcontrollers acting as Azure IoT end devices



AzPrereqCheck.bat Description

- This script validates that the host machine meets all the required prerequisites:
 - Python 3
 - Pip
 - Pyserial
 - Azure Command Line Interface (AZ CLI)
 - <u>STM32CubeProgrammer</u>
 - X-CUBE-AZURE
 - Active Azure account
- If a tools isn't installed the script will download (if applicable) and install it



Installing and Verifying Dependencies



Step by step Guide

- 1) Follow the instructions (this document)
- 2) Run the prerequisite installation and validation tool

	Name	Date modified	Туре	Size	
	📜 .git	9/29/2022 2:58 PM	File folder		
1)	- docs	9/29/2022 3:15 PM	File folder		
	scripts	9/28/2022 1:03 PM	File folder		
	gitignore	9/28/2022 1:03 PM	Text Document	1	1 KB
2)	AzCheckPrereq.bat	9/29/2022 2:57 PM	Windows Batch File	5	5 KB
	CODE_OF_CONDUCT.md	9/28/2022 1:03 PM	MD File	4	4 KB
	CONTRIBUTING.md	9/28/2022 1:03 PM	MD File	1	1 KB
	credentials.txt	9/28/2022 1:03 PM	Text Document	1	1 KB
	LICENSE.md	9/28/2022 1:03 PM	MD File	1	1 KB
	SECURITY.md	9/28/2022 1:03 PM	MD File	2	2 KB




1) Double click the AzCheckPrereq.bat

Name	Date modified	Туре	Size
📜 .git	9/29/2022 2:58 PM	File folder	
docs	9/29/2022 3:15 PM	File folder	
scripts	9/28/2022 1:03 PM	File folder	
gitignore	9/28/2022 1:03 PM	Text Document	1 KB
2) AzCheckPrereq.bat	9/29/2022 2:57 PM	Windows Batch File	5 KB
CODE_OF_CONDUCT.md	9/28/2022 1:03 PM	MD File	4 KB
CONTRIBUTING.md	9/28/2022 1:03 PM	MD File	1 KB
credentials.txt	9/28/2022 1:03 PM	Text Document	1 KB
LICENSE.md	9/28/2022 1:03 PM	MD File	1 KB
SECURITY.md	9/28/2022 1:03 PM	MD File	2 KB



- In the case that you have the prerequisites installed the window will look as follows
- NOTE: IF YOU ARE MISSING ANY REQUIRED SOFTWARE THE SCRIPT WILL INSTALL IT TO YOUR MACHINE AND PROMPT YOU TO RUN AGAIN





- If dependencies were installed by the script, please run the script again.
- The script will then add a few necessary Az CLI extensions

```
Extension 'azure-iot' is already installed.


No updates available for 'azure-iot'. Use --debug for more information.

Extension 'account' is already installed.

No updates available for 'account'. Use --debug for more information.
```



- The script will then open an Azure Login page in a default browser window
- When this window is displayed the host machine is ready to begin the hands on





Thank you



ST logo is a trademark or a registered trademark of STMicroelectronics International NV or its affiliates in the EU and/or other countries. For additional information about ST trademarks, please refer to www.st.com/trademarks.
All other product or service names are the property of their respective owners.

