

A330 Memory Items, FCOM R17 [MEM] procedures

10 procedures. Boxed lines verbatim from the rendered FCOM pages, visually verified. ha330pilot.app · FCOM R17 (15 MAY 26) · study aid only, the current manual governs

EMER DESCENT

1. CREW OXY MASKS ... USE
2. SIGNS ... ON
3. EMER DESCENT ... INITIATE
4. THR LEVERS ... IDLE
5. SPD BRK ... FULL

FCOM R17 PRO-ABN-MISC P1/26 and QRH R35 22.02A ·
PRO-ABN-MISC-00012261.0001001

STALL RECOVERY

1. NOSE DOWN PITCH CONTROL ... APPLY
2. BANK ... WINGS LEVEL
3. THRUST ... INCREASE SMOOTHLY AS NEEDED
4. SPEEDBRAKES ... CHECK RETRACTED
5. FLIGHT PATH ... RECOVER SMOOTHLY
6. FLAPS 1 ... SELECT

FCOM R17 PRO-ABN-MISC P2/26 · PRO-ABN-MISC-00013664.0002001

STALL WARNING AT LIFTOFF

1. THRUST ... TOGA
2. PITCH ATTITUDE ... 15 °
3. BANK ... WINGS LEVEL

FCOM R17 PRO-ABN-MISC P3/26 · PRO-ABN-MISC-00013665.0002001

UNRELIABLE SPEED INDICATION

If the safe conduct of the flight is impacted

1. AP ... OFF
 2. A/THR ... OFF
 3. FD ... OFF
- PITCH/THRUST
4. Below THRUST RED ALT ... 15° / TOGA
 5. Above THRUST RED ALT and Below FL 100 ... 10° / CLB
 6. Above THRUST RED ALT and Above FL 100 ... 5° / CLB
 7. FLAPS (if CONF 0(1)(2)(3)) ... MAINTAIN CURRENT CONF
 8. FLAPS (if CONF FULL) ... SELECT CONF 3 AND MAINTAIN
 9. SPEEDBRAKES ... CHECK RETRACTED
 10. L/G ... UP

When at or above MSA or Circuit Altitude: Level off for troubleshooting
QRH R35 23.03A · ABN-23-A-00017854.0001001

LOSS OF BRAKING

If no braking:

1. REV ... MAX
2. BRAKE PEDALS ... RELEASE
3. A/SKID OFF ... ORDER
4. A/SKID & N/W STRG ... OFF
5. BRAKE PEDALS ... PRESS
6. MAX BRK PR ... 1000 PSI

If still no braking:

7. PARK BRAKE ... USE

FCOM R17 PRO-ABN-BRAKES P 1/16 · PRO-ABN-BRAKES-00010803.0001001

TAWS CAUTION

"TERRAIN TERRAIN" - "TOO LOW TERRAIN" - "TERRAIN AHEAD" -
"CAUTION TERRAIN" - "OBSTACLE AHEAD" - "CAUTION
OBSTACLE"

During night or IMC conditions:

Simultaneously:

1. AP ... OFF
 2. PITCH ... PULL UP
 3. THRUST LEVERS ... TOGA
 4. SPEED BRAKE LEVER ... CHECK RETRACTED
 5. BANK ... WINGS LEVEL or ADJUST
- DO NOT CHANGE CONFIGURATION (SLATS/FLAPS, GEAR) UNTIL
CLEAR OF OBSTACLE.

*During daylight and VMC conditions, with terrain and obstacles clearly
in sight:*

6. FLIGHT PATH ... ADJUST

"SINK RATE"

Above 1 000 ft AAL IMC or above 500 ft AAL VMC:

7. FLIGHT PATH ... ADJUST

Below 1 000 ft AAL IMC or below 500 ft AAL VMC:

8. GO-AROUND ... CONSIDER

"DON'T SINK"

9. FLIGHT PATH ... ADJUST

"TOO LOW GEAR" or "TOO LOW FLAPS"

10. GO-AROUND ... PERFORM

"GLIDESLOPE"

Above 1 000 ft AAL IMC or above 500 ft AAL VMC:

11. FLIGHT PATH ... ADJUST

When conditions require a deliberate approach below glideslope:

12. G/S MODE ... OFF

Below 1 000 ft AAL IMC or below 500 ft AAL VMC:

13. GO-AROUND ... CONSIDER

FCOM R17 PRO-ABN-SURV P 1/8 to 2/8 · PRO-ABN-SURV-AA-00026795.0001001

TAWS WARNING

If the TAWS triggers one of the PULL UP alerts:

Simultaneously:

- 1. AP ... OFF**
 - 2. PITCH ... PULL UP**
 - 3. THRUST LEVERS ... TOGA**
 - 4. SPEED BRAKE LEVER ... CHECK RETRACTED**
 - 5. BANK ... WINGS LEVEL or ADJUST**
- DO NOT CHANGE CONFIGURATION (SLATS/FLAPS, GEAR) UNTIL CLEAR OF OBSTACLE.**

FCOM R17 PRO-ABN-SURV P 3/8 · PRO-ABN-SURV-00026799.0001001

TCAS CAUTION - TRAFFIC ADVISORY

Do not perform a maneuver based on a TA alone.

FCOM R17 PRO-ABN-SURV P 3/8 · PRO-ABN-SURV-00025042.0001001

TCAS WARNING - RESOLUTION ADVISORY

All RA, except any CLIMB RA during approach in CONF 3 or FULL:

- 1. AP (if engaged) ... OFF**
 - 2. BOTH FDs ... OFF**
 - 3. VERTICAL SPEED ... ADJUST or MAINTAIN**
- Any CLIMB RA during approach in CONF 3 or FULL:*
- 4. GO-AROUND ... PERFORM**
 - 5. VERTICAL SPEED ... MONITOR**
 - 6. ATC ... NOTIFY**
- When the "CLEAR OF CONFLICT" aural alert sounds:*
- 7. ATC ... NOTIFY**
 - 8. LATERAL AND VERTICAL GUIDANCE ... ADJUST**
 - 9. AP/FD ... AS RQRD**

FCOM R17 PRO-ABN-SURV P 4/8 to 5/8 · PRO-ABN-SURV-00011464.0005001

WINDSHEAR WARNING - REACTIVE WINDSHEAR

At Takeoff:

Before V1:

If there are significant variations in airspeed, and in airspeed trend below the indicated V1, reject the takeoff.

After V1:

- 1. THR LEVERS ... TOGA**
- 2. REACHING VR ... ROTATE**
- 3. SRS ORDERS ... FOLLOW**

When airborne, during initial climb, or at landing:

- 4. THR LEVERS AT TOGA ... SET OR CONFIRM**
- 5. AP (if engaged) ... KEEP ON**
- 6. SRS ORDERS ... FOLLOW**

DO NOT CHANGE CONFIGURATION (SLATS/FLAPS, GEAR) UNTIL OUT OF WINDSHEAR.

CAREFULLY MONITOR FLIGHT PATH AND SPEED.

WHEN OUT OF WINDSHEAR, SMOOTHLY RECOVER NORMAL CLIMB.

FCOM R17 PRO-ABN-SURV P 6/8 to 7/8 · PRO-ABN-SURV-00012300.0001001