MARCH6N Pattern

Sequence:

1. Write a background pattern of 0-data
2. Read and verify the first location and write I-data to it. Step through every remaining location, reading and verifying 0-data and writing I-data
3. Starting with the last location and working backwards, read and verify I-data and write 0-data to every cell
4. Starting with the first location and working forwards, read and verify 0-data in every cell
5. Repeat above steps for all banks

1.

2.

row

column

3.

4.