```
quick2wire-gpio-admin
                               <<File>>
                             gpio-admin.c
+usage error(argv : char **) : void
+allow access by user(pin: int unsigned, filename: const char*): ...
+parse gpio pin(pin srt : const char *) : unsigned int
+write pin to path(path: const char *, pin: unsigned int): void
+set pullupdown(pin: int, direction: int): void
+main(argc: int, argv: char **): int
```