
ROS-2 Control


- Command Interface
- State Interface



http://control.ros.org/getting_started.html



- Position Controller
- Acceleration Controller
- Velocity Controller
- Joint Trajectory Controller



Install a Controller

Frohits
type

the
connected
state

Controller yand

Z Control >
8 I

Contaller manager.
Undfreambler
Contaller
Contaller