## **INSTRUCTIONS for HDI CALIBRATION- STEP ONE**

## Line up your X on the Base Long & notch on the Base Code Disk

- 1. A successful Step One process MUST be completed before proceeding with Step Two.
- 2. reboot Dexter


Write files to the robot's hard drive using WinSCP. Open WinSCP App




## Host 192.168.1.142 Username: root Password: klg

In the left window locate the folder that has the Dexter files that need to be written to the Dexter Hard Drive.


In the right window locate Dexter robot's hard drive file folder as shown below.




Open the dde\_apps folder on the left and open /srv/samba/share/dde\_apps/ folder on the right, Select all files on left, hit F5 and OK




Open the share folder on the left and open srv/samba/share folder on the right. Select all files on left, hit F5 and OK



Open the www folder on the left and open srv/samba/share/www folder on the right. Select all files on left, hit F5 and OK




Open the core folder on the left and open root/documents/dde/core folder on the right. Select all files on left, hit F5 and OK



## **Step Two is Almost COMPLETE – Power cycle Dexter**

Follow the steps below to modify the time on the new Dexter. Start the PuTTY App






At root@localhost:~# type cd /srv/samba/share/

Hit Enter


At root@localhost:/srv/samba/share# Type date -s "12Dec19"

Hit Enter

(Enter today's date in this format)



When you see the screen show the updated time to the left, this process is finished.



At root@localhost:/srv/samba/share#

Type ./pg

Hit Enter

(It may take a minute)

After a minute or so you will see the rest of this printout as shown.

cot@localhost/srv/samba/share

login as: root

Last login: Thu Feb 11 16:50:13 2016 from 192.168.1.46

Welcome to the Xillinux-2.0 distribution for Xilinx Zyng.

You may communicate data with standard FFGA FIFOS in the logic fabric by writing to or reading from the /dev/xillybus \* device files. Additional pipe files of that sort can be set up with a custom Xillybus IF core.

For more information: http://www.xillybus.com.

To start a graphical X-Windows session, type "startx" at shell prompt.


root@localhost:~# cd /srv/samba/share/
root@localhost:/srv/samba/share# nano Defaults.make\_ins

To update the serial number

At root@localhost:/srv/samba/share#

Type nano Defaults.make\_ins

Hit Enter



Update the six digit Dexter Serial Number with the new Dexter's unique serial number displayed on the Pivot. Replace the XXXXXX with six digit serial number.

Hit Ctrl+O, then hit enter to save the file, then hit Ctrl+X to exit.

This number is used to set the MAC address and is needed to avoid network collisions between two or more Dexters on the same network.

Power cycle then,

**Proceed to Step Two**