

Tutorial switch modat

[Vezi temele personalizate](#)

Bun venit la tutorialul care te va ajuta sa folosesti Nintendo Switch-ul modat.



Site-uri pentru jocuri:

- <https://not.ultranx.ru> - Recomandare primara
- <https://nxbrew.net/>
- <https://nswrom.com/>
- <https://taodung.com/>
- <https://switchgamesmall.icu/>
- <https://romsim.com/>
- <https://romslab.com/>
- <https://switchroms.io/>

Pornirea consolei

Pentru inceput daca consola este oprita pentru a executa payload-ul instalat dupa modare se va apasa scurt butonul de pornire si se v-a astepta cateva secunde pentru ca consosola sa intre in bootloaderul **HEKATE IPL**.. Este posibil ca consola sa nu porneasca din prima incercare din diverse motive, astfel se v-a repeta din nou apasarea butonului pana ce va intra in bootloader.

ATENTIE! A NU SE APASA LUNG PE BUTONUL DE PORNIRE





Official Firmare sau Custom Firmware sau Android

Official Firmware



Pentru a accesa Firmware-ul original cu care a venit consola, dupa ce s-a incarcat **Bootloaderul Hekate IPL** se va apasa cu degetul pe butonul de **Reboot** apoi se v-a selecta **OFW (Normal)** inseamna ca v-a intra din nou in **HEKATE IPL**.

Aici puteti folosi Switch-ul in mod normal cum a venit din fabrica.



Custom Firmware **ATENTIE!**



Pentru a intra in Firmware-ul custom care te v-a lasa sa instalezi jocuri backup sau sa aplici teme custom sau tot felul de modificari software ale consolei, **MAJORITATEA TIMPULUI SE V-A SELECTA EMUMMC CFW** din meniul **Launch**, celelalte optiuni sunt pentru utilizatorii avansati care stiu ce vor sa faca.



Instalare de jocuri

Dupa ce s-a incarcat, puteti sa v-a jucati jocurile instalate la cerere sau puteti instala jocuri la randul vostru.

Pentru a instala un joc, recomand sa folositi **DB Installer/DBI** care il puteti accesa din meniul de **Album**. Urmatorul pas este sa conectati consola la un **PC/Laptop** (voi folosi **Windows**), apoi se v-a executa **Run MTP responder** din acea lista, un folder ar trebui sa se deschida automat, puteti instala jocuri in **copiind fisierele dezarhivate(cu WinRAR sau 7zip) in partitia SD Card Install (se pot instala mai multe deodata)**. Daca jocul nu este actualizat instalati si update-ul pentru joc care de obicei este descarcat separat.



```

DBI: 658-en FW:20.3.0E 2025-09-19 12:47:46
Main menu

Browse SD Card
Install title from DBIbackend
Connect to server...
DBILogs
Browse installed applications
Tools
Browse tickets
Browse saves
Run MTP responder
Run FTP server
Run HTTP server
Activity log
Configuration
Exit

SD: 121.80/134 GB NAND: 19.51/26 GB 32°C 31%

```

```

DBI: 658-en FW:20.3.0E 2025-09-19 13:03:49
MTP Responder (press B to stop)

Scanning applications.....done
Found 3 users
UID: 1000067FB54241035DB88AD3B005FD9B3, Nick: AlviMC
UID: 100008FF24B7B6775DB88AD3B005FD9B3, Nick: AlviJP
UID: 100000000040A2A2DB88AD3B005FD9B3, Nick: xLucatukx
Found 42 saves
System: 0 saves
Account: 37 saves
BCAT: 3 saves
Device: 0 saves
Temporary: 0 saves
Cache: 2 saves
SystemBCAT: 0 saves
Enumerating album items on NAND
Found 191 album items
Enumerating album items on SD Card
Found 14 album items

Checking gamecard...[OK]
Android extensions: no
Waiting interface to be ready: [OK]
Actual USB speed: USB 2.0 High Speed
Server started

Session opened
Initiator: Windows/10.0.22631 MTPClassDriver/10.0.22621.0

SD: 121.80/134 GB NAND: 19.51/26 GB 33°C 29%

```

The image shows two screenshots of a Windows File Explorer window. The top screenshot shows the 'This PC' view with the 'Devices and drives' section highlighted. The bottom screenshot shows the 'Switch' view with the '5: SD Card install' item highlighted.


Top Screenshot: This PC

- Address bar: This PC
- Search bar: Search This PC
- Left sidebar: Downloads, Documents, Pictures, Music, Videos, Scoala, TEMP, bootloader, scripts, switch, screenshots, This PC (selected), Switch, KINGSTONE DRIVE (C:), Network, Linux, Debian, debian-wsl2.
- Main area: Devices and drives section highlighted. It shows a 'Switch' icon and a 'KINGSTONE DRIVE (C:)' icon with a progress bar indicating 177 GB free of 802 GB.
- Bottom status bar: 2 items

Bottom Screenshot: Switch

- Address bar: This PC > Switch
- Search bar: Search Switch
- Left sidebar: Same as the top screenshot, with 'Switch' selected.
- Main area: A grid of 9 items, each with a progress bar and storage information:
 - 1: SD Card: 121 GB free of 133 GB
 - 2: Nand USER: 19.5 GB free of 25.9 GB
 - 3: Nand SYSTEM: 962 MB free of 2.49 GB
 - 4: Installed games: 121 GB free of 133 GB
 - 5: SD Card install: 121 GB free of 133 GB (highlighted with a red box)
 - 6: NAND install: 19.5 GB free of 25.9 GB
 - 7: Saves: 19.5 GB free of 25.9 GB
 - 8: Album: 121 GB free of 133 GB
 - 9: DBILogs: 121 GB free of 133 GB
- Bottom status bar: 9 items


Tutorial switch modat






Teme personalizate

Pentru a instala o tema noua, se v-a utiliza **Themezer-NX** sau daca nu functioneaza folositi **NXThemes-Installer**. Cel mai simplu este sa folositi **Themezer-NX**, dar acesta poate sa nu functioneze cateodata (serverul nu este online sau nu este actualizat). Folosind **Themezer-NX** este foarte simplu, selectati o tema care v-a place si instalati pe rand toate "subtemele" selectandu-le si apasand butonul verde de **Install**, dupa ce ati facut acest lucru apasati pe + de doua ori de pe joycon pentru a instala, dati reboot pentru a aplica tema. **DACA DUPA APLICARE NU SE MAI POATE ACCESA CFW, INTRATI IN HAKATE-IPL->TOOLS->USB TOOLS->SD CARD SI CONECTATI SWITCH-UL LA PC/LAPTOP SI STERGETI FOLDERUL 0100000000001000 DIN ATMOSPHERE/CONTENTS DIN PARTITIA SDCARD. DACA PROBLEMA PERSISTA LA MAJORITATEA TEMELOR, INCERCATI SA NU INSTALATI TEMA DE LOCKSCREEN, DACA INCA PERSISTA ESTE POSIBIL CA FIRMWARE-UL SA FIE PREA NOU SI TREBUIE ASTEPTAT PENTRU VERSIUNI MAI NOI DE THEMEZER.** Pentru varianta **NXThemes-Installer** se vor descarca temele de pe internet (de pe site-ul [Themezer](#) sau alte site-uri care credeti ca sunt de incredere) apoi se vor incarca in folderul Themes (daca nu exista se v-a crea) cu switch-ul conectat la **PC/Laptop** din partitia **SD CARD**.

Themezer







Install theme(s) from external source

Totoro Home

Home menu - press X for preview

by blavla - FairTech Animated by FairTech


Press + to install, B to cancel

Installation completed.

Exit to homebrew launcher

Reboot

NxThemes-Installer



NXThemes Installer Ver. 2.8.2

Themes

Download themes

Uninstall theme

Extract home menu

Settings

Credits

Reboot

Quit

All Apps

sdmc:/themes/ThemezerNX/All Apps

folder

Home Menu

sdmc:/themes/ThemezerNX/Home Menu

folder

Totoro Home

by blavla - FairTech Animated by FairTech

Home menu - press X for preview

Red dead Redemption home

by josephy832 - Small Compact Homescreen by Akai

Home menu - press X for preview

Lock Screen

sdmc:/themes/ThemezerNX/Lock Screen

folder

Player Select

sdmc:/themes/ThemezerNX/Player Select

folder

Settings

sdmc:/themes/ThemezerNX/Settings

folder

A: Install theme Y: Multiselect L/R: Previous/Next page

sdmc:/themes/ThemezerNX/ - Page 1/1

NXThemes Installer Ver. 2.8.2

Themes

Download themes

Uninstall theme

Extract home menu

Settings

Credits

Reboot

Quit

Totoro allapps

by caki88 - All Apps 90% Scale by Such Meme, Many Skill

All apps menu - press X for preview

A: Install theme Y: Multiselect L/R: Previous/Next page

sdmc:/themes/ThemezerNX/All Apps/blavla/ - Page 1/1


Done, restart the console to apply the changes

OK



Altele

Unele aplicatii nu pornesc sau dau crash la firmware un motiv ar fi ca sunt pornite in modul **Applet**, o posibila remediere este sa il porniti in modul **Full memory/Non-Applet** tinand apasat butonul **R** de pe joycon in timp ce porniti un joc si selectati user-ul, daca ati executat cu bine instructiunea se v-a deschide **HBMENU** si nu v-a aparea **Applet Mode**.

Applet



Non-Applet



Android

Partitia de Android se gaseste in meniul **More Configs->LineageOS**.

