

CSL373: Lecture 16 I/O and Disks

The Requirements of I/O

- So far in this course:
 - We have learned how to manage CPU, memory
- What about I/O?
 - Without I/O, computers are useless (disembodied brains?)
 - But... thousands of devices, each slightly different
 - How can we standardize the interfaces to these devices?
 - Devices unreliable: media failures and transmission errors
 - How can we make them reliable???
 - Devices unpredictable and/or slow
 - How can we manage them if we don't know what they will do or how they will perform?
- Some operational parameters:
 - Byte/Block
 - Some devices provide single byte at a time (e.g. keyboard)
 - Others provide whole blocks (e.g. disks, networks, etc)
 - Sequential/Random
 - Some devices must be accessed sequentially (e.g. tape)
 - Others can be accessed randomly (e.g. disk, cd, etc.)
 - Polling/Interrupts
 - Some devices require continual monitoring
 - Others generate interrupts when they need service



Example Device-Transfer Rates (Sun Enterprise 6000)



- Device Rates vary over many orders of magnitude
 - System better be able to handle this wide range
 - Better not have high overhead/byte for fast devices!
 - Better not waste time waiting for slow devices

The Goal of the I/O Subsystem

- Provide Uniform Interfaces, Despite Wide Range of Different Devices
 - This code works on many different devices:

```
FILE fd = fopen("/dev/something","rw");
for (int i = 0; i < 10; i++) {
  fprintf(fd,"Count %d\n",i);
}
close(fd);</pre>
```

- Why? Because code that controls devices ("device driver") implements standard interface.
- We will try to get a flavor for what is involved in actually controlling devices in rest of lecture
 - Can only scratch surface!

Want Standard Interfaces to Devices


- Block Devices: e.g. disk drives, tape drives, DVD-ROM
 - Access blocks of data
 - Commands include open(), read(), write(),
 seek()
 - Raw I/O or file-system access
 - Memory-mapped file access possible
- Character Devices: e.g. keyboards, mice, serial ports, some USB devices
 - Single characters at a time
 - Commands include get(), put()
 - Libraries layered on top allow line editing
- Network Devices: e.g. Ethernet, Wireless, Bluetooth
 - Different enough from block/character to have own interface
 - Unix and Windows include socket interface
 - Separates network protocol from network operation
 - Includes select() functionality
 - Usage: pipes, FIFOs, streams, queues, mailboxes

How Does User Deal with Timing?


- Blocking Interface: "Wait"
 - When request data (e.g. read () system call), put process to sleep until data is ready
 - When write data (e.g. write() system call), put process to sleep until device is ready for data
- Non-blocking Interface: "Don't Wait"
 - Returns quickly from read or write request with count of bytes successfully transferred
 - Read may return nothing, write may write nothing
- Asynchronous Interface: "Tell Me Later"
 - When request data, take pointer to user's buffer, return immediately; later kernel fills buffer and notifies user
 - When send data, take pointer to user's buffer, return immediately; later kernel takes data and notifies user

Main components of Intel Chipset: Pentium 4

- Northbridge:
 - Handles memory
 - Graphics
- Southbridge: I/Q
 - PCI bus
 - Disk controllers
 - USB controllers
 - Audio
 - Serial I/O
 - Interrupt controller
 - Timers



How does the processor actually talk to the device?



- Regardless of the complexity of the connections and buses, processor accesses registers in two ways:
 - I/O instructions: in/out instructions
 - Example from the Intel architecture: out 0x21, AL
 - Memory mapped I/O: load/store instructions
 - Registers/memory appear in physical address space
 - I/O accomplished with load and store instructions

Example: Memory-Mapped Display Controller

- Memory-Mapped:
 - Hardware maps control registers and display memory into physical address space
 - Addresses set by hardware jumpers or programming at boot time
 - Simply writing to display memory (also called the "frame buffer") changes image on screen
 - Addr: 0x8000F000—0x8000FFFF
 - Writing graphics description to commandqueue area
 - Say enter a set of triangles that describe some scene
 - Addr: 0x80010000—0x8001FFFF
 - Writing to the command register may cause onboard graphics hardware to do something
 - Say render the above scene
 - Addr: 0x0007F004
- Can protect with page tables

0x80020000

0x80010000

0x8000F000

0x0007F004

0x0007F000

Graphics Command Queue

Display Memory

Command Status

Physical Address Space

Transfering Data To/From Controller


Programmed I/O:

- Each byte transferred via processor in/out or load/store
- Pro: Simple hardware, easy to program
- Con: Consumes processor cycles proportional to data size


Direct Memory Access:

- Give controller access to memory bus
- Ask it to transfer data to/from memory directly

Sample interaction with DMA controller



What do disks look like?



Some modern disks drives

	Barracuda	a 180 Cheetah X15-26LP
Capacity	181 <i>G</i> B	36.7GB
Platter/Heads	12/24	4/8
Cylinders	24,247	18,479
Sectors/track	~609	~485
Speed	7200RPM	15000RPM
Latency (ms)	4.17	2.0
Avg seek (ms)	7.4/8.2	3.6/4.2
Track-2-track(m	s) 0.8/1.1	0.3/0.4

Disk vs. Memory

- Smallest write: sector
- Atomic write = sector
- Random access: 5ms
 - not improving
- Sequential access: 200MB/s
- Cost \$.002MB
- Crash: doesn't matter ("non-volatile")

- (usually) bytes
- byte, word
- 50 ns
 - getting faster all the time
- 200-1000MB/s
- \$.15MB
- contents gone ("volatile")

Some useful facts

- Disk reads/writes in terms of sectors, not bytes
 - read/write single sector or adjacent groups

- How to write a single byte? "Read-modify-write"
 - read in sector containing the byte
 - modify that byte
 - write entire sector back to disk
 - key: if cached, don't need to read in
- Sector = unit of atomicity.
 - sector write done completely, even if crash in middle
 - (disk saves up enough momentum to complete)
 - larger atomic units have to be synthesized by OS

Some useful costs

- Seek: move disk arm to the right track
 - best case: 0ms (on track already)
 - worst: ~30-50ms (move over entire disk)
 - average: 10-20ms, 1/3 worst case
- Rotational delay: wait for sec to rotate under head
 - best: 0ms (over sector)
 - worst: ~16ms (entire rotation)
 - average: ~8ms (1/2 worst case)
- Transfer bandwidth: suck bits off of device
- Cost of disk access? Seek + rotation + transfer time
 - read a single sector: 10ms + 8ms + 50us ~= 18ms
 - Cool: read an entire track? Seek + transfer! (why?)

Some useful trends

- Disk bandwidth and cost/bit improving exponentially
 - similar to CPU speed, memory size, etc.
- Seek time and rotational delay improving *very* slowly
 - why? require moving physical object (disk arm)
- Some implications:
 - disk accesses a huge system bottleneck & getting worse
 - bandwidth increase lets system (pre-)fetch large chunks for about the same cost as small chunk.
 - Result? trade bandwidth for latency if you can get lots of related stuff.
 - How to get related stuff? Cluster together on disk
 - Memory size increasing faster than typical workload size
 - More and more of workload fits in file cache
 - disk traffic changes: mostly writes and new data