



DEPARTMENT OF PHYSICS AND NANOTECHNOLOGY SRM INSTITUTE OF SCIENCE AND TECHNOLOGY

18PYB103J – Semiconduuctor Physics

Concepts of Optical Recombination and emission process Dr. V. Ganesh





- ☐ When a semiconductor is illuminated with light an electron in the valence band making an upward transition to conduction band.
- ☐ This results electron-hole pair generated, the reverse process of electron-hole annihilation is called recombination.
- ☐ Recombination process may be radiative or non- radiative
 - 1. If electron annihilated with hole energy is relased equal to $E \ge Eg$ called radiative recombination, in this process a photon of energy E = hv is released
- 2. If electron annihilated with hole energy is relased equal to E < Eg called non radiative recombination, in this process phonons are released





Recombination electron – hole pairs observed in different optical process

- ☐ Luminescence: Process where electron hole pairs created and recombined radiatively
- Photoluminescence: electron- hole pairs are generated due to absorption of light and recombination occurs raidiatively
- Cathodluminescence: electron hole pairs are generated by the electron bombardment, and radiative recombination occurs
- ☐ Electroluminescence: process of radiative recombination following injection with pn-junction or similar device.





When a semiconductor is under equilibrium without any incident photon (or) injection of electron the carrier density can be calculated from an equilibrium Fermi level using Fermi Dirac statistics

$$f(E) = \frac{1}{1 + e^{(E - E_F)/kT}}$$

But when light is illuminated non equilibrium carrier concentration is created and above relation is not valid, hence Fermi Dirac distribution for electrons and holes in non equilibrium condition are

$$f(E)_{n} \stackrel{\underline{n}}{=} exp\left(\frac{E_{F_{n}}-E_{e}}{kT}\right)$$
 for electrons $f(E)_{p} \stackrel{\underline{n}}{=} exp\left(\frac{E_{V}-E_{F_{p}}}{kT}\right)$ for holes

Further carrier concentration is calculated as

$$P = N_c \exp \left[\frac{E_{Fn} - E_c}{kT}\right]$$
 for electron $P = N_v \exp \left[\frac{E_V - E_{FP}}{kT}\right]$ for holes





The excess carriers generated in semiconductor at non equilibrium condition must eventually recombine

Generation rate (G) = recombination rate (R)

The generation recombination process involves transition of charge carriers across the energy bandgap and is different for direct & indirect bandgap semiconductor materials.

The probability of radiative recombination is very high and direct bandgap semiconductor due to momentum & energy conservation

Recombintaion rate of charge carriers is depends upon the lifetime charge carriers



In general both radiative and noradiative recombinations are considered, the total life time is given as

$$\frac{1}{T} = \frac{1}{T_r} + \frac{1}{T_{ny}}$$
 where $R = \frac{\Delta n}{T}$





Trin radiative lifetime & Thrin hon-radiative life time of charge carriers. Also total Recombination rate in given by

[R= Rr+Rnr]

Internal quantum efficiency due to recombination Process is

If Tr/Thr is small in which The is large as possible, It increases teads to high radiative recombination in SemiConductor






Emission process:

Generally the emission process are takes place in two types in optical devices

- 1. Spontaneous emission
- 2. Stimulated emission

Spontaneous emission: spontaneous emission, this process requires a conduction band energy state occupied by an electron and an empty valence band energy state. The electron Itself transit from conduction band to valence band spontaneously by releasing a photon.



This photon has a random direction and phase.

This is the opposite of the common situation in equilibrium, but at a finite temperature there will be a small number of full states in the conduction band and empty states in the valence band. Also, electrons and holes can be created via optical absorption and other pumping mechanisms.





Let us consider two energy levels in semiconductor E_1 & E_2 where E_1 corresponds to ground state

E₂ corresponds to exited state

At room temperature most of the electrons are in ground state
When photons of energy grater or equal to bandgap incident on
Semiconductor electron hole pairs are generated, this process is
Called absorption

$$N_{ab} \propto QN_1 \Rightarrow N_{ab} = B_{12} Q N_1$$


 $N_{ab} \square$ number of atoms undergoing absorption process/Vt

 $N_1 \square$ number of atoms in E_1 / V

Q □ energy density of incident radiation

 $B_{12} \square$ proportionality constant









Spontaneous emission:

When electron hole pairs are generated due to the absorption of incident radiation.

After a short time without any external stimulus the electron come back from

Unstable exited to state (E₂) to ground state (E₁) by emitting a photon of energy

$$hv \ge E_2 - E_1$$


This process is called spontaneous emission

Then
$$N_{sp} \propto N_2 \Rightarrow N_{sp} = A_{21} N_2$$

 $N_{sp} \ \square$ is the number of atoms undergoing spontaneous emission process/vt

 $N_2 \square$ number of atoms in E_2 / V

 $A_{21} \square$ proportionality constant








Stimulated emission:

An incident photon causes an upper level atom to decay, emitting a "stimulated" photon whose properties are identical to those of the incident photon.

The term "stimulated" underlines the fact that this kind of radiation only occurs if an incident photon is present





SRM

Stimulated emission:

If a photon of energy (hv) impinges on the electron which is presented in Exited state (E_2).

The electron stimulated back to the ground state by releasing the energy $hv \ge E_2-E_1$ which is phase with the incident radiation this process is called stimulated emission.


$$N_{st} = B_{21} Q N_2$$

 $N_{st} \square$ number of atoms undergoing stimulated process/Vt

 $N_2 \square$ number of atoms in E_2 / V

 $Q \square$ energy density of incident radiation

 $B_{21} \square$ proportionality constant





Ratio between Sportancous and etime lated Coefficient



Then
$$Q = \frac{A_{21}}{\left[\frac{N_1}{N_2}\right]B_{12} - B_{21}} \longrightarrow (1)$$

From Boltzmann distribution law, at a given temperature (T), the ratio of population of two levels is given by $\frac{N_1}{N_2} = e^{(E_2-E_1)/kT} = e^{h\tilde{\nu}/kT} \Rightarrow Q = e^{h\tilde{\nu}/kT}_{B_12} - B_{21}$

on of two levels 15 gran
$$Q = \frac{A_{21}}{N_2} = e^{\frac{A_{21}}{N_2} - \frac{A_{21}}{R_{22}} + \frac{A_{21}}{R_{22}}} + \frac{A_{21}}{R_{22}} + \frac{A_{21}}{R_{22}}$$

Also, from planks body radiation theory

$$Q = \frac{8\pi hc}{\lambda^5} \times \left[\frac{1}{e^{hP/kT}}\right] \rightarrow (3)$$

In equation (2) if B21 = B12 then Q = A21 × [eht/kt_1] >A

Here ARB are Einsteins Coefficients which gives value for tation of spontaineous and extinulated emission.