

GP0: PASS
GP1: PASS for static profile
GP2: NOT ENABLED
GP3: NOT MEASURED
GP4: NOT MEASURED