
L-LAS Series

L-LAS-LT-180-SL-...

- **Type -P:** Line laser, **Laser class 1** (<0.4 mW, wavelength 670 nm), visible red laser spot, typ. Ø 0.3 mm
- Type -L: Line laser, Laser class 2 (<1 mW, wavelength 670 nm), visible red laser line, typ. 0.3 mm x 3 mm
- Reference distance 180 mm
- Measuring range typ. 240 mm
- Start of measuring range at typ. 60 mm
- Resolution typ. 60 µm
- Interference filter and red light filter integrated
- CMOS line detector with 512 pixel, 4096 subpixel
- RS232 interface (USB or Ethernet adaptor available)
- Windows® user interface
- 2 digital inputs, 2 digital outputs
- 2 analog outputs (voltage 0...+10V and current 4...20mA)
- Scan frequency max. 2 kHz (3.3 kHz)
- Switching state indication via 2 three-color LEDs (red/grn/blu)
- Optics cover made of scratch-resistant glass





Instruments





Technical Data


Model	L-LAS-LT-180-SL-P	L-LAS-LT-180-SL-L
Light source	Semiconductor laser, 670 nm, DC-operation, 0.4 mW max. opt. power, laser class 1 acc. to DIN EN 60825-1. The use of these laser sensors therefore requires no additional protective measures.	Semiconductor laser, 670 nm, DC-operation, 1 mW max. opt. power, laser class 2 acc. to DIN EN 60825-1. The use of these laser sensors therefore requires no additional protective measures.
Reference distance	180 mm	
Measuring range	typ. 240 mm	
Start of measuring range	typ. 60 mm (measured from housing edge, cf. picture beam path)	
End of measuring range	typ. 300 mm (measured from housing edge, cf. picture beam path)	
Resolution	typ. 60 μm	
Reproducibility	typ. ± 60 μm	
Linearity	<= 0.25% of full scale output (FSO)	
Laser line geometry	typ. Ø 0.3 mm	typ. 0.3 mm x 3 mm
Optical filter	Interference filter, red light filter RG630	
Analog output (ANA)	1x current output: I-OUT (4 20mA) 1x voltage output: ANA (0 +10V)	
Digital outputs (OUT0, OUT1)	OUT0: (-) Measuring value < lower tolerance threshold OUT1: (+) Measuring value > upper tolerance threshold pnp bright-switching/npn dark-switching or pnp dark-switching/npn bright-switching, adjustable under Windows®, 100 mA, short-circuit proof	
Digital inputs (IN0, IN1)	IN0: External trigger, IN1: Teach/Reset (double function), input voltage +Ub/0V, with protective circuit	
Voltage supply	+24VDC (± 10%)	
Sensitivity setting	adjustable under Windows® via PC	
Laser power correction	adjustable under Windows® via PC	
Current consumption	typ. 200 mA	
Enclosure rating	Electronics: IP54, optics: IP67	
Temperature stability	0.01% of measuring range/°C	
Temperature ranges	operating temperature range: -10°C +50°C storage temperature range: -20°C +85°C	
Housing material	Aluminum, anodized in black	
Housing dimensions	LxWxH approx. 65 mm x 55 mm x 20.6 mm (without connectors)	
Type of connector	8-pole circular connector type Binder 713/763 (PLC/Power) 4-pole circular fem. connector type Binder 707 (PC/RS232)	
Connecting cable	to PLC: cab-M12/8-gshd to PC/RS232 interface: cab-las4/PC or cab-las4/PC-w to PC/USB interface: cab-4/USB or cab-4/USB-w to PC/Ethernet interface: cab-4/ETH	
LED indication (4x two-color LED)	1x three-color LED red/green/blue for tolerance band monitoring: red = Measuring value out of tolerance window green (ok) = Measuring value within tolerance window white = Measuring value out of measuring range 1x three-color LED red/green/blue (Power indication): green = Power	
Teach/reset button	for norm value teaching or for re-	set of maximum values via input IN1
EMC test acc. to	DIN EN 60947-5-2 (€	
Measuring frequency	max. 2 kHz (3.3 kHz)	
Max. switching current	100 mA, short-circuit proof	
Interface	RS232, parameterisable under Windows®	
Output polarity	Bright-/dark-switching, can	be switched under Windows®







Dimensions


L-LAS-LT-180-SL-P L-LAS-LT-180-SL-L






180








All dimensions in mm





Beam Path

L-LAS-LT-180-SL-P L-LAS-LT-180-SL-L







Connector Assignment


Connection to PLC:

8-pole M12 connector Binder Series 713/763

Pin: Color: Assignment: white OUT1 +24VDC (± 10%) 2 brown 3 I-OUT (4...20mA) green IN1 (TEACH/RESET) 4 yellow 5 OUT0 grey ANA (0...+10V) 6 pink blue GND (0V) 8 IN0 (EXT TRIGGER) red

Connecting cable: cab-M12/8-g-(length)-shd (shielded)

(standard length 2m)



cab-M12/8-g-...-shd (max. length 5m, outer jacket: PUR)

Connection to PC:

4-pole fem. connector Binder Series 707

Pin: Assignment:

+24VDC (+Ub, OUT)

GND (0V) 2 3 RxD

Connection via RS232 interface at the PC:

Connecting cable: cab-las4/PC-(length) cab-las4/PC-w-(length) (angle type 90°) (standard length 2m)

alternative:

Connection via USB interface at the PC:


Connecting cable (incl. driver software): cab-4/USB-(length) cab-4/USB-w-(length) (angle type 90°) (standard length 2m)

alternative:


Connection to local network via Ethernet bus:

Adapter (incl. software "SensorFinder"): cab-4/ETH-500 (standard length 0.5m)





(length 0.5m, outer jacket: PUR) 4-pole M12 fem. conn. (D-coded) for connection of an external CAT5 cable, e.g. cab-eth/M12D-RJ45-flx-(length)



cab-las4/PC-... (max. length 10m, outer jacket: PUR) or cab-las4/PC-w-... (no picture) (max. length 5m, outer jacket: PUR)




cab-4/USB-... or cab-4/USB-w-... (no picture) (each max. length 5m, outer jacket: PUR)






Angled Connector

Angled connector rotatable by 180°:





LED Display





Laser Warning

The laser line sensors of L-LAS-LT Series comply with laser class 2 according to EN 60825-1. The use of these laser transmitters therefore requires no additional protective measures.

The laser line sensors of L-LAS-LT Series are supplied with a laser warning label.



LASER RADIATION

DO NOT STARE INTO THE BEAM

CLASS II LASER PRODUCT








Parameterization

Windows® user interface:

(The current software version is available for download on our website.)

The L-LAS-LT-SL sensor can be easily parameterised with the Windows® user interface L-LAS-LT-Scope (as of V5.1). For this purpose the sensor is connected to the PC with the serial interface cable cab-las4/PC (or with USB cable cab-/USB or with Ethernet adaptor cab-4/ETH). When parameterisation is finished, the PC can be disconnected again.



With the help of the L-LAS-LT-Scope software the following settings can be made at the sensor:

- Setting of laser power and type of automatic power correction
- Polarity of digital outputs
- Different evaluation modes
- Start of the teach process by software button
- Setting of tolerance ranges for monitoring the measured value

Furthermore, various numerical and graphical measured quantities can be visualized with the L-LAS-LT-Scope software. For example, the raw data of the CCD line sensor can be displayed graphically and numerically.

