


## LAM 5.x advanced bracket


Angle adjustable mounting bracket Equerre de montage réglable Winkelverstellbare Montagehalterung Soporte de montaje ajustable en ángulo




## Dimensions / Encombrements / Abmessungen / Dimensiones













+/- 90°




1

(0)

## Setting / Réglage / Einstellung / Ajuste





- Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Sensor Partners for any consequences arising out of the use of this material. en
- fr Les équipements électriques doivent être installés, exploités et entretenus par un personnel qualifié. Sensor Partners décline toute responsabilité quant aux conséquences de l'utilisation de cet appareil
- Elektrische Geräte dürfen nur von Fachpersonal installiert, betrieben, gewartet und instand gesetzt werden. de Sensor Partners haftet nicht für Schäden, die aufgrund der Verwendung dieses Materials entstehen.
- Sólo el personal de servicio cualificado podrá instalar, utilizar, reparar y mantener el equipo eléctrico. Sensor Partners no asume las responsabilidades que pudieran surgir como consecuencia de la utilización de este material