
# **L-LAS** Series

# L-LAS-LT-50-CL

- Line laser <0.4 mW, wave length 670 nm, laser class 1
- Visible red laser line, typ. 0.3 mm x 3 mm
- Reference distance 50 mm
- Measuring range typ. 38 mm
- Start of measuring range at typ. 36 mm
- Resolution typ. 10 μm
- Interference filter and red light filter integrated
- CCD line detector with 512 pixel, 2048 subpixel
- RS232 interface (USB or Ethernet converter available)
- Windows® user interface
- 2 digital inputs, 2 digital outputs
- 1 analog output (0...+10V, optionally additional output 4...20mA)
- Scan frequency max. 500 Hz
- Switching state indication via 4 LEDs (2x red/grn, 2x yel/grn)
- Optics cover made of scratch-resistant glass





Instruments





# **Technical Data**


Model	L-LAS-LT-50-CL	L-LAS-LT-50-CL-4/20
Light source	Solid state laser, 670 nm, AC operation, <0.4 mW opt. power, laser class 1 acc. to DIN EN 60825-1.  The use of these laser transmitters therefore requires no additional protective measures.	
Reference distance	50 mm	
Measuring range	typ. 38 mm	
Start of measuring range	typ. 36 mm (measured from housing edge, cf. picture beam path)	
End of measuring range	typ. 74 mm (measured from housing edge, cf. picture beam path)	
Resolution	typ. 10 μm	
Reproducibility	typ. ± 10 µm	
Linearity	<= 0.25% of full scale output (FSO)	
Laser line geometry	typ. 0.3 mm x 3 mm	
Optical filter	Interference filter, red light filter RG630	
Analog output (ANA)	1x voltage output (0 +10V)	1x voltage output (0 +10V) 1x current output (4 20mA)
Digital outputs (OUT0, OUT1)	OUT0: (-) Measuring value < lower tolerance threshold OUT1: (+) Measuring value > upper tolerance threshold pnp bright-switching/npn dark-switching or pnp dark-switching/npn bright-switching, adjustable under Windows®, 100 mA, short-circuit proof	
Digital inputs (IN0, IN1)	IN0: External trigger, IN1: Teach/Reset (double function) Input voltage +Ub/0V, with protective circuit	
Voltage supply	+24VDC (± 10%)	
Sensitivity setting	adjustable under Windows® via PC	
Laser power correction	adjustable under Windows® via PC	
Current consumption	typ. 200 mA	
Enclosure rating	Electronics: IP54, optics: IP67	
Temperature stability	0.01% of measuring range/°C	
Temperature ranges	Operating temperature range: -10°C +50°C Storage temperature range: -20°C +85°C	
Housing material	Aluminum, anodized in black	
Housing dimensions	LxWxH approx. 82.85 mm x 60 mm x 20 mm (without flange connectors)	
Type of connector	8-pole circular fem. connector type Binder 712 (PLC/Power) 4-pole circular fem. connector type Binder 707 (PC/RS232)	
Connecting cable	to PLC: cab-las8/SPS or cab-las8/SPS-w to PC/RS232 interface: cab-las4/PC or cab-las4/PC-w to PC/USB interface: cab-4/USB or cab-4/USB-w to PC/Ethernet interface: cab-4/ETH	
LED indication (4x two-color LED)	2x two-color-LED red/green and 1x two-color-LED yellow/green for tolerance band monitoring: red (+) = Measuring value > upper tolerance threshold red (-) = Measuring value < lower tolerance threshold green (ok) = Measuring value within tolerance window 1x two-color LED yellow/green (multifunctional): yellow = Power indication	
EMC test acc. to	DIN EN 60947-5-2 ( <b>€</b>	
Measuring frequency	max. 500 Hz	
Max. switching current	100 mA, short-circuit proof	
Interface	RS232, parameterisable under Windows®	
Output polarity	Bright-/dark-switching, can be switched under Windows®	








# **Dimensions**

L-LAS-LT-50-CL L-LAS-LT-50-CL-4/20










All dimensions in mm





**Beam Path** 

L-LAS-LT-50-CL L-LAS-LT-50-CL-4/20





# **Connector Assignment**


#### **Connection to PLC:**

## 8-pole fem. connector Binder Series 712

Color: Assignment: white GND (0V) 2 +24VDC (± 10%) brown 3 green IN0 (EXT TRIGGER) IN1 (TEACH/RESÉT) 4 vellow 5 grey OUT0 (-) 6 pink OUT1 (+) GND (0V) or blue in case of -4/20: ANA (current 4 ... 20mA)

8 ANA (voltage 0 ... +10V) red

Connecting cable: cab-las8/SPS-(length) or cab-las8/SPS-w-(length) (angle type 90°) (standard length 2m)



cab-las8/SPS-... (max. length 25m, outer jacket: PUR)

cab-las8/SPS-w-... (max. length 25m, outer jacket: PUR)

## **Connection to PC:**

## 4-pole fem. connector Binder Series 707

Pin: Assignment:

+24VDC (+Ub, OUT)

2 GND (0V)

3 RxD

TxD 4

#### Connection via RS232 interface at the PC:

Connecting cable: cab-las4/PC-(length) cab-las4/PC-w-(length) (angle type 90°) (standard length 2m)

## alternative:

### Connection via USB interface at the PC:

USB converter (incl. driver software): cab-4/USB-(length) cab-4/USB-w-(length) (angle type 90°) (standard length 2m)



Connection to local network via Ethernet bus:

Ethernet converter (incl. software "SensorFinder"): cab-4/ETH-500


(standard length 0.5m)

## Optional:

External CAT5 cable, e.g. cab-eth/M12D-RJ45-flx-(length)

0

cab-4/ETH-500 (length 0.5m, outer jacket: PUR) 4-pole M12 fem. conn. (D-coded) for connection of an external CAT5 cable, e.g. cab-eth/M12D-RJ45-flx-(length)



cab-las4/PC-... (max. length 10m, outer jacket: PUR) or cab-las4/PC-w-... (no picture) (max. length 5m, outer jacket: PUR)


cab-4/USB-... or cab-4/USB-w-... (no picture) (each max. length 5m, outer jacket: PUR)





# **LED Display**

#### LED display:





# Laser Information

The laser transmitters of the line sensors L-LAS-LT-50-CL and L-LAS-LT-50-CL-4/20 comply with laser class 1 according to EN 60825-1.

Under reasonably foreseeable conditions a class 1 laser is safe.

The reasonably foreseeable conditions are kept during specified normal operation. The use of these laser transmitters therefore requires no additional protective measures.

The Iline sensors L-LAS-LT-50-CL and L-LAS-LT-50-CL-4/20 are supplied with an information label "CLASS 1 Laser Product".

CLASS 1 Laser Product IEC 60825-1: 2008-05 THIS LASER PRODUCT COMPLIES WITH 21 CFR 1040 AS APPLICABLE








## **Parameterization**

#### Windows® software L-LAS-LT-Scope V4.x:

(The current software version is available for download on our website.)

The L-LAS-LT sensor can easily be parameterised with the Windows® user interface. For this purpose the sensor is connected to the PC with the serial interface cable cab-las4/PC respectively by means of USB converter cab-4/USB or Ethernet converter cab-4/ETH. When parameterisation is finished, the PC can be disconnected again.

#### Windows® user interface:



With the help of the L-LAS-LT-Scope software the following settings can be made at the sensor:

- Setting of laser power and type of automatic power correction
- Polarity of digital outputs
- Different evaluation modes
- Start of the teach process by software button
- Setting of tolerance ranges for monitoring the measured value

Furthermore, various numerical and graphical measured quantities can be visualized with the L-LAS-LT-Scope software. For example, the raw data of the CCD line sensor can be displayed graphically and numerically.

