# Week 9

ESE3025

### FreeRTOS Overview

- library components:
  - FreeRTOSConfig.h
    - a file containing macro definitions (#define) for many of the RTOS critical parameters, including: tick rate, preemption mode, etc.
  - FreeRTOS.h
    - must be included with any application that uses FreeRTOS, i.e., you must have #include<FreeRTOS.h>
  - API-specific header files:
    - task.h
    - queue.h
    - timers.h
    - list.h
    - projdefs.h
    - semphr.h

## FreeRTOS Overview (2)

- API source files:
  - tasks.c
  - o queue.c
  - list.c
  - o port.c
- see the FreeRTOS Reference Manual provided here (to see a breakdown of API functions by API Group, e.g., Task and Scheduler API, Software Timer API, Semaphore API, etc.):
  - https://github.com/takiszourntos/teaching/blob/master/documentation/FreeRTOS\_Reference\_
     Manual\_V10.0.0.pdf

```
<u>F</u>ile <u>E</u>dit <u>S</u>ource Refac<u>t</u>or <u>N</u>avigate Se<u>a</u>rch <u>P</u>roject ConfigTools <u>R</u>un Analysis FreeRTOS <u>W</u>indow <u>H</u>elp
E
                                                           Quick Access
                                                        Project Explorer 🛭 🚼 Peripherals+ 👭 Registers 🎋 Faults
▶ ➡ Project References
                                                                          Project Settings
    ▶ ⋒ Includes
    ▼  2 example
      ▼ @inc
       FreeRTOSConfig.h
      ▶ ⊜ STC
       readme.txt
    ▼ <sup>™</sup> freertos
      ▼ ⊜inc
                                                                          (x)=
       n croutine.h
       FreeRTOS.h
       ▶ list.h
       mpu_wrappers.h
       portable.h
       portmacro.h
       ▶ 🔓 projdefs.h
       la queue.h
       semphr.h
       ▶ In StackMacros.h
       lask.h
       b in timers.h
      ▼ @ STC
       ▶ ☐ FreeRTOSCommonHooks.c
       ▶ In FreeRTOSCommonHooks.h
       heap 3.c
       list.c
       port.c
       p queue.c
       tasks.c
   ▶ 🎏 lpc_chip_175x_6x
   ▼ periph pinint
    ▶ ➡ Project References
    ▶ ♠ Project Settings
    ▶ ⋒ Includes
    ▼  example
Freertos_blinky
```

U NXP LPC1769 (freertos blinky)

mcu\_temp - freertos\_blinky/freertos/src/tasks.c - MCUXpresso IDE

### FreeRTOS Conventions

see Appendix 1 in the FreeRTOS Reference Manual

#### APPENDIX 1: Data Types and Coding Style Guide

#### **Data Types**

Each port of FreeRTOS has a unique portmacro.h header file that contains (amongst other things) definitions for two special data types, TickType\_t and BaseType\_t. These data types are described in Table 3.

Table 3. Special data types used by FreeRTOS

Table 3. Special data types used by FreeRTOS				
Macro or typedef used	Actual type			
TickType_t	This is used to store the tick count value, and by variables that specify block times.			
	TickType_t can be either an unsigned 16-bit type or an unsigned 32-bit type, depending on the setting of configUSE_16_BIT_TICKS within FreeRTOSConfig.h.			
	Using a 16-bit type can greatly improve efficiency on 8-bit and 16-bit architectures, but severely limits the maximum block period that can be specified. There is no reason to use a 16-bit type on a 32-bit architecture.			
BaseType_t	This is always defined to be the most efficient data type for the architecture. Typically, this is a 32-bit type on a 32-bit architecture, a 16-bit type on a 16-bit architecture, and an 8-bit type on an 8-bit architecture.			
	BaseType_t is generally used for variables that can take only a very limited range of values, and for Booleans.			
	es other than 'char' are not used (see below), instead type names defined			

Standard data types other than char are not used (see below), instead type names defined within the compiler's stdint.h header file are used. 'char' types are only permitted to point to ASCII strings or reference single ASCII characters.

#### Variable Names

Variables are prefixed with their type: 'c' for char, 's' for short, 'l' for long, and 'x' for BaseType\_t and any other types (structures, task handles, queue handles, etc.).

If a variable is unsigned, it is also prefixed with a 'u'. If a variable is a pointer, it is also prefixed with a 'p'. Therefore, a variable of type unsigned char will be prefixed with 'uc', and a variable of type pointer to char will be prefixed with 'pc'.

#### **Function Names**

Functions are prefixed with both the type they return and the file they are defined in. For example:

xQueueReceive() returns a variable of type <u>BaseType t</u> and is defined within queue.c.

- vTaskPrioritySet() returns a void and is defined within task.c.
- vSemaphoreCreateBinary() returns a void and is defined within semphr.h.

920 St. 900407 SSSS SSS

#### Formatting

One tab is always set to equal four spaces.

File scope (private) functions are prefixed with 'prv'.

#### **Macro Names**

Most macros are written in upper case and prefixed with lower case letters that indicate where the macro is defined. Table 4 provides a list of prefixes.

#### Prefix port (for example, portMAX\_DELAY)

Table 4. Macro prefixes

err (for example, errQUEUE\_FULL)

task (for example, taskENTER CRITICAL())

config (for example, configUSE\_PREEMPTION)

pd (for example, pdTRUE)

pdTRUE

pdFALSE

Table 5. Common macro definitions

Rationale for Excessive Type Casting

pdPASS

pdFAIL

function naming convention, rather than the macro naming convention.

Macro

0

Value

0

The macros defined in Table 5 are used throughout the FreeRTOS source code.

Location of macro definition

portable.h

projdefs.h

projdefs.h

task.h

Note that the semaphore API is written almost entirely as a set of macros, but follows the

FreeRTOSConfig.h

The FreeRTOS source code can be compiled with many different compilers, all of which differ

in how and when they generate warnings. In particular, different compilers want casting to be

used in different ways. As a result, the FreeRTOS source code contains more type casting

than would normally be warranted.

### a note on: vTaskDelay()

- vTaskDelay() creates a delay with a specific number of TICKS
- but it also does something else important: while it is active, it places the task running it into BLOCKED state, allowing other tasks to run in that time
- if you want a delay without putting your task into the BLOCKED state, you can try a couple of things:
  - use a for(;;) loop
  - use taskENTER\_Critical() and taskEXIT\_Critical() --- suspends preemption

# vTaskDelayUntil() versus vTaskDelay()

