
## FENDER VIBROLUX SCHEMATIC

## NOTICE

VOLTAGES READ TO GROUND WITH V.T.V.M. VALUES SHOWN + OR - 20 %



## FENDER "VIBROLUX" LAYOUT

NOTICE

VOLTAGES READ TO GROUND WITH ELECTRONIC VOLTMETER, VALUES SHOWN + OR - 20 %

