
## FENDER "VIBRASONIC" SCHEMATIC

## NOTIC

1 - VOLTAGES READ TO GROUND WITH ELECTRONIC YOLTMETER. VALUES SHOWN + OR -

2 - ALL RESISTORS 1/2 WATT IF NOT SPECIFIED



## FENDER "VIBRASONIC" LAYOUT MODEL 56/3

NOTICE VOLTAGES READ TO GROUND WITH ELECTRONIC VOLTMETER, VALUES SHOWN + OR - 20%

