
FENDER BASSMAN SCHEMATIC

NOTE

- YOLTAGES READ TO GROWNS WITH ELECTRONIC


YOLTMETER. VALUES SHOWN + OR - 20%

2- ALL RESISTERS "ZWATT, 10% TOLERANCE IF NOT SPECIFIES.



%

FENDER "BASSMAN" LAYOUT MODEL 666-B



NOTE - ALL RESISTORS YZW-10% TOLERANCE IF NOT SPECIFIED.

NOTE- ALL CAPACITORS AT LEAST ADD VOLT RATING IF NOT SPECIFIED.