

RPLIDAR Quick Start



FIGURE 2. Using RPLIDAR

QUICK START STEPS:

STEP 1

DOWNLOAD THE RPLIDAR SDK FROM ROBOPEAK WEBSITE: http://go.slamtec.com/rplidar/download

■ STEP 2

CONNECT YOUR PC AND LIDAR SENSOR WITH PROVIDED CABLES. (SEE FIGURE1)

■ · STEP 3

PUT RPLIDAR IN A SPACE AND RUN RPLIDAR DEMO. (SEE FIGURE 2)



RUNNING FRAME_GRABBER DEMO AND CLICK SCAN BUTTON START SCAN



THANK YOU FOR PURCHASING THE AMAZING LASER SCANNER DEVELOPMENT KIT FROM SLAMTEC,

MORE INFORMATION PLEASE REFER TO THE DOCUMENT PROVIDED BY SLAMTEC: http://go.slamtec.com/rplidar




FIGURE 1. Connect RPLIDAR to PC