

PT-P950NW

? FAQs & Troubleshooting

Date: 10/17/2025 ID: faqp00100084_000

Using Web Based Management

Overview

You can use a standard web browser to change your printer's settings using the Hyper Text Transfer Protocol (HTTP) or Hyper Text Transfer Protocol over Secure Socket Layer (HTTPS). When using Web Based Management, the following actions are possible:

- Display printer status information
- Change network settings such as TCP/IP information
- Display software version information of the printer and print server
- Change network and printer configuration details

- We recommend Microsoft Edge for Windows, Safari 10/11 or later for Mac, Google Chrome™ for Android (4.x or later), and Google Chrome™/Safari for iOS (10.x or later).
- Please make sure that JavaScript and cookies are always enabled in whichever browser you use.
- In order to use Web Based Management, your network must use TCP/IP, and the printer and computer must have a valid IP address.

Configuring the Printer Settings Using Web Based Management (Web Browser)

A standard web browser can be used to change your print server settings using the HTTP (Hyper Text Transfer Protocol).

1. Type "http://printer_ip_address/" into your browser. (Where "printer_ip_address" is the IP address or the print server name.)
For example (if the printer's IP address is 192.168.1.2.):
http://192.168.1.2/

If you edited the Hosts file on your computer or are using a Domain Name System, you can also enter the print server's DNS name. The print server supports TCP/IP and NetBIOS, so you can also enter the print server's NetBIOS name. To find the NetBIOS name, click the **Network** tab and then select **Network Status**. The NetBIOS name assigned is the first 15 characters of the node name and appears as "BRW[ethernet address]".

2. Change the print server settings.

The default login password to manage printer settings is marked "Pwd" and located either:

- on the back or bottom of the printer
- in the battery cavity
- in the media compartment

For TD-2320D/2350D/2320DF/2350DF/2320DSA/2350DSA users:

If the Battery Base is installed, uninstall it to confirm the default password.

We recommend you change it to protect your printer from unauthorized access.

For more information, see **[IMPORTANT – Network Security Notice: Default Login Password Change]** or **[User's Guide]** on the [\[Manuals\]](#) page.

We recommend setting a login password to prevent unauthorized access to Web Based Management.

1. Click **Administrator**.
2. Type the password you want to use (up to 32 characters).
3. Re-type the password in the **Confirm new password** box.

4. Click **Submit**.

The next time you access Web Based Management, enter a password in the Login box, and then click .

After configuring the settings, logout by clicking .

You can also set a password by clicking **Please configure the password**. on the printer's web page if you have not set a login password.

If your question was not answered, have you checked other FAQs?

[Go to the Top page in the FAQs & Troubleshooting section](#)

[See other FAQs in this category](#)

Have you checked manuals?

[Go to the Manuals section](#)

If you need further assistance, please contact Brother customer service:

[Go to the Contact Us](#)

Related Models

PJ-773, PJ-883, PT-9800PCN, PT-D800W, PT-E550W, PT-E800W, PT-P750W, PT-P900W/ P900Wc, PT-P950NW, QL-1060N, QL-1110NWB/ 1110NWBc, QL-580N, QL-710W, QL-720NW, QL-810W/ 810Wc, QL-820NWB/ 820NWBc, RJ-2050, RJ-2140, RJ-2150, RJ-3050, RJ-3050Ai, RJ-3150, RJ-3150Ai, TD-2120N, TD-2125N, TD-2125NWB, TD-2130N, TD-2135N, TD-2135NWB, TD-2320D, TD-2320DF, TD-2350D, TD-2350DF, TD-2350DSA, TD-4100N, TP-M5000N

Content Feedback

To help us improve our support, please provide your feedback below.

Step 1: How does the information on this page help you?

- ☐ Very helpful
- ☐ Helpful
- ☐ Not helpful

Step 2: Are there any comments you would like to add?

Please note this form is used for feedback only.

[Clear](#)

Submit