Microwave

From GridLAB-D Wiki

TODO: This page needs to be completed.

Microwave - Residential Microwave (explicit model)

Synopsis

```
object microwave {
// residential_enduse properties
shape "type: unknown";
load "power factor: 0.000000; power.r: 0.000000";
energy +0+0\overline{i} kVAh;
power +0+0j kVA;
peak demand +0+0i kVA;
heatgain +0 Btu/h;
cumulative heatgain +0 Btu;
heatgain_fraction +0 pu;
current_fraction +0 pu;
impedance fraction +0 pu;
power_fraction +0 pu;
power factor +0;
constant_power +0+0j kVA;
constant_current +0+0i kVA;
constant admittance +0+0i kVA;
voltage_factor +1 pu;
breaker amps +0 A;
configuration IS110;
override NORMAL;
power_state OFF;
// microwave properties
installed_power +0 kW;
standby_power +0 kW;
circuit split +0;
state OFF;
cycle_length +0 s;
runtime +0 s;
state_time +0 s;
```

See also

- Residential module
 - User's Guide
 - Appliances
 - house class Single-family home model.
 - residential_enduse class Abstract residential end-use class.
 - occupantload Residential occupants (sensible and latent heat).
 - ZIPload Generic constant impedance/current/power end-use load.
- Technical Documents
 - Requirements

1 of 2 9/6/16, 8:17 AM

- Specifications
- Developer notes
- Technical support document
- Validation

Retrieved from "http://gridlab-d.sourceforge.net/wiki/index.php?title=Microwave&oldid=8589"

■ This page was last modified on September 6, 2016, at 08:12.

2 of 2