Introduction to Signals and Systems

Amirhossein Afsharrad

Signals and Systems Tutorial Session 1

March 9, 2020

Overview

- Introduction
- System Properties
- 3 Linear Time-Invariant Systems Introduction
- Properties of LTI Systems


Introduction


Introduction

Signals

Definition

From a mathematical point of view, a **signal** is simply a function.





Systems

Definition

From a mathematical point of view, a system is a function on the space of signals.

If \mathcal{T} is a system, then $\mathcal{T}\{x\} = y$, where x and y are signals.

Each of the two signals x and y can be either discrete or continuous.

Energy of Signals

Definition

The energy of a continuous-time signal x(t) is

$$E_x = \int_{-\infty}^{\infty} |x(t)|^2 dt$$

Definition

The energy of a discrete-time signal x[n] is

$$E_x = \sum_{-\infty}^{\infty} |x[n]|^2$$

Power of Signals

Definition

The power of a continuous-time signal x(t) is

$$P_x = \lim_{T \to \infty} \frac{1}{2T} \int_{-T}^{T} |x(t)|^2 dt$$

Definition

The power of a discrete-time signal x[n] is

$$P_x = \lim_{N \to \infty} \frac{1}{2N+1} \sum_{-N}^{N} |x[n]|^2$$

Power-Type and Energy-Type Signals

Definition

A signal x(t) or x[n] is said to be **energy-type** if

$$E_x < \infty$$

Definition

A signal x(t) or x[n] is said to be **power-type** if

$$0 < P_x < \infty$$

- The power of an energy-type signal is 0.
- The energy of a power-type signal is ∞ .
- A signal can be energy-type, power-type, or neither energy-type nor power-type.

System Properties

Memory

Definition

A system is said to be **memoryless** if its output for each value of the independent variable at a given time is dependent only on the input at that same time.

Invertibility

Definition

A system is said to be **invertible** if distinct inputs lead to distinct outputs.

Causality

Definition

A system is **causal** if the output at any time depends only on values of the input at the present time and in the past.

Definition

A system is said to be **stable** if for every bounded input (i.e., the magnitude of the input does not grow without bound), the output of the system is also bounded.

Time Invariance

Definition

a system is **time invariant** if a time shift in the input signal results in an identical time shift in the output signal.

$$\mathcal{T}\{x[n]\} = y[n] \Rightarrow \mathcal{T}\{x[n-n_0]\} = y[n-n_0]$$

$$\mathcal{T}\{x(t)\} = y(t) \Rightarrow \mathcal{T}\{x(t-t_0)\} = y(t-t_0)$$

Linearity

Definition

A system is said to be **linear** if has the property of superposition, i.e. for every input-output pairs (x_1, y_1) and (x_2, y_2) , the output of the system to the signal $ax_1 + bx_2$ is $ay_1 + by_2$.

Linear Time-Invariant Systems – Introduction

The Impulse Response - Convolution

Definition

The response of a system to the impulse input $(\delta[n] \text{ or } \delta(t))$ is called **the impulse** response of the system.

For a discrete-time system with impulse response h[n], if the input is x[n]:

$$x[n] = \dots + x[-1]\delta[n+1] + x[0]\delta[n] + x[1]\delta[n-1] + x[2]\delta[n-2] + \dots = \sum_{k=-\infty}^{\infty} x[k]\delta[n-k]$$

Because of time invariance, the output to $\delta[n-k]$ is h[n-k]. Taking linearity into consideration, the input-output relationship is:

$$x[n] = \sum_{k=-\infty}^{\infty} x[k]\delta[n-k] \Rightarrow y[n] = \sum_{k=-\infty}^{\infty} x[k]h[n-k]$$

The Impulse Response

$$y[n] = \sum_{k=-\infty}^{\infty} x[k]h[n-k]$$

= $(x*h)[n]$ discrete convolution


For continuous-time systems, the results are similar:

$$y(t) = \int_{-\infty}^{\infty} x(\tau)h(t-\tau)d\tau$$

= $(x*h)(t)$ continuous convolution

Convolution - Graphical Intuition

Check this link for animated procedure of continuous-time convolution.




Properties of LTI Systems

The Commutative Property

$$(x*h)[n] = (h*x)[n] = \sum_{k=-\infty}^{\infty} h[k]x[n-k] = \sum_{k=-\infty}^{\infty} x[k]h[n-k]$$
$$(x*h)(t) = (h*x)(t) = \int_{-\infty}^{\infty} h(\tau)x(t-\tau)d\tau = \int_{-\infty}^{\infty} x(\tau)h(t-\tau)d\tau$$


The Distributive Property

$$x * (h_1 + h_2) = x * h_1 + x * h_2$$



The Associative Property

$$x*(h_1*h_2) = (x*h_1)*h_2$$



Memorylessness

An LTI system is memoryless if and only if h[n] = 0 for $n \neq 0$, so the impulse response has the form

$$h[n] = K\delta[n]$$

or

$$h(t) = K\delta(t)$$

As a result (convolution), a memoryless LTI system has the simple input-output relationship

$$y = Kx$$

Invertibility

An LTI system with impulse response h is invertible if there exists a signal h_i such that

$$h * h_i = \delta$$



Causality

An LTI system with impulse response h[n] or h(t) is causal if and only if

$$h[n] = 0 \quad \text{for } n < 0$$

or

$$h(t) = 0 \quad \text{for } t < 0$$

Remark: While causality is a property of systems, it is common terminology to refer to a signal as being causal if it is zero for n < 0 or t < 0.

Definition

A discrete-time signal h[n] is said to be **absolutely summable** if

$$\sum_{k=-\infty}^{\infty} |h[k]| < \infty$$

Definition

A continuous-time signal h[n] is said to be **absolutely integrable** if

$$\int_{-\infty}^{\infty} |h(\tau)| \mathrm{d}\tau < \infty$$

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

Proof(⇒):

If
$$|x[n]| < B$$
 for all n , and $\sum_{k=-\infty}^{\infty} |h[k]| < \infty$:

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

Proof(⇒):

If |x[n]| < B for all n, and $\sum_{k=-\infty}^{\infty} |h[k]| < \infty$:

$$|y[n]| = \left| \sum_{k=-\infty}^{\infty} h[k]x[n-k] \right|$$

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

Proof(⇒):

If |x[n]| < B for all n, and $\sum_{k=-\infty}^{\infty} |h[k]| < \infty$:

$$|y[n]| = \left| \sum_{k=-\infty}^{\infty} h[k]x[n-k] \right|$$

$$\leq \sum_{k=-\infty}^{\infty} |h[k]| |x[n-k]|$$

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

Proof(⇒):

If |x[n]| < B for all n, and $\sum_{k=-\infty}^{\infty} |h[k]| < \infty$:

$$|y[n]| = \left| \sum_{k=-\infty}^{\infty} h[k]x[n-k] \right|$$

$$\leq \sum_{k=-\infty}^{\infty} |h[k]| |x[n-k]|$$

$$\leq B \sum_{k=-\infty}^{\infty} |h[k]| < \infty$$

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

Proof(⇐):

If $\sum_{k=-\infty}^{\infty}|h[k]|=\infty$, we show that there exists a bounded input x[n] for which the system output grows unbounded.

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

Proof(⇐):

If $\sum_{k=-\infty}^{\infty} |h[k]| = \infty$, we show that there exists a bounded input x[n] for which the system output grows unbounded.

$$x[n] = \begin{cases} 0 & h[-n] = 0 \\ \frac{|h[-n]|}{h[-n]} & h[-n] \neq 0 \end{cases} \Rightarrow |x[n]| \le 1$$

An LTI system is stable if and only if its impulse response is absolutely summable or absolutely integrable.

$Proof(\Leftarrow)$:

If $\sum_{k=-\infty}^{\infty} |h[k]| = \infty$, we show that there exists a bounded input x[n] for which the system output grows unbounded.

$$x[n] = \begin{cases} 0 & h[-n] = 0 \\ \frac{|h[-n]|}{|h[-n]|} & h[-n] \neq 0 \end{cases} \Rightarrow |x[n]| \le 1$$

$$y[0] = \sum_{k=-\infty}^{\infty} x[k]h[-k] = \sum_{k=-\infty}^{\infty} |h[-k]| = \infty$$