CAN

Start

Initialization

CAN_init()

idle

Send value

CAN_SendByte()

System shutdown

End