UART Interface Diagram

	SDA									
SCL		1 – 7	8	9	1 – 8	9	1 – 8	9	

START   ADDR   R/W   ACK   DATA   ACK   DATA   ACK   STOP