



OPTICAL PUMPING OF RUBIDIUM

Guide to the Experiment

INSTRUCTOR'S MANUAL

A PRODUCT OF TEACHSPIN, INC.

TeachSpin, Inc. 45 Penhurst Park, Buffalo, NY 14222-1013 (716) 885-4701 or www.teachspin.com

Copyright © June 2002

Lab cop4

Table of Contents

SECTION			PAGE
1.	Introduction		1-1
2.	Theory		
	Α.	Structure of alkali atoms	2-1
	В.	Interaction of an alkali atom with a magnetic field	2-2
	C.	Photon absorption in an alkali atom	2-8
	D.	Optical pumping in rubidium	2-11
	Ε.	Zero field transition	2-14
	F.	Rf spectroscopy of Rb ⁸⁵ and Rb ⁸⁷	2-15
	G.	Transient effects	2-17
3.	Apparatus		•
	A:	Rubidium discharge lamp	3-1
	В.	Detector	3-3
	C.	Optics	3-5
	D.	Temperature regulation	3-10
•	E.	Magnetic fields	3-14
	F.	Radio frequency	3-19
4.	Experiments		
	Α.	Absorption of Rb resonance radiation by atomic Rb	4-1
	В.	Low field resonances	4-6
	C.	Quadratic Zeeman Effect	4-12
	D.	Transient effects	4-17
5.	Getting Start	red .	5-1



INTRODUCTION

The term "optical pumping" refers to a process which uses photons to redistribute the states occupied by a collection of atoms. For example, an isolated collection of atoms in the form of a gas will occupy their available energy states, at a given temperature, in a way predicted by standard statistical mechanics. This is referred to as the thermal equilibrium distribution. But the distribution of the atoms among these energy states can be radically altered by the clever application of what is called "resonance radiation."

Alfred Kastler, a French physicist, introduced modern optical pumping in 1950 and, in 1966, was awarded a Nobel Prize "for the discovery and development of optical methods for studying hertzian resonances in atoms." In these laboratory experiments you will explore the phenomenon of optical pumping and its application to fundamental measurements in atomic physics. It is not likely that you will have time to study all the possible experiments that this instrument is capable of performing, but you should have ample opportunity to explore many interesting phenomena. The apparatus has deceptively simple components, yet it is capable of exploring very complex physics.

The atom you will be exploring is rubidium. It is chosen because of its hydrogen-like qualities. That is, it is a very good approximation to consider this atom as a one-electron atom, since the "core" electrons form a closed shell, noble gas configuration. The rubidium atoms are contained within a sealed glass bulb along with 30 torr of the noble gas neon. Ideally, if one were studying the metrology of the energy state of rubidium, one would want to have the atoms in vacuum at extremely low density, so they would not interact. Such systems do exist; they are called an atomic beam apparatus, but they are very large and expensive instruments which have their own serious limitations. The addition of neon, as a "buffer gas," in a small contained volume, greatly simplifies the apparatus and the experiments. Because of the spherical symmetry of the electronic ground state of neon, collisions between a rubidium and neon atom do not exchange angular momentum. This turns out to be crucial for performing optical pumping experiments.

You will probably need to review your atomic physics and possibly your optics. The use of circularly polarized light is also crucial to the optical pumping process. We strongly urge you to review these subjects as well as to look up most of the references given in this manual. Although the basic process was discovered over 50 years ago, the topic is very current.

Optical pumping is the basis of all lasers; it is an important tool for studying collision and exchange relaxation processes, and also finds applicability in both solid state and liquid state physics. A good article to start your reading might be Thomas Carver's review article in Science 16 August, 1963 Vol. 141, No. 3581. There is also a set of reprints called MASERS AND OPTICAL PUMPING, AAPT Committee Resource Letters, published in 1965. Look them up.

Have fun!



THEORY

2A. Structure of Alkali Atoms

In these experiments, we will study the absorption of light by rubidium atoms, and, as a prelude to that, we will consider the atomic structure of the rubidium atom. In the quantum mechanical model we will consider, atoms are described in terms of the central field approximation in which the nucleus is taken to be a point particle characterized by its only observable properties of charge, spin angular momentum, and electric and magnetic moments. The energy levels can be described by angular momentum wave functions that can be calculated generally from the angular parts of the separated Schrodinger equation. These functions are applied in a perturbation theory approach to calculate the eigenstates of the atom. In the case of the alkali atoms, the angular momenta are coupled in what is called the Russell-Saunders coupling scheme, which yields energy level values close to those observed.

All of the alkali atoms are similar in structure to the hydrogen atom. That is, many of their properties are determined by a *single* valence electron. Rubidium, which has an atomic number of 37, can be described by means of an electronic configuration (in the standard notation):

where the superscripts are the number of electrons in each shell [2A-1]. The electrons in the inner shells are paired, and to the approximation necessary here, we can completely neglect the presence of the inner electrons, and concentrate our attention on the single outer electron. That is, the entire discussion of all our optical pumping experiments will be based on a model that considers a free rubidium atom as if it was a simple hydrogenic single electron atom.

The outer electron can be described by means of an orbital angular momentum L, a spin angular momentum S, and a total non-nuclear angular momentum J, all in units of \hbar . Since these are all vectors they can be combined by the usual rules as shown in Figure 2A-1. Each of these angular momenta has a magnetic dipole moment associated with it, and they are coupled by a magnetic interaction of the form $\mu_L \cdot \mu_S$. As is the case with classical angular momenta, different orientations of the vectors lead to different interaction energies. Here, however, the values of energy that result are quantized, and can have only allowed values.

As can be seen from the figure, the total angular momentum can be written as

$$J = L + S$$

In the absence of any further interactions **J** will be a constant of the motion.

In the electronic ground state of an alkali atom the value of L is zero, as it is in the hydrogen atom. Since a single electron has an intrinsic spin angular momentum of $\hbar/2$, the value of S will be $\frac{1}{2}$, and the total angular momentum will have a value of $S = \frac{1}{2}$.



FIGURE 2A-1. Angular momentum coupling in the valence electron of an alkali atom.

In spectroscopic notation, the electronic state is written $^{2S+1}$ L $_J$ so the ground state of an alkali atom is designated $^2S_{1/2}$. The first excited state has an L value of 1 \hbar , and is designated as a P state. Higher values of L are given the label D, F, ... by convention.

In the case of the P state, J can only have the values L+S and L-S. Thus, there are only two P states, $^2P_{1/2}$ and $^2P_{3/2}$, for the single electron in an alkali atom. These states have different energies. This energy splitting, called the **Fine Structure**, is shown diagrammatically in Figure 2A-2. Please note, Figure 2A-2 is not to scale! The fine structure splitting is *much*, *much*, *much*, smaller than the energy difference between the ground state and the first excited state.




FIGURE 2A-2. Energy level diagram of an alkali atom.

We must now take into account the properties of the nucleus of the atom. In particular we must consider the nuclear spin and the nuclear magnetic dipole moment. Many nuclei have an intrinsic angular momentum, similar to that of the electron, with different values depending on the nucleus.

Associated with this spin is a magnetic dipole moment. In the approximation that we are considering here, the nuclear moment will couple with the electronic magnetic dipole moment associated with **J** to form a total angular momentum of the atom, **F**. In the context of the vector model the coupling is as shown in Figure 2A-3.




FIGURE 2A-3. Hyperfine coupling in an alkali atom.

The nuclear spin is denoted by I, the interaction is again of the form $\mu_I \cdot \mu_J$, and the result is a further splitting of the energy levels called the **Hyperfine Structure**. This energy can be characterized by a Hamiltonian as

$$\mathcal{H} = \text{ha } \mathbf{I} \cdot \mathbf{J}$$
 2A-1

where h is Planck's constant and a is a constant that is different for each electronic state and is determined experimentally. The eigenvalues of this Hamiltonian give the interaction energies as shown in Figure 2A-4.




FIGURE 2A-4. Hyperfine splitting for I = 3/2

REFERENCES

[2A-1] J. C. Slater, "Quantum Theory of Atomic Structure" (McGraw-Hill, New York, 1960).

2B. Interaction of an Alkali Atom with a Magnetic Field

e must now consider the effect of a weak external magnetic field on the energy levels of our alkali atom. This will produce the **Zeeman Effect**, and will result in further splitting of the energy levels. What is meant by "weak" magnetic field? If the resulting splitting is very small compared to the **Hyperfine Splitting** (HFS), the magnetic field is said to be weak. This will be the case in all the experiments discussed here.

A vector diagram for an alkali atom is shown in Figure 2B-1. B designates the magnetic field, and M is the component of F in the direction of the magnetic field. F precesses about the magnetic field at the Larmour frequency.




FIGURE 2B-1. Zeeman effect in an alkali atom.

The Hamiltonian that accounts for the interaction of the electronic and nuclear magnetic moments with the external field is

$$\mathcal{H} = \text{ha } \mathbf{I} \cdot \mathbf{J} - \frac{\mu_J}{J} \mathbf{J} \cdot \mathbf{B} - \frac{\mu_I}{I} \mathbf{I} \cdot \mathbf{B}$$
 2B-1

where μ_J is the total electronic magnetic dipole moment (spin coupled to orbit), and μ_I is the nuclear magnetic dipole moment. The resulting energy levels are shown in Figure 2B-2 for the $^2S_{1/2}$ ground electronic state with a positive nuclear magnetic moment and a nuclear spin of 3/2. The levels are similar for the $^2P_{1/2}$ state. For reasons that will become clear later, we will ignore the $^2P_{3/2}$ state. As can be seen from Figure 2B-2 the magnetic field splits each F level into 2F + 1 sublevels that are approximately equally spaced. In actuality, they vary in their spacing by a small amount determined by the direct interaction of the nuclear magnetic moment with the applied field. We will take advantage of this later on to allow all of the possible transitions to be observed.




FIGURE 2B-2. Energy levels of an alkali atom in the ${}^{2}S_{1/2}$ state with a nuclear spin of 3/2 and a positive nuclear magnetic dipole moment in a weak magnetic field.

In the case of an atom with either J=1/2 or I=1/2 the energy levels can be calculated in closed form from quantum mechanics. This solution is called the Breit-Rabi equation. To proceed further, we need to consider the atom-magnetic field interaction in more detail. A single electron has spin of 1/2 and an electrical charge of about 1.6×10^{-19} coulomb. In the simplest picture, this rotating charge gives rise to a magnetic dipole moment whose magnitude is equal to μ_0 , the Bohr magneton. If the electron is bound in an atom, its effective magnetic moment changes and is best described by means of the Lande g-factor.

If the nucleus is neglected, the vector model [2B-1] is used to write the energy of interaction of an atom with an external magnetic field as

Magnetic energy =
$$\frac{M[(L+2S)GJ}{J^2}\mu_0B = g_J\mu_0MB$$
 2B-2

where g_J , known as the Lande g-factor, is given by

$$g_J = \frac{(\mathbf{L} + 2\mathbf{S})\mathbf{S}J}{J^2}$$
 2B-3

This can be evaluated from the vector model to be

$$g_J = 1 + \frac{J(J+1) + S(S+1) - L(L+1)}{2J(J+1)}$$
 2B-4

In terms of this g-factor the interaction energy of the electronic spin with a magnetic field can be expressed as

$$W = -g_{I}\mu_{0}BM$$
 2B-5

where B is the magnitude of the magnetic field and M is the component of the electron spin along the magnetic field. In the case of rubidium, where J = S = 1/2 the Lande g-factor is 2. Actually, the measured g-factor turns out to be 2.00232.

If the interaction with the nucleus is considered, the g-factor is given by

$$g_F = g_J \frac{F(F+1) + J(J+1) - I(I+1)}{2F(F+1)}$$
 2B-6

The interaction energy is then given by

$$W = g_F \mu_0 BM$$
 2B-7

where the direct interaction of the nuclear moment with the magnetic field is being neglected.

The above results are satisfactory as long as the interaction energy with the magnetic field is small, and the energy levels depend only linearly on the magnetic field. For the purposes of our experiment, we need to consider terms quadratic in the field. Equation 2B-1 can be diagonalized by standard methods of perturbation theory. The result is the Breit-Rabi equation

$$W(F,M) = -\frac{\Delta W}{2(2I+1)} - \frac{\mu_I}{I} BM \pm \frac{\Delta W}{2} \left[1 + \frac{4M}{2I+1} x + x^2 \right]^{1/2}$$
 2B-8

where

$$x = (g_J - g_I) \frac{\mu_0 B}{\Delta W} \qquad g_I = -\frac{\mu_I}{I \mu_0}$$
 2B-9

W is the interaction energy and ΔW is the hyperfine energy splitting [2B-2].

A plot of the Breit-Rabi equation is shown in Figure 2B-3. The energy is shown on the vertical axis field as the dimensionless number $W/\Delta W$, and the horizontal axis shows the magnetic field as the dimensionless number x. The diagram can be divided into three main parts. The first is the Zeeman region very close to x=0 where the energy level splitting varies linearly with the applied magnetic field. The second is the Paschen-Back region x>2, where the energy levels are again linear in the magnetic field. This corresponds to the decoupling of I and J. The upper group of four levels corresponds to m_J , the projection of J along the axis of the applied magnetic field, having a value of 1/2, while the four lower levels correspond to $m_J=-1/2$. The individual levels correspond to different values of m_I , the projection of I along the axis of the applied magnetic field.

The third region is the intermediate field region that extends from the Zeeman to the Paschen-Back region. Here, the energy levels are not linear in the applied magnetic field; I and J are decoupling; and M is no longer a "good" quantum number. In the Zeeman region, M is a good quantum number. At high fields m_I and m_J are good quantum numbers and can be used to label the levels. At all fields, $M = m_I + m_J$.

In the optical pumping experiment, we will be concerned with small magnetic fields, where the levels are either linear in the magnetic field, or where there is a small quadratic dependence.




FIGURE 2B-3. Breit-Rabi diagram of an alkali atom in a magnetic field. The nuclear spin is 3/2 and the nuclear magnetic moment is positive.

REFERENCES

[2B-1] J. C. Slater, "Quantum Theory of Atomic Structure" (McGraw-Hill, New York, 1960).

[2B-2] N. F. Ramsey, "Molecular Beams" (Oxford University Press, London, 1969).

2C. Photon Absorption in an Alkali Atom

he three lowest electronic states of an alkali atom are shown in Figure 2A-2. As discussed there, if all filled electron shells are omitted, these three states can be labeled as

ground electronic state:

first excited electronic state:

 $5p^{2}P_{10}$

second excited electronic state: 5p ²P_{3D}

An electric dipole transition can take place between S and the P states with the selection rules $\Delta S = 0$, $\Delta J = 0$, ± 1 and $\Delta L = 0$, ± 1 but not L = 0 to L = 0. Thus this type of transition can occur from the ground state to both of the excited states.

In the optical pumping experiment we are primarily interested in the absorption of light




FIGURE 2C-1. Light absorption by a volume of gas.

by a volume of a gas as illustrated in Figure 2C-1. Assuming that the light is resonant with one of the allowed transitions, a fraction of the incident light will be absorbed by the atoms of the gas. Once the atoms have been excited they will decay back to the ground state by spontaneous emission, but since this emission occurs equally in all directions, only a small amount will be radiated into the outgoing beam. For our discussion, this fraction will be ignored.

It is convenient to describe this process using the concept of a "cross section". Suppose for instance, that the incoming beam consisted of electrons instead of photons. In that case, the attenuation of the incoming electrons by the gas atoms can, in the limit of low density, be

described by the simple relation

$$n = n_0 e^{-\sigma \rho \ell}$$
 2C-1

where n_0 and n are the incident and outgoing flux of electrons, ρ is the gas density, ℓ is the path length through the gas, and σ is the cross section. In the case of electron-atom or atomatom scattering the magnitude of the cross section is of the order of 10^{-20} m², which is $(10^{-10})^2$, and 10^{-10} m is taken to represent the geometrical diameter of the atom.

A similar concept can be applied to the absorption of photons by a volume of gas. Here we write

$$I = I_0 e^{-\sigma_0 \rho \ell}$$
 2C-2

where I₀ and I represent the incident and outgoing flux of photons. If the incident photons are resonant with an atomic transition the observed cross-section will be dramatically different from the geometrical cross-section. In fact, this cross-section is often taken to be of the order of the wavelength of the radiation squared. In this experiment you will attempt to measure the photon absorption cross-section for rubidium resonance radiation on rubidium atoms, and you can compare your measured value with expectations.

The quantity σ_0 is the maximum absorption cross-section measured at the center of the atomic resonance, and it is related to the usual definition of the absorption coefficient by

$$k_0 \equiv \sigma_0 \dot{\rho}$$
 2C-3

For an absorption line that is being broadened only by the Doppler effect, the maximum absorption coefficient can be calculated from

$$k_0 = \frac{2}{\Delta v_D} \cdot \frac{\lambda_0^2 g_2}{8\pi g_1} \cdot \frac{\rho}{\tau}$$
 2C-4

where λ_0 is the wavelength at the center of the absorption line, $\Delta \nu_D$ is the Doppler width of the absorption line, g_1 and g_2 are the statistical weights of the lower and upper state respectively, and τ is the radiative lifetime of the upper electronic state. The Doppler width can be calculated from

$$\Delta v_D = 3 \times 10^{-20} v_0 \left(\frac{T}{M}\right)^{\frac{1}{2}}$$
 2C-5

where ν_0 is the transition frequency, T is the absolute temperature of the absorbing gas, and M is the mass of the absorbing atom [2C-1].

For optical pumping, we must take the hyperfine structure into account. The energy levels are as shown in Figure 2A-4. Now an additional selection rule, $\Delta F = 0$, ± 1 , must be added for changes in the total angular momentum quantum number. Additional splitting is introduced by an external magnetic field as shown in Figure 2B-2, requiring yet another selection rule $\Delta M = 0, \pm 1$. Thus, the selection rules for an electric dipole transition can be summarized by

Electric dipole transition:
$$\Delta S = 0$$
, $\Delta J = 0$, ± 1 , $\Delta L = 0$, ± 1 but not $L = 0$ to $L = 0$
 $\Delta F = 0$, ± 1 and $\Delta M = 0$, ± 1

In the emission spectrum of an alkali atom, all transitions obeying the above selection rules are observed, and these give rise to the well-known bright line spectrum (the emission Zeeman effect will be ignored in this discussion). In absorption, however, things can be somewhat different in regard to the selection rule for M. Since angular momentum must always be conserved, the absorption of light in the presence of an applied magnetic field will depend on the polarization of the light and the direction of the incoming beam of light with respect to the direction of the magnetic field. For our purposes we are only interested in the absorption of circularly polarized light that is resonant with the transition from the ²S_{1/2} state to the P states.

In the optical pumping experiment, the direction of the incident light is parallel to the applied magnetic field, and the light is polarized so that it is either right or left circularly polarized. In this arrangement, only transitions in which M changes by +1 or -1 are allowed, but not both. Pumping will occur in either case as will be discussed later.

The above discussion applies to allowed electric dipole transitions in an atom. We must also consider magnetic dipole transitions that are about 10^5 times weaker than in the electric dipole case. The transitions in which we will be interested occur in the hyperfine structure and between the magnetic sublevels, and will only be observed in absorption. The selection rules are $\Delta F = 0, \pm 1$ and $\Delta M = 0, \pm 1$. Which transitions occur depends on the orientation of the RF magnetic field with respect to the dc magnetic field.

In our experiment, the RF magnetic field is perpendicular to the dc magnetic field. In this case, the only transitions that can occur have $\Delta F = 0$, ± 1 and $\Delta M = \pm 1$. The $\Delta F = \pm 1$ transitions occur at RF frequencies of several gigahertz (GHz), and can not be observed with this apparatus. Therefore, we will only be concerned with $\Delta F = 0$ and $\Delta M = \pm 1$.

In the case of allowed electric dipole transitions in emission, the lifetimes of the excited states are of the order of 10⁻⁸ second resulting in a natural line width of several hundred megahertz (MHz). The actual line width, determined by Doppler broadening, is of the order of one GHz. For magnetic dipole transitions in the hyperfine structure of the ground electronic state, the lifetimes for radiation are much longer, and collision processes will determine the actual lifetimes.

REFERENCES

[2C-1] Allan C. G. Mitchell and Mark W. Zemansky, "Resonance Radiation and Excited Atoms (Cambridge Univ. Press, 1961).

2D. Optical Pumping in Rubidium

ptical pumping is a method of driving an ensemble of atoms away from thermodynamic equilibrium by means of the resonant absorption of light [2D-1, 2D-2, 2D-3, 2D-4]. Rubidium resonance radiation is passed through a heated absorption cell containing rubidium metal and a buffer gas. The buffer gas is usually a noble gas such as helium or neon. If it were not present, the rubidium atoms would quickly collide with the walls of the cell which would tend to destroy the optical pumping. Collisions with the buffer gas are much less likely to destroy the pumping, thus allowing a greater degree of pumping to be obtained.

The general arrangement of the apparatus is shown in Figure 2D-1.




FIGURE 2D-1. Apparatus arrangement for optical pumping.

Resonance light is produced by an RF discharge lamp containing xenon gas and a small amount of rubidium metal, which has been enriched in Rb⁸⁷ such that there are equal amounts of natural Rb and Rb⁸⁷. The gas is excited by an oscillator operating at a frequency of about 100 MHz. The high electric field produced in the lamp causes ionization in the gas, and the resulting electrons are accelerated sufficiently to excite the rubidium atoms by collisions. Spontaneous radiation from the excited states produces the emission spectrum of rubidium.

Resonance light from the lamp consists of two main lines one at 780 and one at 795nm. The 780 nm line is removed by the interference filter and the remaining light is circularly polarized before being passed through the absorption cell. An optical detector monitors the intensity of the transmitted light. A dc magnetic field is applied to the absorption cell along the optical axis, and transitions are induced in the sample by means of a transverse RF magnetic field.

Figure 2D-2 shows the magnetic fields and angular momenta involved in the optical pumping of rubidium. The projection of F along the magnetic field is the magnetic quantum number M, and this vector precesses about the applied magnetic field at the Larmor frequency. Note that the RF magnetic field is perpendicular to the applied dc magnetic field.

Transitions are induced between electronic energy levels by the optical radiation and between the Zeeman levels by means of the RF magnetic field. The optical transitions are shown schematically in Figure 2D-3 for those energy levels involved in the optical pumping of Rb⁸⁷ which has a nuclear spin of 3/2. The transitions are shown for the case of $\Delta M = +1$, but the

situation would be similar for $\Delta M = -1$ except that the pumping would go to the M = -2 level of $^2S_{1/2}$ electronic ground state.




FIGURE 2D-2. Magnetic fields and angular momenta involved in the experiment.

Due to the circular polarization of the incident light, there are no transitions from the M = +2 magnetic sublevel of the ground state since there is no M = 3 state.




FIGURE 2D-3. Transitions involved in the optical pumping of Rb⁸⁷.

The excited states can decay back into this level by spontaneous emission or collisions providing a path into the level but not out of it. Hence, the population of this level will increase with respect to the other sublevels. The population of the M = +2 level is monitored by the intensity of the transmitted light. Any process that changes this population, such as transitions between the M levels, will change the intensity of this transmitted light.

The intensity of the transmitted light is monitored by a photodiode whose output is amplified and observed on an oscilloscope or other recording device. The RF is set to a predetermined frequency and amplitude, and the magnetic field is slowly varied. The resulting output represents the transmitted light intensity as a function of applied magnetic field.

The optical pumping process itself will be studied in this experiment, and it will be determined that pumping requires a time of 10-20 milliseconds to achieve a suitable population of the

M = +2 sublevel. Hence, the rate of variation of the magnetic field must be kept small in order for there to be sufficient absorption of the transmitted light.

If the above discussed processes were the only ones that occurred, the result would be a very large increase in the population of the M = +2 or M = -2 states. However, we must consider collisional processes between the pumped rubidium atoms and other rubidium atoms, and also collisions with atoms of the buffer gas. These collisions can result in transitions between the magnetic substates, and such transitions will tend to equalize the populations and destroy the optical pumping. In actuality, the amount of pumping will be determined by a balance between the rate of transitions into the pumped state, and the rate at which atoms are removed from this state by collisional relaxation processes.

A set of rate equations can be used to describe the pumping process [2D-5]. Consider the isotope Rb ⁸⁷ that has a nuclear spin of 3/2 and a total of 8 magnetic sublevels in the ground electronic state. Let b_{ij} be the probability per unit time that an atom in the sublevel i of the ground state has undergone a transition to the sublevel j of the ground state by absorption and re-emission of a photon. Similarly let w_{ij} be the probability per unit time for the corresponding transition produced by relaxation processes. The occupation probability $p_k(t)$ of the k-th level is obtained by the solution of the following set of eight simultaneous differential equations:

$$\dot{p}_k = -\sum_{i=1}^8 (b_{kj} + w_{kj}) p_k + \sum_{i=1}^8 (b_{ik} + w_{ik}) p_i \quad k = 1, 2, ... 8$$
 2D-1

Only seven of these equations are independent since $\sum_{k} p_{k} = 1$. The dot denotes

differentiation with respect to time, and the sums should exclude terms in which j=k and i=k. For a full discussion see the article by Franzen and Emslie [2D-5]. It is shown there that the population of the M=+2 or the M=-2 state will increase exponentially with time after the pumping light is turned on and the population of the other M levels will decrease. Thus, an excess population in the level of maximum M will develop, as compared to the population distribution in thermodynamic equilibrium. This is what is meant by the term "optical pumping".

REFERENCES

- [2D-1] Robert L. de Zafra, Am. J. Phys. volume?, 646 (1960).
- [2D-2] William Happer, Rev. Mod. Phys., 44, 169 (1972).
- [2D-3] G. W. Series, Rept. Progr. Phys. 22, 280 (1959).
- [2D-4] Alan Corney, "Atomic and Laser Spectroscopy" (Oxford Univ. Press, 1986).
- [2D-5] W. Franzen and A. G. Emslie, Phys. Rev. 108, 1453 (1957).

2E. Zero Field Transition

Before we consider RF resonances in rubidium it is necessary to discuss the transitions that can be observed at zero magnetic field. Assume that the apparatus is set up as in Figure 2D-1 and that no RF is applied. The magnetic field is now slowly swept around zero, and the intensity of the transmitted light is monitored. A decrease in intensity will be observed as the field goes through zero as shown in Figure 2E-1.




FIGURE 2E-1. Transition at zero magnetic field with no RF.

If the magnetic field is set to zero manually, a dc signal will be observed as a decrease in the intensity of the transmitted light. This can be understood qualitatively by referring to Figure 2E-2 which shows the energy levels near zero magnetic field. To either side of zero field the levels are split in energy, and normal optical pumping occurs. However, at or near zero field, the levels become degenerate; optical pumping does not produce a population imbalance; and more light is absorbed.

The zero field signal provides a good way to determine the parameters for zero total magnetic field within the volume of the absorption cell. If the magnetic field is swept in time, and the output of the optical detector displayed on a scope, the field in the cell can be made as near zero as possible by adjusting the compensating coils and the orientation of the apparatus to achieve minimum line width. The above is true as long as the magnetic field is not swept too rapidly. Fast sweeping will produce time dependent effects which will be discussed later.




FIGURE 2E-2. Energy levels near zero magnetic field with no RF.

2F. RF Spectroscopy of Rb85 and Rb87

s mentioned in the previous section, optical pumping drives an atomic system away from thermodynamic equilibrium. Consider the energy levels of the ground electronic state as depicted in Figure 2D-3 which applies to Rb⁸⁷ (nuclear spin of 3/2). We are interested in the levels for atoms in a weak magnetic field (far right of diagram). Since I = 3/2 and J = 1/2, the total angular momentum quantum number has the values of F = 2 or F = 1. The levels would be similar for Rb⁸⁵ except in that case F = 3 or 2.

In thermodynamic equilibrium, the population of the magnetic sublevels of the ground electronic state would be essentially equal, and optical pumping will lead to an excess of population in either the M=2 or the M=-2 levels. After the pumping light has been on for a sufficient time, of the order of milliseconds, a new equilibrium will be established, and the intensity of the light transmitted by the cell will reflect this new equilibrium. If an RF magnetic field is applied as shown in Figure 2D-1 transitions with $\Delta M=\pm 1$ will be induced, and these will tend to drive the system back toward thermodynamic equilibrium. The result will be a decrease in the intensity of the transmitted light.

Equation 2B-5 gives the relative energy levels of the ground electronic state. We can calculate the resonance transition frequency as

$$W(M+1) - W(M) = g_F \mu_0 B(M+1) - W(M) = g_F \mu_0 B$$
 2F-1
 $v = g_F \mu_0 B/h$ 2F-2

where ν is the transition frequency in sec⁻¹ and h is Planck's constant. For our experiment, it is convenient to measure the magnetic field in gauss keeping in mind that 10^4 gauss is equal to one tesla. Using these units, $\mu_0/h=1.3996$ MHz/gauss. The above equations are true as long as the energy levels are a linear function of the applied magnetic field. When terms quadratic in the magnetic field need to be considered, an expansion for the frequency can be used as shown in the next paragraph. At even higher fields, the full Breit-Rabi equation must be used.

To obtain an expression for the transition frequencies that is good to terms quadratic in the magnetic field, it is convenient to re-label the energy levels in terms of an average quantum number [2F-1]. The resonance frequencies for transitions between the levels $|F, M\rangle$ and $|F, M-1\rangle$ with energies W(F, M) and W(F, M-1) and mean azimuthal quantum number $\overline{M} = M - \frac{1}{2}$ are

$$\omega_{FM} = (W_{F,M} - W_{F,M-1})/\hbar$$
 2F-3

Physically meaningful values of \overline{M} occur in the range $-I \le M \le I$.

The resonance frequencies correct to second order in the magnetic field are given by

$$\omega_{I+1/2,\bar{M}} = \frac{B(g_J \mu_B - 2\mu_I)}{(2I+1)\hbar} - \frac{2B^2 \bar{M} (g_J \mu_B + \mu_I / I)^2}{(2I+1)^2 \hbar^2 \omega_{hf}}$$
2F-4

$$\omega_{I-1/2,\overline{M}} = -\frac{B(g_J \mu_B + 2\{1 + 1/I\}\mu_I)}{(2I+1)\hbar} + \frac{2B^2 \overline{M}(g_J \mu_B + \mu_I/I)^2}{(2I+1)^2 \hbar^2 \omega_{hf}}$$
 2F-5

where μ_B is the Bohr magneton and $\hbar\omega_{hf}=(2I+1)\,A/2$ is the energy splitting of the Zeeman multiplets at zero magnetic field. To first order in B, the resonance frequencies are independent of \bar{M} . To second order in B, the resonance frequencies exhibit a quadratic splitting proportional to B^2 \bar{M} which is the same for both Zeeman multiplets [2F-2].

REFERENCES

- [2F-1] A. Ben-Amar Baranga et al, Phys. Rev. A, 58, 2282 (1998).
- [2F-2] H. Kopfermann, "Nuclear Moments" (Academic Press, NY, 1958).

2G. Transient Effects

p until now we have been considering optical pumping only in the steady state, either when the RF has been on for a relatively long time or when there is thermodynamic equilibrium. We will now consider transient phenomena.

We referred, in section 2D, to the time it takes to establish equilibrium after the pumping radiation has been turned on. Here, we will consider the behavior of the pumped system when the RF is rapidly turned off and on while tuned to the center of resonance. In the Zeeman region, at weak magnetic fields, the resonance frequency is given by

$$\omega_0 = 2\pi v_0 = g_f \frac{\mu_0}{\hbar} B_0$$
 2G-1

The Gyromagnetic Ratio γ is defined as

$$\gamma = g_f \frac{\mu_0}{\hbar}$$
 2G-2

The Larmor frequency ω_0 is given by

$$\omega_0 = \gamma B_0$$
 2G-3

Thus γ is the atomic equivalent of the gyromagnetic ratio used in nuclear magnetic resonance.

Figure 2G-1 shows a vector diagram of the spin and the magnetic fields that are relevant to this experiment. The vector \mathbf{B}_{RF} represents the applied RF magnetic field that is provided by the coils at right angles to the static field. We will assume that the magnitude of the RF magnetic field is always much smaller than that of the static field. We will also consider the problem classically.




FIGURE 2G-1. F and its precession about B. B_{RF} is the RF magnetic field.

Consider the system as seen in a coordinate system that is rotating about **B**. The equation of motion is

$$\frac{d\mathbf{F}}{dt} = \gamma \mathbf{F} \times \mathbf{B}$$
 2G-4

The oscillating magnetic field can be considered to consist of two counter-rotating magnetic fields, and transformed to a coordinate system rotating about **B** with angular frequency ω . Then

$$\frac{d\mathbf{F}}{dt} = \frac{\partial \mathbf{F}}{\partial t} + \boldsymbol{\omega} \times \mathbf{F}$$

or

$$\frac{\partial \mathbf{F}}{\partial t} = \gamma \mathbf{F} \times \mathbf{B} + \mathbf{F} \times \boldsymbol{\omega} = \gamma \mathbf{F} \times (\mathbf{B} + \frac{\boldsymbol{\omega}}{\gamma})$$
 2G-6

$$= \gamma \mathbf{F} \times \mathbf{B}_{\text{eff}}$$
 2G-7

where

$$\mathbf{B}_{\mathsf{eff}} = \mathbf{B} + \frac{\omega}{\gamma}$$
 2G-8

In the rotating frame, the effect is the addition of a magnetic field $\frac{\omega}{\gamma}$ to the dc field **B.** [2F-1]

Consider the RF field to be composed of two counter-rotating components of which one has an angular velocity of $-\omega$ as shown in Figure 2G-2. The effective magnetic field is given by [2G-2]

$$\left| B_{eff} \right| = \left[(B - \frac{\omega}{\gamma})^2 + \bar{H_{rf}}^2 \right]^{\frac{1}{2}} = \left| \frac{a}{\gamma} \right|$$
 2G-9

where

$$a = \left[(\omega_0 - \omega)^2 + (\gamma B_{\eta'})^2 \right]^{\frac{1}{2}} = \left[(\omega_0 - \omega)^2 + (\frac{\omega_0 B_{\eta'}}{B})^2 \right]^{\frac{1}{2}}$$
2G-10

and

$$\omega_0 = \gamma B_0$$
, $\cos \theta = \frac{\omega_o - \omega}{\alpha}$ 2G-11

At resonance $\omega = \omega_0$, $\cos \theta = 0$ and $\theta = 90^\circ$.

Also
$$a = \frac{\omega_0 B_{rf}}{B}$$
 and $\left| B_{eff} \right| = \frac{\omega_0 B_{rf}}{\gamma B} = \gamma B \cdot \frac{B_{rf}}{\gamma B} = B_{rf}$.




FIGURE 2G-2. Magnetic fields in the rotating coordinate system.

At resonance in the rotating frame, **F** precesses at the Larmor frequency about $\mathbf{B}_{RF} = \mathbf{B}_{eff}$. Off resonance, it precesses about \mathbf{B}_{eff} . This precession is equivalent to a change in the quantum number M, or a transition between the M sublevels. At resonance, the Larmor frequency is $\mathbf{v} = \gamma B_{rf}$ resulting in a period of $T = 1/\gamma B_{rf}$. At a given value of the RF

magnetic field, the ratio of the periods of the two isotopes is $\frac{T_{87}}{T_{85}} = \frac{\gamma_{85}}{\gamma_{87}}$. In the present experiment we will only be interested in the situation at resonance.

Assume that the optical pumping has created an excess population in the M=2 sublevel in the absence of RF. To the approximation used here we will consider only the M=2 and M=1 sublevels, and neglect all effects of collisional relaxation. Assume now that the RF is applied at the resonance frequency. The situation is as depicted in Figure 2G-3.




FIGURE 2G-3. RF transitions between the M = 2 and the M = 1 sublevels.

The arrows labeled b_{12} and b_{21} represent the transition probabilities from the M = 1 to the M = 2 and the M = 2 to the M = 1 sublevels respectively. The rate equations are

$$\dot{p}_2 = -b_{21}p_2 + b_{12}p_1$$

$$\dot{p}_1 = -b_{12}p_1 + b_{21}p_2$$
2G-12

However, $b_{12} = b_{21} = b$. The equations are not independent, and therefore we will consider only one of them and the normalization condition.

Substitution yields

The solution is

$$\dot{p}_{2} = -bp_{2} + bp_{1}$$

$$p_{1} + p_{2} = 1$$

$$\dot{p}_{2} = b(1 - 2p_{2})$$

$$p_{2} = \frac{1}{2} + \delta e^{-2bt}$$

$$p_{1} = \frac{1}{2} - \delta e^{-2bt}$$

$$2G-13$$

$$2G-14$$

$$2G-15$$

where δ represents the initial excess population in p_2 . At t=0 $p_2=1/2+\delta$ and approaches 1/2 at $t=\infty$. Similarly $p_1=1/2-\delta$ at t=0 and approaches 1/2 at $t=\infty$. Thus the effect of the RF is to equalize the population of the two states. δ depends on the intensity of the optical pumping radiation and b is proportional to the current in the RF coils.

The above calculation suggests an exponential approach to the equal population condition. The situation is different, however, if the RF is suddenly turned on at the resonance frequency after the optically pumped equilibrium has been attained. Since the transition probability is the same for the up or down transition, and the initial population of the upper state is greater than that of the lower, the number of downward transitions will be greater than that of the upward and excess population will be created in the lower state. This will result in a rapid decrease in the intensity of the transmitted light.

Now the situation is reversed, and an excess population will again be transferred to the upper state resulting in a rapid increase in the intensity of the transmitted light. If the transmitted light intensity is being monitored as a function of time a damped ringing signal will be observed [2G-3], and the period of this ringing will correspond to the Larmor frequency for the precession of F about the RF magnetic field as seen in the rotating frame.

The above treatment neglects the effects of the other magnetic sublevels and also the effects of collisions between rubidium atoms and collisions between rubidium atoms and the buffer gas. However, the basic properties of the observed signal are described.

Before the RF is applied the initial population of the p_2 state is $\frac{1}{2} + \delta$. The time to reach 1/e of this value can be shown to be

$$t_{1/e} = \frac{1}{2b}$$
 2G-16



Thus this time is inversely proportional to the RF perturbation and to the current flowing in the RF coils. It is instructive to measure this time as a function of the RF current.

REFERENCES

[2G-1]	I. I. Rabi, N. F. Ramsey, and J. Schwinger, Rev. Mod. Phys. 26, 167 (1954).
[2G-2]	N. F. Ramsey, "Molecular Beams" (Oxford University Press, London, 1969).
[2G-3]	G. W. Series Rent Proor Phys 22 280 (1959)



3. APPARATUS

The specifications given here are not meant as a guarantee of performance, but as typical values. We expect individual instruments to vary, however if some value is more than a factor of two different from those given, this should be brought to the attention of Teachspin Inc.

3A. Rubidium Discharge Lamp

he Rubidium discharge lamp consists of an RF oscillator, oven and gas bulb. The gas bulb is filled with a little Rubidium metal and a buffer gas. The bulb sits within the coil of the oscillator (Figure 3A-1). Stray ions within the bulb are accelerated by the RF electric fields caused by changing magnetic fields. Collisions between the accelerated ions and neutral atoms (both buffer gas atoms and vaporized Rb atoms) cause those atoms to be either ionized or to enter into an excited electronic state. Relaxation of the excited state by spontaneous emission results in the observed resonant radiation from the lamp. The bulb is heated in the oven to increase the Rb vapor pressure (see vapor pressure curves in theory section), and also to regulate the lamp temperature. The lamp intensity changes rapidly with temperature, increasing by 5%/°C at operating temperatures. The oven temperature is set to 115 °C±5 °C.




Figure 3A-1. a) Discharge Lamp

b.) Back Panel Lamp Connections

The rubidium bulb has been isotopically enriched with Rb⁸⁷. It is filled with 50% Rb⁸⁷ and 50% natural Rb. This equates to about 36% Rb⁸⁵ and 64% Rb⁸⁷. The buffer gas is Xenon. This lamp is an optically extended source of light with radiation from both isotopes of Rubidium and multiple lines from the buffer gas Xenon.

 $\begin{array}{lll} Oscillator\ Voltage & +17\ V\ DC \\ Oscillator\ Current & 120\text{-}160\ mA \\ Oven\ Voltage & +28\ V\ DC \\ Oven\ Current & 450\ mA\ (Warm-up)\ 100mA\ (Steady-state) \\ Oscillator\ Frequency & 75\text{-}90\ MHz. \\ Oven\ Temperature & 115 \pm 5\ ^{\circ}C \\ Lamp\ Intensity^{1} & all\ lines 9.0\ \mu W \\ & 795\ nm\ 1.7\ \mu W \end{array}$

The electrical connections to the lamp are made at the back panel. The lamp uses +17 VDC for the oscillator and +28 VDC for the oven. The connection looking into the back panel socket is shown in Figure 3A-1. The Lamp oscillator, oven, and the experimental cell temperature controller all run off a separate +28V power supply.

Voltage is supplied to the lamp when the main power is turned on. Within a few minutes of applying power to the lamp you should see the pinkish discharge light. The oven within the lamp takes 10 to 20 minutes to stabilize. It should be noted that the 795 nm spectral line that is used in the experiment is in the near infrared and cannot be seen by the human eye. The light that you see comes from other lines of Rubidium and Xenon.

¹ The Lamp Intensity is measured by the photodiode. The photodiode was placed such that the front face of the photodiode was 15 cm. from the front face of the lamp and the diode adjusted vertically for a maximum signal. We use the specified responsivity of the diode as 0.6 A/W. For the single 795 nm line measurement the interference filter was placed between the lamp and diode, we assumed the transmission coefficient of the interference to be 0.80 (See figure 3C-1)

3B. Detector

The detector is a Silicon photodiode from Photonic Detectors Inc. PDB-C108 (See spec sheet (Appendix A) The active area of the diode is circular, with a diameter of ¼ inch. The spectral response at 795 nm is about 0.6 A/W. The diode is connected to a current to voltage preamplifier. (See Figure 3B-1) To determine the current supplied by the photodiode, divide the output voltage by the "gain" resistance. The diode is used in photovoltaic mode (cathode grounded, rather than reversed biased) for minimum noise. The preamp is a current-to-voltage converter with three "gain" settings selectable by the small switch on the front of the detector. It has a two-pole low-pass filter to roll off the high frequency gain at about 10kHz.(see Table 3B-1). The photodiode preamplifier has a voltage output of 0.0 to -11.5 V. It is important that the pre-amp be operated at a gain setting such that the output is between -2.0 to -8.0 V to avoid saturating the pre-amp. Power connections to the preamp are by the black plastic connector to the front panel of the electronics box.




Figure 3B-1. a.) Schematic of Photodiode Preamplifier.

b.) Preamp Power Connections

Gain Resistor	Low pass 3dB point	Noise ²
$(M\Omega) \pm 5\%$	$(kHz.) \pm 10\%$	(μV_{p-p})
1	12.0	20
3	8.0	40
10	5.0	100

Table 3B-1. Photodiode Preamplifier Specifications

The signal from the preamp is on the Coax cable with BNC connector labeled <u>Detector</u>. This separate detector connector allows the student to observe the signal from the preamp directly on an oscilloscope. Note: the signal from the preamp is negative with respect to ground.

Normally the preamplifier output will be plugged into the input of the detector section of the electronics box. The detector inverts the signal from the preamp so that more light appears

² Peak to peak noise voltage measured with the front of photodiode covered and with a bandwidth of 0.1 Hz to 1 kHz. (Detector electronics: gain = 1000, Low- pass time constant = 1ms, 10s oscilloscope trace)

as a larger voltage on the meter or detector output. The detector electronics consist of the follow sections:

<u>DC Offset:</u> 0 -10 V DC Set by ten turn potentiometer and fine control approximately 0-20mV set by a one turn potentiometer. The fine control will only be useful at the highest gain settings.

Gain: 1,2,5...100 Adjustable gain set by selector switch and X1, X10 set by toggle switch. Maximum gain is 1000.

<u>Low Pass Filter</u>: A two pole low pass filter with the following time constants; min., 1ms, 10ms, 100ms, 1s, 3s. When set to min. the frequency response is determined by the gain setting of the preamplifier

<u>Meter:</u> The meter displays the output voltage of the detector electronics. The range is -4 to +4 volts with the meter multiplier toggle set to X1 and -8 to +8 Volts when set to X2.


There is 80 μV_{p-p} (referred to the input) of 60 cycle pickup noise on the detector output.


3C. Optics

800

810

<u>Two plano-convex lenses:</u> Diameter 50mm, focal length 50mm. Plano-convex lenses minimize spherical aberrations when there are large differences in the object and image distance from the lens. For best use, the curved side should face towards the larger distance.





Interference filter: Diameter 50mm. The transmission characteristics of the filter are shown in Figure 3C-1. We are mostly interested in the Rubidium D lines at 780nm and 795 nm. The transmission peak of the interference filter may be "tuned" to shorter wavelengths by rotation about the vertical axis. If λ_0 is the peak wavelength then when the filter is tilted at an angle θ the new peak wave length will be given by,

$$\lambda_{\rm S} = \lambda_0 \left(1 - \sin^2 \theta / n^2 \right)^{1/2}$$

(Building Scientific Apparatus, Moore, Davis, and Coplan; Addison-Wesley Second edition pg. 166) where n is the index of refraction of the filter.

Two Linear Polarizers in Rotatable Mounts: Diameter 50mm. Figure 2C-2 shows the transmission and extinction characteristics of the polarizers. The linear polarizer mount has a alignment mark indicating the axis of polarization. The mark should be accurate to $\pm 5^{\circ}$. The rotatable mounts are only held in place by the thumb screw and if the thumb screw is not tighten it is possible for the polarizers or quarter wave plate to fall out.

Figure 3C-1 Transmission of Interference Filter

0.1




Figure 3C-2. Transmission Characteristics of Linear Polarizers

<u>Quarter Wavelength Plate in Rotatable Mount.</u> Diameter 50 mm, "optical thickness" 205 ± 5 nm. When properly oriented, the quarter wave plate allows linearly polarized light to be converted to circularly polarized light. The plate has two optical axes (at 90 degrees to each other) with different indices of refraction along each axis. Light travels at different speeds along each axis. The axes are called the "fast axis" and "slow axis". To produce




Figure 3C-3 Tilt Tuning o Quarter Wave Plate.

circularly polarized light, monochromatic linear polarized light is placed incident to the plate at 45° to each axis. If the plate is of the correct thickness, then the phase lag along the slow axis causes the light exiting the plate to be circular polarized. The "optical thickness" of the plate may not be 795nm/4 which is the desired value. Tuning the optical thickness

(retardation) can be accomplished by rotating the plate about the vertical axis. Rotation about the slow axis increase the retardation, and about the fast axis decreases it. See figure 3C-3. This tuning method requires the fast or slow axis to be aligned vertical.

Alignment:

The first lens is used to collect the light from the lamp. It is desirable to have approximately parallel light rays for the interference filter and ¼-wave plate. However, the extended source size makes this impossible to achieve exactly. The bulb in lamp is approx. 10 mm X 15 mm. It is instructive to remove all the optics, detector, and cell (see section on cell) from the optical rail and place on it just the lamp and one lens. Then in a darkened room, one can observe the spot shape and size from the lamp as a function of the lamp lens separation.

During most of the alignment process it is helpful to have the room lights dimmed to reduce stray light interference. You do need a little light to be able to see the components and detector meter. The optics can be rotated both about the z-axis (the direction along the optical rail) and the vertical axis (towards the center of the Earth) in the alignment process. The experimental cell has been centered 3.5" above the optical rail. (3.5" is also the length of a standard business card which we have found useful for alignment.)




Figure 3D-1

Note that the magnet coils are NOT centered on the optical rail. The short side is for the detector and the longer side is for the lamp and other optics. Place the lamp near the end of the optical rail with the center hole 3.5" above the rail. This will leave plenty of room for the other optical components. You can move the lamp closer to the cell (for higher light intensity) once you have the optics aligned. Place the first lens in front of lamp flat




Figure 3C-2 Side View of Optical Rail.

side towards the lamp, so that the distance between the center of the lamp and center of the lens about 5 cm., this corresponds to a distance of 3-4 cm. between the carriers on the rail. You will see that one side of the optical rail has a ruler attached. Place the second lens and the detector on the short side of the optical rail. The separation between the lens and detector carriers should be about 1-2 cm. The flat side of the lens should face the detector and the detector should be centered at 3.5" above the rail.

Turn on the electronics (See electronics section), making sure that the lamp and detector are plugged in. After a few minutes the lamp should turn on and in about 15 minutes the lamp will be stable.

- 1) Set the cell temperature to 20 °C {This is not a critical step. We just don't want the cell temperature to be set at some high temperature were there is very little transmission. If the cell is set at any temperature below 50 °C that should be fine.} Set the gain and offset of the detector electronics to zero.
- 2) Set the preamp "gain" to $1M\Omega$ (switch down). The meter should be reading off scale (too much light for the preamp.)
- 3) Put the interferences filter on the rail to reduce all but the 795 nm. Rb line {Though it makes little difference in this case, the reflective side of the interference filter should be placed towards the light source.}
- 4) Now adjust the position and height of the lenses for a maximum light signal. Since you set the height of the detector and lamp to 3.5", the height of the cell, you should not change these heights.

Alignment of Polarizers:

The alignment marks on the linear and circular polarizers are accurate to $\pm 5^{\circ}$. The $\frac{1}{4}$ -wavelength retarder may not be of exactly the right thickness. Careful alignment of these components can improve your signals by as much as 30%. However this is not necessary to get a signal. For a quick alignment, set the linear polarizer at 45° and the $\frac{1}{4}$ -wave plate at 0° or 90° . The light needs to go through the linear polarizer before it passes through the $\frac{1}{4}$ -wave plate.

For a better alignment, set the first linear polarizer at 45°. Set the second linear polarizer in front of the detector and rotate it about the z-axis till you see maximum extinction, minimum signal. Typical extinction is about 2% of the maximum signal. The alignment mark on the second polarizer should be close to 135° or 315°. (90° difference from first polarizer) Now place the ¼ wave plate after the first polarizer and rotate the wave plate about the z-axis till you see a maximum signal. The alignment mark should be near 0, 90, 180, or 270°. You may now rotate the second linear polarizer about the z-axis, (using it as an analyzer) to determine the degree of circular polarization.

For complete Circular polarization there should be no change in the signal level as you rotate the linear polarizer. Typical changes from maximum to minimum are between 0% to 50%. If there is a change in light level reaching the detector as you rotate the second linear polarizer, then you can "tune" the ¼-wave plate by rotation about the fast or slow axis (Figure 3E-1) Rotate the ¼-wave plate slightly (5-10°) about the vertical axis. Now rotate the second linear polarizer again and observe the relative changes in the signal. If the relative change is worse than before, then the ¼-wave plate needs to be rotated 90° about the z-axis. Otherwise continue tilting the ¼-wave plate about the vertical axis and analyzing the result with the second linear polarizer.

For the absolute best in alignment (given the components available) one needs to correct for the slight differences between the alignment marks and the real position of the axes. There are several ways to do this. The way we choose to do this is by adjusting the first linear polarizer to 45°. We do this by observing that at exactly 45° a rotation of 180° about the vertical axis is equivalent to a rotation of 90° about the z-axis.

Remove the circular polarizer and have in place only the two linear polarizers. Set the first LP for 45°. Rotate the second LP about the z-axis until you observe the minimum signal. Record the position of the second linear polarizer. Now flip the first LP (rotate 180° about vertical axis). Again rotate the second LP about the z-axis until you observe the minimum signal. Record the position of the second LP. If the difference in position from the first reading is 90° then the first LP is at 45° to the vertical. If the difference is less than 90°, then increase the setting of the first LP by a few degrees (the amount you need to change it is exactly ½ the difference between your readings of the second LP and 90°).




Figure 3C-1

If the difference is greater than 90° then you need to decrease the angle of the first LP. After the first LP is set to 45° then follow the previous steps for alignment of the \(^1/4\)-wave plate.

3D. Temperature Regulation

The following components make up the cell temperature regulation system.

<u>Temperature regulator:</u> Proportional, Integral, Derivate (PID) temperature controller with associated electronics.

Temperature probe: Type T (Copper – Constantan) Thermocouple (5 μm wire) {Constantan is magnetic and the small wire size was chosen such that the magnetic effects of the probe were unobservable, but the small wire size also makes the probe very delicate.}

Oven: The oven contains the following:

Rubidium cell: Glass cylinder with an outside length of 36mm and outside diameter of 25 mm. the wall thickness is about 1.5 mm. The cell contains rubidium metal with associated vapor and 30 torr of neon as a buffer gas.

Cell holder: Foam insert that holds the cell in the center of the oven.

<u>Heater</u>: The heater is an open ended glass cylinder on which is wrapped non-magnetic bifilar wound heater wire. The resistance of the heater is about 50Ω .

Insulation: A layer of foam insulation surrounds the heater.

Oven casing: The oven casing is a Plexiglas cylinder. The removable end caps contain 50mm optical windows. Holes in the casing allow for the heater wire and thermocouple wire to enter the inside of the oven. Also, attached to the oven casing and RF wiring box (to be discussed in the RF section)

Operation:

The thermocouple plugs into the front panel blue plug. The heater is connected to the blue banana plugs on the front panel. The manual for the controller has been included. There are three keys on the controller which are used to program it, (Figure 3D-1) the SCROLL, UP and DOWN keys. Under normal operation you will only be changing the temperature set-point. The controller will normally display the current temperature (PROC). Press the SCROLL key once and the parameter name will appear, wait 1.5 seconds and the parameter value will appear. Press the SCROLL key twice and the controller will step to the next parameter name SP (Set Point), wait 1.5 seconds and the value of the set point will be displayed. You may change the value of the set point with the UP and DOWN keys. To get back to the current temperature press the SCROLL key twice again. The temperature is displayed in degrees Celsius.

The minimum temperature is set by the ambient room temperature. The maximum temperature of about 100 °C. is power limited by the power supply 28V and the heater

resistance 50 ohm. There is no need to worry about your students burning out the heater. There is simply not enough power to raise the temperature significantly above 100 °C.




Figure 3D-1

Instrument Configuration and Control Setup of the controller has been done by Teachspin. The Instrument Configuration is as follows: (Please refer to the Controller Manual if you have questions).

To enter the Instrument Configuration mode press and hold the SCROLL and UP keys simultaneously until the display begins to flash. When the display begins to flash release the SCROLL and UP keys and press the DOWN key. The SCROLL key is used to step through the parameter sequence. (See page 13 of the Controller manual). First the parameter name is displayed on the screen, after 1.5 seconds of no key activity the parameter value is displayed. The UP and DOWN keys are used to change the parameter value. Pressing the SCROLL key returns you to the parameter name, pressing the SCROLL key again steps you to the next parameter name. To exit the Instrument Configuration mode, press and hold the UP and Down keys simultaneously.

Note: When exiting the mode the parameter name must be displayed and not the parameter value!

Though not discussed in the Controller manual, we have found that changing the Instrument Configuration also resets the Control Set-up parameters to their default values. If you do make changes to the Instrument Configuration, you will also have to change the Control Setup.

INSTRUMENT CONFIGURATION PARAMTERS

SEnS	210	Sensor Select (Type T thermo couple, high resolution, °C)
rLO	10.0	Input Range Minimum
rHi	130.0	Input Range Maximum
OUtS	0.200	Output Select (DC pulse, No alarm, No option)
SPS	1	Single/Dual Setpoint, Select (one set point)
CntL	rP	Control Select (Reverse-acting PID)
tunE	EASY	Tuning Select (Easy tune)

There have also been changes made to the Control Setup, some of these variables (indicated with an asterisk *) only appear if the Controller is in Manual tuning mode. To enter the Control Setup mode press and hold the UP and DOWN keys simultaneously. The same key action exits this mode. Note: When exiting the mode, the parameter name must be displayed and not the parameter value!

CONTROLLER SETUP PARAMETERS

SP	50.0	Set Point °C	
Pb	5.8	Proportional Band*	%
rSEt	8.41	Reset (Integral) value* minu	tes.seconds
rAtE	1.26	Rate (Derivative) value*	minutes.seconds
biAS	0.0	Bias (manual Reset) value*	%
FiLt	30	Filter Time Constant	seconds
OFFS	. 0	Input Ofset	
Ct	0.5	Output Cycle Time	seconds
SPL	OFF	Set Point Lock	

We have chosen to set up the PID controller in Easy Tune mode.³ This mode offers satisfactory performance and all the experimenter has to do to change the temperature is change the set point. Though we have not done any careful studies, we have observed more stable signals when the controller is in manual tuning mode *and is tuned correctly*! The problem with the manual tuning mode is that optimal tuning parameters at one temperature will be different from those at another temperature

There are several ways to tune the controller. First we use a list of tuning parameters for several different temperatures (Appendix B). The second is the Pretune Manual mode (see page 21 of the Controller Manual.). To use pretune, first put the controller in manual tuning, then change the set point by 10 °C, then select the process variable display. While the name PROC is on the display press and hold the UP key. PROC will start to blink, when the decimal point and the right hand side of the displays begins to blink then Pre-Tune is active and you can release the key.

³ The tuning of PID controllers (choosing the right mix of P, I and D) is an active area of engineering and the interested student is encouraged to research it on their own.

Finally there is a vast engineering literature on PID controllers (search the web under tuning +"PID controller"). A student who feels more comfortable with engineering than with the Wigner-Eckhart Theorem might enjoy determining the tuning parameters themselves. We have used the Ziegler-Nichols Closed Loop Tuning Method with some success. The controller temperature display does not have enough resolution to display the small thermal oscillations, used in this method to determine the tuning parameters, so we monitored either the voltage going to the heater (by putting a voltmeter across the banana plugs of the electronic box) or by monitoring the oscillating light level through the rubidium cell. In either case it would be useful to have a strip chart recorder or computer with an Analog to Digital Converter to monitor the slow oscillations (periods of several minutes).

Temperature Electronics:

The dc pulse output from the Temperature Controller is passed through a low pass filter ($\tau = 10$ s.) and then amplified. The out put on the blue banana plugs is a DC voltage from 0-26V with a slight 2 Hz ripple. The 2 Hz. ripple is from the 0.5 second cycle time of the DC pulse output.

3E. Magnetic Fields

All DC magnetic fields are produced by Helmholtz coil pairs. The coils are copper wire wrapped on phenolic bobbins. The following table lists their properties:

	Mean Radius cm(inches)	Turns/Side	Field/Amp (T x10 ⁻⁴ /Amp)	Maximum Field (T x10 ⁻⁴)
Vertical Field	11.735 (4.620)	20	1.5	1.5
Horizontal Field	15.79 (6.217)	154	8.8	22.0
Sweep Field	16.39 (6.454)	11	0.60	0.60

Table 3E-1 Magnetic Field values. The calibration of Field/Amp is only approximate. The student will have to determine a more accurate value.

A simplified schematic of the current regulated field control circuitry is shown in Figure 2E-1. The circuit is a simple voltage-to-current converter. The Reference Voltage determines the voltage across the sense resistor and hence the current through the coils. The compensating network "tunes" out the coil inductance so that it appears as a pure resistance to the rest of the circuit. The compensating network draws no DC current.

The voltage across the sense resistor may be measured via tip jacks. The 100 ohms is in series so that the sense resistor can not be accidentally shorted by the student. Connections to the coils are made by the front panel banana plugs. *All the field controls are "unipolar*". If you wish to reverse the field direction you must switch the front panel banana jacks.




Figure 3.E-1). Schematic of Filed control circuitry.

<u>Vertical Field.</u> The Vertical Field is run between ground and the negative supply voltage. This is done because of the current limit of the power supply. The sense resistor is thus at -15V with respect to ground. Caution should thus be exercised if this voltage is monitored with anything but a floating voltmeter.

Sense Resistor: 1Ω , 1%. Monitoring of the sense resistor is done through the back panel tip jacks.

<u>Polarity:</u> The vertical coil is wired so that field will point downward when the red jack is in the red plug. This is the correct direction to cancel the Earths Field in the Northern hemisphere. If you are in the Southern hemisphere you should reverse the jacks. A current of about 0.33 Amperes will cancel the vertical field in Buffalo, NY. USA.

<u>Control:</u> The ten turn potentiometer sets the Reference Voltage. The maximum voltage is 1.0 Volt. (one turn = 0.1 Volt = 0.1 Ampere.)

<u>Horizontal Field.</u> The Main Horizontal Field can be run off the internal power supply with a maximum current of about 1.0 Ampere. Or an external power supply can be used to go to higher fields. The external power supply is connected to banana plugs on the back panel. A toggle switch on the back panel determines which supply is in use.

Sense Resistor: 0.5Ω , 1%. Monitoring of the sense resistor is done via front panel tip jacks.

<u>Polarity:</u> The Horizontal Field is wired such that the field will point from the lamp towards the detector (in the direction of light propagation) when the red plug is in the red jack.

<u>Control:</u> The ten turn potentiometer sets the Reference Voltage. The maximum voltage is 1.5 Volt. (one turn = 0.15 Volt = 0.3 Ampere.)

External Power: The following conditions must be obeyed when using an external DC power supply. The maximum voltage is 40V. The maximum current is 3.0 A. (The circuitry is fuse protected.) The red banana plug must be connected to the positive terminal of the power supply. (The circuitry is diode protected against reverse polarity.)

There are a few other facts that the user should be aware of when using an external power supply. At room temperature, the main coil resistance is about $10\,\Omega$. When large currents are used the coils temperature will increase (to about 75 °C @ 2.7A). This increase causes an increase in the resistance of the coils (to about $12\,\Omega$.)⁴- The changing coil resistance may cause the control circuitry to fall out of compliance. The large amount of heat being dissipated by the coils changes the thermal environment for the nearby cell and lamp. You may notice that it takes a long time for the cell temperature to stabilize. The temperature increase of the coil will also cause a change in the size of the copper coil. It might be instructive for the

⁴ Because we are using a current regulated supply there is a little positive feed back in this situation. As the temperature increases the resistance also increases, but this causes more power to be delivered to the coils (I²R) which further increases the temperature, thus eliminating the current.

students to estimate the magnitude and sign of this change to determine if it would have any effect on their field calibration.

Error light: The error light will come on when the current regulated supply is close to being out of compliance (not enough voltage to supply the desired current). For efficient operation when using an external power supply the voltage of the external power supply should be set a few volts above the point where the error light comes on. The pass element of the control circuitry (which is the power transistor mounted on the back panel heatsink) must dissipate all the excess power. In the worst case scenario the pass transistor will warm up to 90 °C. This is within transistor's specifications, but it will be happier and live a longer life if it is kept cooler.

<u>Horizontal Sweep Field.</u> We often refer to this field as just the Sweep field. The Sweep field coil is a single layer of wire wrapped on top of the Horizontal field coils.

Sense Resistor: 1.0Ω , 1%. Monitoring of the sense resistor is done via front panel tip jacks.

<u>Polarity:</u> The Sweep Field is wired such that the field will point from the lamp towards the detector (in the direction of light propagation) when the red plug is in the red jack.

Control: The Refence Voltage for the sweep field is the sum of three voltages; a Start Field voltage, a Sweep voltage, and a Modulation voltage. We will discuss each in turn. The maximum current that the sweep control can supply is about 1.0 A. When turned to full scale both the Start field and Sweep (Range) voltage are about 1.0 V. This means that it is very easy to set the sweep control so that it is out of compliance. There is no error light to warn the students when this happens. They need to be alert to the possibility.

Start Field: The ten turn potentiometer sets the Start Field voltage. The maximum voltage is about 1.0 Volt. (one turn ≈ 0.1 Volt = 0.1 Ampere.)

Sweep Field: The Sweep voltage is a voltage ramp that starts at zero volts and goes to the voltage set by the ten turn potentiometer marked Range. The maximum range voltage is about 1.0 Volt. The ramp time is set by the selector switch marked Sweep Time. The sweep time may be set from 1 to 1000 seconds. Two toggle switches control when the ramp is started. When the Start/Reset toggle is at Reset, the Sweep voltage is zero. When the toggle is moved to Start the ramp is started. The Single/Continuous toggle determines what happens when the ramp finishes. When set to Continuous the sweep voltage will be reset to zero and then the ramp will repeat itself. If the Single/Continuous toggle is set to Single, then at the end of the ramp the sweep voltage will remain at the voltage maximum voltage set by the Range potentiometer. This is useful in setting up a sweep. With the toggle at reset (or the Range pot turned to zero) use the Start Field potentiometer to set the starting point for the

⁵ This is with maximum voltage and the current set near the mid point. The pass element will have to dissipate the maximum power, for a given supply voltage, when the pass element voltage is equal to the load voltage, which will be equal to one half of the supply voltage.

sweep. Sweep quickly through the signal, and then use the Range potentiometer to set the end of the sweep.

Ext. Start: It is also possible to control the starting of sweeps electronically. The BNC labeled Ext. Start on the lower front panel accepts TTL signals. With the Start/Reset toggle set to Start, a positive TTL pulse (+5V) on the Ext. Start BNC will reset the sweep voltage to zero. On the falling edge of this pulse the sweep voltage will start to ramp. If the Controller is set to Continuous, the ramp will reset at the end of the ramp and start again. If set to Single, the ramp will stop after one sweep, and remain at the maximum voltage until the next pulse is received.

Modulation Voltage: As has been stated previously, the Reference voltage for the Horizontal Sweep Field is the sum of three different voltages; the Start Field voltage, the Sweep voltage, and the Modulation voltage. The Modulation voltage is derived from the controls labeled Magnetic Filed Modulation on the upper front panel. The circuit for these controls is shown in figure 3E-2.




Figure 3E-2 Modulation Voltage Schematic.

They consist of a BNC input, a Start Field /MOD. toggle switch and a one turn potentiometer labeled Amplitude. The Modulation Voltage has several uses. With the toggle switch set to Start Field the BNC input is excluded from the circuit and a small DC voltage is supplied to one side of the potentiometer. The Modulation voltage (which is the voltage on the potentiometer wiper) is then some fraction of this DC voltage. The Modulation voltage thus acts as a fine control of the start field. This is useful when you want to sit right on one of the dips in the Rubidium spectrum. The field range is 0-6 mG (60μ T).

With the Start Field/MOD. toggle in the MOD. position the voltage present on the BNC input is supplied to the potentiometer and becomes the basis for the modulation voltage with the following specifications,

 $\begin{array}{ll} \mbox{Input Impedance} & \mbox{1k} \ \Omega \\ \mbox{Maximum Voltage} & \pm 20 V \\ \mbox{Voltage - Field conversion} & \mbox{1V} \approx 10 \mbox{mG} \\ \end{array}$

The modulation input can be used for at least two separate experiments. Magnetic field modulation experiments used in conjunction with Lock-in or AC detection methods. Secondly large Square wave signals can be applied and the input used for Field Reversal Experiments. (See Experiment section)

Recorder Output and Recorder Offset. The Recorder output is a signal derived from the 1Ω sense resistor that is suitable for driving a chart recorder or oscilloscope. The voltage across the 1Ω sense resistor has been amplified and passed through a low pass filter (time constant = 2 ms.). The signal can also be given a DC offset with ten turn Recorder Offset potentiometer which adds a negative DC voltage to the signal, (-15 Volts at full scale). The gain of the Recorder Output has been set so that $50\text{mV} \approx 1 \text{ mG} (\bar{10} \,\mu\text{T})$, and the voltage can go from - 13.5V to +13.5V. When setting up the largest possible sweeps of the instrument the student needs to keep the output within this range.

3F. Radio Frequency

The RF section consists of the following RF coils, 50 Ω current sense resistor and RF amplifier. (See figure 3F-1)

The RF coils are located on the outside of the cell heater.

Coils 3 turns/side, 18 gauge copper wire

Diameter 6.45 cm (2.54")

Separation 10.80 cm (4.25") (not Helmholtz)

Inductance⁶ 1.66 μH Parallel Capacitance⁷ 24 pF




Figure 3F-1 RF Coil and 50 Ω Current Sensing Resistor.

The $50\,\Omega\,0.5$ Watt Current Sense Resistor is located in the electrical breakout box on the side of the cell. Oscilloscope probe jacks are on the side of the box so that you may measure the voltage across the resistor and thus measure the current in the coil. We have found that most scope probes are magnetic and would advise you to remove the probe after measuring the current. Because of the nuisance of attaching the probe to the sense resistor the student may be tempted to simply measure the voltage at the output of the amplifier. Thought this would be fine to measure relative changes in RF amplitude at one frequency it will not give an accurate measure of the current at high frequencies due to the effects of the long cable and finite coil impedance.

Radio Frequency Amplifier:

Input Impedance 50 Ω Output Impedance 15 Ω

Frequency Range 10kHz. – 30 MHz.

Voltage Gain

Maximum Output Current

Maximum Output Voltage

Maximum Output Power

6 V/V

100mA

8 V _{p-p}

100 mW

Modulation Input TTL input, 0V = RF on, 5V = RF off

⁶ Determined from frequency where voltage across coil is equal to voltage across 50Ω series resistor.

⁷ The capacitance value was not measured directly but is inferred from the resonance at 25 MHz, with $\omega = 1/(L * C)^{1/2}$.



The Besides the input and output connections on the lower front panel the RF amplifier has a single turn Gain control to adjust the output amplitude. And a TTL RF Modulation Input by which the RF can be modulated on and off. The modulation input can be used with a Lock-in Amplifier or other AC detection technique. The output of the amplifier should be monitor with a oscilloscope to insure that the amplifier is not being overdriven (clipped). A clipped RF output will lead to harmonics and spurious signals.



EXPERIMENTS

4A. Absorption of Rb resonance radiation by atomic Rb

n this first experiment, you will make an approximate measurement of the cross-section for the absorption of rubidium resonance radiation by atomic rubidium. The measured value will then be compared with the geometric cross-section and the value calculated from theory.

The apparatus should be arranged as shown in Figure 4A-1. The linear polarizer and the quarter wave plate should be removed since they will not be needed for this experiment. The cell heater should be off, and the apparatus allowed to come to equilibrium. It may be necessary to insert a neutral density filter before the absorption cell to prevent saturation of the detector amplifier.




FIGURE 4A-1. Arrangement of the apparatus.

Set the cell heater to 300 K, and allow thermal equilibrium to be established. It will take about 30 minutes for the temperature to become stable. Measure the intensity of the optical signal taking care to record all amplifier gain settings. Repeat the measurement in temperature increments of 10 K, taking care that thermal equilibrium is reached between readings. Repeat the series of measurements as many times as possible both increasing and decreasing the temperature.

Determine the density of atomic rubidium in the cell as a function of temperature from Table 4A-1, and fit the data to an equation of the form

$$I = ae^{-b\rho}$$
 4A-1

where ρ is the density of atomic rubidium in the cell. From the value of b determine the cross-section for the absorption of rubidium resonance radiation by atomic rubidium.

Compare your result with the calculated value of the cross-section and with the geometrical cross-section.

Temperature, K	Density, atoms/cubic meter
290	3.3 X ₁₀ ¹⁵
300	1.1 X 10 ¹⁶
310	2.9 X 10 ¹⁶
320	7.5 X 10 ¹⁶
330	1.8 X 10 ¹⁷
340	4.3 X 10 ¹⁷
350	8.3 X 10 ¹⁷
360	1.5 X 10 ¹⁸
370	3.7 X 10 ¹⁸
380	6.3 X 10 ¹⁸
390	1.2 X ₁₀ ¹⁹
400	2.4 X 10 ¹⁹

TABLE 4A-1. Density of rubidium atoms over solid or liquid rubidium as a function of temperature [4A-1].

SAMPLE DATA

C. 0	Temperature, K	Detector Output, Volts
27	300	1.57
37	310	1.31
47	320	1.06
5 7	330	0.72
67	340	0.52
77	350	0.24
87	360	0.17
52	370	0.14
109	380	0.13
117	390	0.12
127	400	0.12




FIGURE 4A-2. Plot of Sample Data

It can be seen from the plot that above a density of about 200 X 10¹⁶ there is no further decrease in the intensity of the transmitted light. Ideally the cell should be optically thick, and no light should be transmitted. The light that is transmitted does not fall within the absorption profile of the rubidium in the cell, and hence gets through the cell and causes this background.

This radiation comes from the wings of the emission line and from the buffer gas in the discharge lamp. In order to correct for this a constant detector output voltage of 0.14 volt will be subtracted from all readings, and the plot and fit will be limited to the first seven points. The result is shown in Figure 4A-3.




FIGURE 4A-3. Plot of Sample Data with Background Correction

Points are the data. Curve was fit using Sigma Plot© and nonlinear regression analysis to yield

$$I = 1.36e^{-0.040\rho}$$
 4A-2

The length of the absorption path was about 2.5 cm giving a result

$$0.025\sigma X 10^{16} = 0.040$$
 4A-3
 $\sigma = 1.6 X 10^{-16} \text{ m}^2$ 4A-4

and $\sigma = 1.6X10^{-10} \text{ m}^2$ 4A-4

This can be compared with the result calculated from the equations in section 2C, using a Doppler width at 350K of about 550×10^6 MHz, and a center frequency of about 3.77 x 10^{14} Hz. This corresponds to a center wavelength of 795 X 10^{-9} m. The resulting maximum cross-section is $\sigma_0 = 15 \times 10^{-16} \, \text{m}^2$.

A more detailed calculation of the cross-section is in the literature [4A-2], and a value of about $10 \times 10^{16} \text{ m}^2$ is given there. The geometrical cross-section is about $(10^{-10})^2 = 10^{-20} \text{ m}^2$. Notice that the resonant cross-section is much larger than that normally associated with atomic scattering processes. As a point of interest the value of the absorption cross-section for sodium resonance radiation in atomic sodium is $12 \times 10^{-16} \text{ m}^2$ [4A-3].

Care needs to be taken in the interpretation of these results, since the cross-sections involved are somewhat ambiguous. The cross-section is a function of the frequency distribution in the absorption profile of the rubidium atom, and the intensity of the absorbed light will depend on the relationship of the intensity profile of the incident light to the absorption profile of the

atom. Therefore the measured result should be considered to be only approximate. These considerations are discussed in detail in the literature [4A-4]. The main point here is to realize that the cross-section for absorption of resonance radiation by an atom is much larger than what is usually taken as a measure of the geometrical cross-section.

The measured cross-section is about 10 times smaller than that calculated from theory. However this is not unreasonable considering the sources of error in the experiment. One of the largest of these is the rapid variation of the density of rubidium atoms in the cell as a function of temperature. This dependence, as shown in the Table 4A-1, was calculated from graphical data contained in [4A-1], and is subject to considerable error.

REFERENCES

[4A-1]	Values of density calculated from the vapor pressure data tabulated in "The
	Characterization of High Temperature Vapors", (John Wiley & Sons, 1967).
[4A-2]	A. M. van der Spek, J. J. L. Mulders and L. W. G. Steenhuysen, J. Opt. Soc.
	Am. 5, 1478 (1988).
[4A-3]	Alan Corney, "Atomic and Laser Spectroscopy", pp288, (Oxford University
	Press, 1986).
[4A-4]	Allan C. G. Mitchell and Mark W. Zemansky, "Resonance Radiation and
	Excited Atoms", (Cambridge Univ. Press, 1961).



4B. Low Field Resonances

In all of the following experiments of this lab, it will be necessary to apply a weak magnetic field along the optical axis of the apparatus. In order to do this satisfactorily, the apparatus must be located where the local residual magnetic field is as uniform as possible. The proposed location should be surveyed with a compass to check for gross inhomogeneity in the local field, and the orientation of the horizontal component of the residual field should also be determined. All iron or steel objects should be removed from the vicinity of the apparatus. The instrument should be placed on a table made with no magnetic material, such as the one supplied for this experiment by TeachSpin.

The optical axis of the apparatus should be oriented such that the horizontal component of the residual field is along this axis. The apparatus should be set up as shown in Figure 4B-1, and the interference filter reinstalled. Be sure that the linear polarizer is ahead of the quarter-wave plate in order to obtain circularly polarized light, and that the two are oriented properly.




FIGURE 4B-1. Apparatus arrangement for optical pumping.

In order to observe the zero-field transition, no RF is applied and the magnetic field is swept slowly around zero. This is accomplished by varying the current in the sweep windings. The current through the main horizontal field coils should be set to zero. Adjust the current in the vertical compensating coils to achieve *minimum width* of the zero field transition. Also check the orientation of the apparatus along the horizontal component of the residual field by rotating the apparatus about the vertical axis and setting for minimum line width.

Set the cell temperature to 320 K and allow thermal equilibrium to be established. It is most convenient if the output of the optical detector is observed on the vertical axis of a storage oscilloscope, and a signal proportional to the current in the horizontal axis sweep coils is displayed on the horizontal axis. As will be shown later optical pumping is a slow process, and during these experiments it will be necessary to use a very slow sweep rate for the magnetic field current.

Figure 4B-2 shows the zero field resonance and the Zeeman resonances and at a frequency of 0.0134 MHZ.




FIGURE 4B-2. Zeeman resonances and zero field resonance at very low magnetic fields.


MEASUREMENT OF THE NUCLEAR SPINS

There are two isotopes of rubidium, and they have different nuclear spins. We are going to pretend that we don't know their values, so we can measure them. In order to do this we must measure the g_F values from which the spins can be calculated. This can be done by measuring a single resonant frequency of each isotope at a known value of the magnetic field. The magnetic field will be determined approximately from the geometry of the field coils. Since nuclear spins are either integral or half-integral we need only an approximate value of the field.

We will use only the sweep field coils for this purpose, and their parameters are as follows:

Mean radius =
$$0.1639 \text{ m}$$
 B(gauss) = $8.991 \times 10^{-3} \text{ I N} / \overline{R}$ 4B-1 11 turns on each side

where I is the current in amps, N is the number of turns on each side, and \overline{R} is the mean radius of the coils. The coils satisfy the Helmholtz condition. At the sweep monitor terminals on the front panel, a voltage is presented that is numerically equal to the current in amps (the current passes through a one ohm resistor). Use this voltage as a measure of the sweep coil current.



An RF signal can now be applied to the RF coils, and its amplitude set to an arbitrary value. Later this amplitude will be adjusted for optimum transition probability. The frequency of the RF should be set to about 150 KHz. Sweep the horizontal magnetic field slowly increasing from zero, and search for the Zeeman resonances. Measure the current at which each resonance occurs.

An oscilloscope should be used to measure a signal proportional to the RF current at the connector on the cell holder. This signal is developed across a 50 ohm resistor that is in series with the RF coils, and therefore it is proportional to the amplitude of the RF magnetic field.

Measure the characteristics of the RF transitions as a function of the amplitude of the RF magnetic field, and determine the value that provides optimum transition probability [2G-2].

The remaining data in this section should be taken using that value of RF magnetic field.

LOW FIELD ZEEMAN EFFECT

With the main coils still disconnected, measure the transition frequencies of each isotope as function of sweep coil current, and plot the results to determine that the resonances are indeed linear in the magnetic field. From the slope of the plots determine the ratio of the g_F-factors, and compare the measured ratio with that predicted by theory.

SWEEP FIELD CALIBRATION

For the remainder of the experiment it will be necessary to have a more precise value of the magnetic field than can be obtained from the geometry of the coils. In this section we will calibrate the sweep coils using the known g_F values and the previous measurements.

From the previous measurements calculate the value of the magnetic field for each isotope from the resonance equation, and plot the magnetic field vs. the current in the sweep coils. Fit the data to a straight line using a linear regression to obtain an equation for the magnetic field vs. current.

It will now be necessary to make a calibration of the main field coils.

MAIN FIELD CALIBRATION

Connect up the main coils so that their field is in the same direction as that of the sweep coils. The current control for the main coils is too coarse to allow the resonances to be centered well using it alone. It will be necessary to use both the main coils and the sweep coils for this calibration. The voltage presented by the main coil monitor on the front panel (which is

developed across a 0.5 ohm resistor) is one half of the main coil current in amps. Use this voltage as a measure of the main coil current.

Use both sets of coils to make measurements at resonance frequencies up to about 1 MHz, and use the sweep coil calibration to correct the measured fields for the residual field. Plot the data on a linear plot, and use a linear regression to obtain the best fit.

SAMPLE DATA

Residual magnetic field:

The zero field resonance was determined to be at a sweep field current of 0.323 amp. From this and the above coil parameters the residual field is 0.188 gauss. Since the rest of the experiment will be done with the magnetic field oriented opposite to the residual field, the above number must be subtracted from the values calculated from Equation 4B-1.

Nuclear spins:


At an RF frequency of 150 KHz the measured currents for the two isotopes were 0.836 and 0.662 amp corresponding to magnetic field values of 0.504 and 0.400 gauss. From each of these values a residual field of 0.188 gauss must be subtracted yielding 0.316 and 0.212 gauss.

The resonant frequencies are determined from

$$v = g_F \mu_0 B / h \qquad 2F-2$$


resulting in g_F values of 0.34 and 0.51. From Equation 2B-4 the corresponding nuclear spins are I = 5/2 and I = 3/2 with theoretical g_F values of 1/3 and 1/2 respectively.

Low field Zeeman effect:




The slopes of the two plots are in the ratio of 0.430/0.287 which gives a value of 1.498. The theoretical ratio is 1.5.

Sweep field calibration



Main field calibration

Freq. MHz	Total field, gauss	Sweep current, amp	Main current, amp	B from sweep coils, gauss	B from main coils, gauss	Isotope
0.2000	0.2858	0.321	0.0322	0.0047	0.2811	Rb ⁸⁷
0.2000	0.4287	0.316	0.0492	0.0017	0.4270	Rb ⁸⁵
0.3003	0.4291	0.306	0.0500	-0.0045	0.4336	Rb ⁸⁷
0.3003	0.6437	0.313	0.0740	-0.0002	0.6439	Rb ⁸⁵
0.4002	0.5719	0.197	0.0740	-0.0716	0.6435	Rb ⁸⁷
0.4002	0.8578	0.662	0.0740	0.2148	0.6430	Rb ⁸⁵
0.5002	0.7148	·0.205	0.0900	-0.0667	0.7815	Rb ⁸⁷
0.5002	1.0722	0.785	0.0900	0.2906	0.7816	. Rb ⁸⁵
1.0001	1.4291	0.121	0.1786	-0.1185	1.6482	Rb ⁸⁷



4C. Quadratic Zeeman effect

The RF resonances of both isotopes will now be studied as the applied magnetic field is increased into a region where the energy level splitting is no longer linear in **B**. Each of the zero field energy levels splits into 2F + 1 sublevels, whose spacing is no longer equal. In this region there are 2F resonances whose splittings can be resolved. Thus for I = 3/2 there are a total of six resonances with $\Delta F = 0$ and $\Delta M = \pm 1$, and for I = 5/2 a total of ten. These can all be observed. Their intensities depending on the pumping conditions.

The magnetic field at which these resonances can be observed can be approximately determined from the resonance equation

$$v = g_F \mu_0 B / h \qquad 2F-2$$

and the current for the main field coils set from the previous calibration.

Start with the main field current at zero, and set the sweep current to the center of the zero field transition. Then set the main field current to the desired value, and use the sweep field to observe the resonances. For a given frequency, measure the sweep field current corresponding to each resonance, and calculate the total magnetic field. If the first frequency that you try does not yield resolved resonances go to a higher frequency.

SAMPLE DATA

Rb⁸⁷: Front Panel settings: Output gain = 20×10

v = 4.9874 MHz

 $RC = 100 \, \text{msec}$

RF amp gain = 3 on dial

Sweep time = 100 sec

Main field current = 0.820 amp

Main field = 7.117 gauss

The observed spectrum is shown in Figure 4C-1 and the calculated spectrum from the Breit-Rabi equation is shown in Figure 4C-2.




FIGURE 4C-1. Observed spectrum of Rb⁸⁷ at optimum RF power.




FIGURE 4C-2. Calculated spectrum of Rb⁸⁷.

The absorption intensities in Figure 4C-2 have been adjusted to match the observed spectrum. The Breit-Rabi equation can not be directly solved for x and hence B, but it can be easily solved by a computer program such as Maple or Mathmatica. The results in Figure 4C-2 were obtained using Maple 5.

The resonances occur at fields shown in the following table:

Sweep Field Current, amp	Sweep Field, gauss	Total Field from calibration, gauss	Total Field from BR eqn., gauss
0.292	-0.013	7.104	7.095
0.310	-0.002	7.115	7.106
0.321	0.004	- 7.121	7.113
0.339	0.016	7.133	7.124
0.355	0.025	7.142	7.134
0.373	0.036	7.153	7.145

There is a systematic difference of 0.009 gauss or about 0.14% between the calculated and measured total field values.

The Rb⁸⁷ spectrum taken under the same conditions as above except at higher RF power is shown in Figure 4C-3. Here the double quantum transitions, which occur midway between the single quantum transitions, are shown. Notice that the single quantum transitions have become broader because they are being overdriven by the higher RF power.




FIGURE 4C-3. Observed spectrum of Rb⁸⁷ at higher RF power showing double quantum transitions.

Rb⁸⁵: Front Panel settings: Output gain = 20 X 10

v = 3.3391 MHz

 $RC = 100 \, \text{msec}$

RF amp gain = 3 on dial

Sweep time = 100 secs

Main field current = 0.820 amp

Main field = 7.117 gauss




FIGURE 4C-4. Observed spectrum of Rb⁸⁵ at optimum RF power.




FIGURE 4C-5. Calculated spectrum of Rb⁸⁵.

The resonances occur at fields shown in the following table:

Sweep Field Current, amp	Sweep Field, gauss	Total Field from calibration, gauss	Total Field from BR eqn., gauss
0.318 amp	0.003	7.120	7.115
0.344	0.019	7.136	7.130
0.369	0.034	7.151	7.146
0.395	0.050	7.167	7.162
0.421	0.066	7.183	7.178
0.446	0.081	7.198	7.193

There is a systematic difference of 0.005 gauss or about 0.07% between the calculated and measured total field values.

The Rb⁸⁵ spectrum taken under the same conditions as above except at higher RF power is shown in Figure 4C-6. Here the double quantum transitions, which occur midway between the single quantum transitions, are shown. Notice that the single quantum transitions have become broader because they are being overdriven by the higher RF power.




FIGURE 4C-6. Observed spectrum of Rb⁸⁷ at higher RF power showing double quantum transitions.

4D. Transient Effects

In order to observe transient effects it is necessary to either turn the pumping light off and on rapidly or turn the RF on and off while tuned to the center of a resonance. Here we will do the latter while tuned to the center of a low field resonance, and observe the transmitted light intensity as a function of time.

SAMPLE DATA

A square wave pulse of about 0 to +5 volts amplitude is connected to the RF modulation input on the front panel, and the frequency of the square wave should be set to about 5 Hz. The falling edge of the square wave should be used to trigger the sweep of a storage scope, and the output of the detector monitored. The following data was taken at the resonance




FIGURE 4D-1. Time dependence of the transmitted light intensity vs. RF amplitude.

frequency of 0.3 MHz. The RF amplitude was taken as the voltage across the 50 ohm resistor in series with the RF coil. A typical result is shown in Figure 4D-1. The upper trace shows the waveform that is gating the RF, and the lower shows the resulting optical signal.

When the RF is on all of the Zeeman levels are mixed, no optical pumping takes place, and the transmitted light intensity is a minimum. Turning off the RF allows pumping to begin, and the light intensity increases exponentially until a maximum value is reached. The time constant of this exponential is a measure of the optical pumping time. The characteristic value of the time will be found to be proportional to the intensity of the pumping light.

When the RF is turned on transitions will occur between the Zeeman sublevels and the population of the levels will be driven toward equilibrium. If the rise time of the RF envelope is short enough the populations will overshoot giving rise to the ringing shown in Figure 4D-1. The ringing damps out, and the light intensity approaches that for the unpumped cell.




FIGURE 4D-2. Expanded region where the RF is turned on.

Figure 4D-2 shows an expanded region of Figure 4D-1 in the region of where the RF is turned on. It can be seen that the ringing is damped out followed by a longer damping time before the light returns to the unpumped value.




FIGURE 4D-3. Expanded region where the RF is turned on.

Further expansion of the region around the RF turn on time yields a result shown in Figure 4D-3. Here the ringing can be clearly be seen, and its period measured. According to the earlier discussion this period should be linearly proportional to the reciprocal of the amplitude of the RF, since it corresponds to a precession of F about the RF magnetic field. Figure 4D-4 shows this to be the case for both isotopes where the fit has been done by regression analysis in SigmaPlot.




FIGURE 4D-4. Period of ringing vs. peak RF volts.

At a given value of the RF magnetic field, the ratio of the periods of the ringing is goes inversely as the g_F factors, and the above data shoes that this ratio is 989/641 = 1.54 to be compared with a theoretical value of 1.50.



5. Getting Started

a.) Before unpacking the optical pumping apparatus you will need to find a good place to set up your instrument.

Magnetic Environment: You need a location with relatively uniform DC magnetic fields. It should be well away (several feet) from any iron (steel tables, shelves, radiators etc.) or other magnetic material. You will also need to align the optical axis of the instrument along the horizontal component of the Earth's Magnetic field. You will also need a non-magnetic table on which to place the instrument. AC Magnetic fields at the power line frequency (50/60Hz.) will also effect the performance of the instrument. AC magnetic fields are believed to limit the low field line width, and large AC fields can lead to strange line shapes.

<u>Room lights:</u> It is useful (though not essential) to be able to dim or turn off the room lights during some of the optical alignment. TeachSpin does provide a black cloth to cover the optics while taking data, however a little stray light always does seem to get into the detector. This can be particularly annoying when there are large changes in the ambient light level.

<u>Thermal Environment</u>: DC drifts in the signal level are due in large part to temperature changes in the lamp and experimental cell. Though both the lamp and cell are in regulated ovens, changes in the ambient temperature will invariably lead to drifts in the signal level.

- b.) Once you have selected a site for your instrument, remove it from the box. Place the experiment platform on the table and align the optical axis with the Earth's magnetic field. (you will need a compass for this). Place the Electronics box several feet away from the experiment platform. (AC magnetic fields from the power supply transforms will affect the line widths)
- c.) Before you start to place the optics on the rail, you will need to remove two pieces of shipping foam from inside the cell oven. With a small flat blade screw driver remove the three screws that hold the end caps onto each end of the cell oven. Place the end caps aside. Inside each side of the cell oven you will see a white doughnut shaped (annulus) piece of foam insulation and a black piece of shipping foam. Leave the white doughnut pieces in place. Remove the black shipping foam piece from each side of the oven.

On one side of the oven you will see the thermocouple temperature sensor covered with black heat shrink tubing. The Thermocouple wire is only 5 µm in diameter and very delicate. In the center of the oven you will see the experimental cell held in place by a white foam support. You should confirm that the cell is still in the center of the oven. If you need to move the cell push gently on the foam support, make sure that the cylindrical cell does not become tilted in the support. If for some reason you need to replace or change the cell, remove the cell and the foam support together. Push gently from the side with the thermocouple towards the side without the thermocouple. Once the cell is properly placed in the center of the oven, make sure that the thermocouple is touching or at least close to the experimental cell. For an accurate measure of the cell temperature you do not want the thermocouple to be touching the heater element. Now replace the white doughnut shaped foam pieces of insulation and then the end caps.

If you think you would find it easier to work on the cell oven if it was not between the magnet coils, you may remove the cell oven as follows: Remove the black anodized (1/2 "diameter 5.94" long) spacer from the top of the Horizontal magnet coils. It is held in place by two ¼-20 brass screws. Remove the cable tie downs from the wooden base, so that you can get some slack in the heater and RF cables. Loosen the nylon screws that hold the Cell Oven to the optical rail and then remove the Cell Oven from between the magnet coils. Be careful feeding the cable between the coils. Follow these steps in reverse to put the Cell Oven back on the rail.

- **d.)** Placing Optics: Note that the magnet coils are not located in the center (wrt length) of the optical rail. The long part of the optical rail is for the Lamp and it's associated optics. The experimental cell is centered 3.5" above the optical rail. (See Figure 2D-1) in Apparatus)
 - 1) Place the Lamp near the end of the long section of optical rail. Adjust the height of the lamp such that the bulb is centered 3.5^{n^2} above the rail.
 - 2) Place the 50mm plano-convex lens after the lamp, with the flat side facing the lamp and with the distance between the lamp bulb and the center of the lens equal to about 50 mm. (This placement is not crucial and we will adjust the lens position for maximum signal later)
 - 3) Place the Interference filter with the reflecting side towards the lamp.
 - 4) Place the Linear Polarizer after the interference filter with axis of the polarizer at 45° (The alignment mark on the holder indicates the direction of the axis).
 - 5) Adjust the ¼ wave plate so that its axis is at 0° and place it after the Linear Polarizer.

² A standard business card is 3.5" in length which we use for quick alignment.

¹ The heater element is the glass cylinder in which the cell and it's foam support slide.



- 6) On the other side of the Magnet coils place the remaining plano-convex lens (curved side towards the cell) and then the detector. Set the height of the detector so that the diode is centered 3.5" above the rail.
- e.) Connect the Electronics. You now need to make the following connections.
 - 1.) Plug Lamp power into back panel connector
 - 2.) Plug blue Thermocouple into lower front panel and blue heater banana plugs.
 - 3.) Plug Black plastic Pre-amp power and Detector BNC into lower front panel.
 - 4.) Plug in Vertical Field banana plugs into lower front panel. (red plug in red jack)³
 - 5.) Plug the Horizontal Sweep Field banana plugs into the lower front panel. The horizontal fields are wired such that if the red plug is in the red jack the field will point in the direction of the light, (from the lamp to the detector). If you have oriented the experimental platform such that the lamp is on the south end then put the red plug in the red jack. Don't worry about this too much, simply plug it in and if you don't see the zero field transition then reverse the plugs. At this point you do not have to connect the Horizontal field. If you do connect it make sure that the current is set to zero

Turn on the power switch on the back panel power entry module. After a few seconds of setup the temperature regulator will display the cell temperature. Check that the set point of the regulator is 50°C. Push the SCROLL key twice. SP will be displayed for 1.5 seconds and then the value of the set point will be displayed. If the value is not 50°C then push the UP or DOWN keys till it is. Push the SCROLL key twice again. PROC will be displayed for 1.5 seconds and then the current temperature. If you have question please refer to the Temperature section of the Apparatus or the controller manual.

- f.) The lamp should turn on after a few minutes of warm up. You will see a purplish pinkish glow. The Lamp and the Cell Oven will take 10-20 minutes to thermally stabilize.
- g.) Optical alignment. You will now adjust the optics for a maximum signal. It is best if you turn off the room lights for this alignment, but leave enough light so that you can see what you are doing and also observe the detector meter. Set the preamp gain for $10M\Omega$ (toggle switch on preamp in middle position). On the Detector Amplifier set the Gain = 1, Gain Mult. = x1, Time Constant = 100ms, Meter Multiplier = x1, and DC Offset = 0. There should be a signal on the meter. Use a card to block the lamp and make sure this signal is from the lamp and not the room lights. If the signal is off scale change the meter multiplier to x2. If the signal is still off scale then you are probably saturating the preamp and you will need to change the preamp gain to $3M\Omega$ (toggle switch in up position).
- h.) You have set the Detector and Lamp height equal to the experimental Cell height.

 Maximizing the optical signal is now only a matter of adjusting the height of the two lenses and the spacing between the first lenses and the Lamp and the second lens and the

³ This assumes you live in the Northern Hemisphere.

Detector. Loosen the nylon thumb screw on the side of the optical carriers to move the lenses along the optical rail. Loosen the nylon thumb screw on the side of the support holder to adjust the height of the lenses. Watch the meter on the Detector Amplifier while you do this and maximize the signal. If you are a perfectionist you can use the gain and DC offset control to zoom in on the maximum signal. The Lamp bulb is not always perfectly centered over the optical rail and you may find that slightly rotating the first lens about the vertical axis will steer the beam back to the center of the Cell and give you a little more signal.

i.) Zero Field Transition. Having maximized the DC signal, we are now ready to find the zero field signal. The purpose is to adjust the horizontal and vertical coils so that the magnetic field at the cell is zero. We take care of the third component of the local field by aligning the instrument so that the axis is parallel with the local field.

It is very useful (though not necessary) to have an X-Y storage oscilloscope for this experiment. Make sure that there is no RF on the RF coils by unplugging the coils from the RF amplifier. Make sure the main Horizontal filed is either set to zero or unplugged. Cover the optics with the black cloth. Adjust the DC offset so that the meter reads zero and turn up the gain to 20. You can adjust the gain as necessary if you have too much or too little signal. You may also have to adjust the DC offset if the signal drifts out of range.

We find that the cell can take along time to thermally equilibrate within the oven. The simple act of placing the cloth over the instrument is enough to temporarily change the temperature and cause a DC drift. Using a compass approximately align the instrument with the local field. Set the vertical field current to 0.33 A (3.3 on the dial). If you are using a X-Y storage scope attach the Y axis to the Detector output and the X-axis to the Horizontal Sweep field Recorder Output and turn the Recorder offset to zero (full CCW). Set the Y-axis gain to 0.5 V/div and the X-axis to 1.0 V/div. Make sure that both inputs are DC coupled. Now on the Horizontal Sweep Field control put the Start/Reset toggle to Reset and starting from zero slowly increase the horizontal sweep field by turning the Start Field potentiometer.

You expect to see a broad dip in the transmitted light signal. In Buffalo, NY this dip is centered at a current of about 0.3 Amperes (Dial reading of 3.0). If you see no dip, try reversing the polarity of the Horizontal Sweep field (reverse the banana plugs). Then try changing the Vertical field. Turn the potentiometer one turn and try sweeping the horizontal field again. It is not inconceivable (if you are in a building with a lot of steel) that the local vertical field is in the opposite direction, try reversing the polarity of the vertical field. If all else fails do not hesitate to contact TeachSpin. We will be happy to help you.

⁴ This is the approximate setting to cancel the vertical component of the Earth's Field in Buffalo, NY. USA. If you are further north you may need to a larger current and further south a smaller current. Of course it is really the local field that you must cancel out and the building you are in may make much more of a difference than your latitude.

j.) Once you have found the dip, you will adjust the vertical field and position of the experimental platform for a minimum width. The easiest way to do this is to adjust the field to the side of the dip (using the Start Field control) and then adjusting both the vertical field and the angle platform for a maximum signal. You will have to adjust the oscilloscope gain and offsets during this iterative process. For the X-axis offset you can use the recorder offset On the Horizontal Field Sweep control to keep the signal centered.

When you have finally finished aligning the magnetic fields you should find that the zero field transition corresponds to an intensity change of about 2% of the DC signal and that it has a line width of about 3 mG (30 μ T) (The gain of the recorder output has been set so that 50mV ≈ 1 mG (10 μ T).

You are now ready to do other experiments turn to section 4.


⁵ There might be some confusion about what is meant by maximum signal. When you sweep through the zero field signal the dip corresponds to less light getting to the detector. This is a minimum signal. When sitting on the side of the dip and looking for a maximum signal, that is more light going to the detector.


PID Tuning Parameters versus Temperature

Temperature °C	Proportional Band Pb	Reset rSEt	Rate rAtE
30	6.2	13.28	2.14
40	5.3	9.52	1.38
50	4.4	8.14	1.22
60	3.7	6.32	1.05
70	3.0	5.17	0.52
80	2.5	4.09	0.35
90	2.0	3.35	0.35
100	1.7	3.12	0.32
110	1.2	2.31	0.25

The units for the reset and rate are xx.yy where xx are in minutes and yy are seconds. It should be noted that the Gain is inversely proportional the Proportional Band. If you express both the rate and reset in seconds then you can show that there exists the following relationships between the parameters; reset/PB ≈ 110 and reset/rate ≈ 6.04

PHOTONIC Silicon Photodiode, Blue Enhanced Photoconductive Type PDB-C108 DETECTORS INC.





FEATURES

- High speed
- Low capacitance
- Blue enhanced
- Low dark current

DESCRIPTION

The PDB-C108 is a silicon, PIN planar diffused, blue enhanced photodiode. Ideal for high speed photoconductive applications. Packaged in a hermetic TO-8 metal can with a flat window.

APPLICATIONS


- Instrumentation
- Industrial controls
- Photoelectric switches
- Flame sensors

ABSOLUTE MAXIMUM RATING (TA=25°C unless otherwise noted)

SYMBOL	E FARAMETERAL	* MIN	MAX	-UNITS
VBR	Reverse Voltage		100	<u> </u>
T _{sts}	Storage Temperature	-55	+150	°C
То	Operating Temperature Range	-40	+125	%
Ts	Soldering Temperature*		+240	°C
ار	Light Current		0.5	mA

^{*1/16} inch from case for 3 secs max

SPECTRAL RESPONSE



ELECTRO-OPTICAL CHARACTERISTICS (TA=25°C unless otherwise noted)

SYMBOL	CHARACTERISTIC	TEST CONDITIONS	MIN	TYP	MAX	UNITS
lsc	Short Circuit Current	H = 100 fc, 2850 K	400	460		μΑ
lρ	Dark Current	H = 0, VR = 10 V		5	15	nA
Rsн	Shunt Resistance	H = 0, VR = 10 mV	65	120		MΩ
. TC RsH	Rsн Temp. Coefficient	H = 0, VR = 10 mV		-8		%/°C ·
C¹	Junction Capacitance	H = 0, VR = 10 V**		75		pF
Arange	Spectral Application Range	Spot Scan	350		1100	nn
λρ	Spectral Response - Peak	Spot Scan		950		nm
VBR	Breakdown Voltage	I = 10 μA	100	125		V
NEP	Noise Equivalent Power	Vr.= 10 V @ Peak	-	8x10 ⁻¹³		W/ √ Hz
tr	Response Time	RL = 1 KΩ V _R = 50 V		20		nS

Information in this technical data sheet is believed to be correct and reliable. However, no responsibility is assumed for possible inaccuracies or omission. Specifications are subject to change without notice. **f = 1 MHz (FORM NO. 100-PDB-C108 REV B)



Instruments Designed for Teaching

WARRANTY-USA

Do not attempt to repair this instrument while under warranty

TeachSpin, Inc. is proud of the quality and workmanship of its teaching apparatus. We offer a warranty which is unique in the industry because we are confident of the reliability of our instruments.

This instrument is warranted for a period of **two (2) years** from the date the instrument is delivered. TeachSpin will pay for all labor and parts to repair the instrument to new working specification, when the breakdown is due to defects in components, workmanship or ordinary use.

TeachSpin will pay all shipping costs required for one year of the warranty and the owners will be responsible for all shipping costs for year two of the warranty contract.

This warranty is void under the following circumstances:

- a) Instrument has been dropped, mutilated, or damaged by impact or extreme heat.
- b) Repairs or attempted repairs not authorized by TeachSpin, Inc. have been done to the unit.
- c) Instrument has been subjected to high voltages, plugged into excess AC voltages or otherwise electrically abused.
- d) Instrument has been dropped or damaged by impact or extreme heat.

TeachSpin, Inc. makes no expressed warranty other than the warranty set forth herein, and all implied warranties are excluded. TeachSpin, Inc.'s liability for any defective product is limited to the repair or replacement of the product at our discretion.

TeachSpin, Inc. shall not be liable for:

- 1) Damage to other properties caused by any defects, for damages caused by inconvenience, loss of use of the product, commercial loss, or loss of teaching time.
- 2) Damage caused by operating the unit, without regard to explicit instructions in the TeachSpin manual.
- 3) Any other damages, whether incidental, consequential or otherwise.

This manual is intended for use in support of installation, commissioning and configuration of the 1/32-DIN Temperature Controller.

The procedures described in this manual should be undertaken only by personnel competent and authorized to do so.

TEMPERATURE CONTROLLER MANUAL

TEACHSPIN, INC. 45 PENHURST PARK BUFFALO NY 14222 716-885-4701

CAUTION: Read This Manual!!



THE INTERNATIONAL HAZARD SYMBOL IS INSCRIBED ADJACENT TO THE REAR CONNECTION TERMINALS. IT IS IMPORTANT TO READ THIS MANUAL BEFORE INSTALLING OR COMMISSIONING THE UNIT.

Table of Contents

Section 1 - Installation - Panel-Mounting	Pag
1.1 Unpacking the Instrument	5
1.2 Installing the Controller in the Mounting Panel	6
Section 2 - Installation - Wiring Connections	1.
2.1 Mains (Line) Supply	8
2.2 Low Voltage (24V AC/DC) Supply - Option 2.3 Thermocouple Input	8 9
2.4 RTD Inputs	. 9
2.5 DC Inputs	9
2.6 Relay Outputs (Output 2 & Output 3)	9
2.7 dc Pulse Output (Output 1)	10
2.8 RS485 Communications	10
Section 3 - Front Panel	
3.1 Indicators	11
3.2 Keys	. 11
Section 4 - Instrument Configuration	
4.1 Entry into Instrument Configuration Mode	13
4.2 Parameter Sequence	13
4.3 Exit from Instrument Configuration Mode	18
Section 5 - Operation Mode	
5.1 Normal Operation (Yellow LED OFF)	20
Section 6 - Control Setup (Yellow LED ON)	
6.1 Adjustment Ranges	23
6.2 Default Values/Settings	23
Section 7 - Calibration Mode	
7.1 Prerequisites	24
7.2 Entry into Calibration Mode	25
7.3 Calibration Procedure	26
7.4 Exiting Calibration Mode	27

A - Product Specification	•	26
B - Order Matrix		31

Figures & Tables

Figure 1-1	Main Dimensions	5
Figure 1-2	Panel Cut-out Dimensions	. 5
Figure 2-1	Rear Terminal Connections	7
Figure 2-2	Mains (Line) Supply Connections	- 8
Figure 2-3	Low Voltage AC/DC Supply Connections	9
Figure 2-4	RS485 Line Termination	10
Table 4-1	Sensor Selection Codes	17
Table 4-2	Output Selection Codes	17

Installation - Panel-Mounting

1.1 UNPACKING THE INSTRUMENT

- 1. Remove the Controller from its packing. A panel gasket and a "no tools required" fixing strap are supplied. Retain the packing for future use (e.g. moving the Controller to a different site).
- 2. Examine the delivered items for damage or deficiencies. If any is found, notify the carrier immediately. Check that the Product Code on the label affixed to the Controller housing corresponds to that ordered.




FIGURE 1-1 M






FIGURE 1-2 Panel Cut-out Dimensions

1.2 INSTALLING THE CONTROLLER IN THE MOUNTING PANEL CAUTION: Do not remove the front panel gasket from the Controller, as this may cause inadequate clamping of the Controller to the mounting panel. Ensure that this gasket is not distorted and that the Controller is positioned squarely against the mounting panel. Apply pressure to the front panel bezel only.





Installation - Wiring Connections




FIGURE 2-1 Rear Terminal Connections

	Function (see Table 4-2)					
Output	Control Output	Alarm 1	Alarm 2	RS485 Comms.		
Output 1	*	*				
Output 2a 3	*	*				
Output 2b 3	*	*				
Output 3 3			*	*		

2.1 MAINS (LINE) SUPPLY

This version of the Controller will operate on a 96 - 264V AC 50/60Hz mains (line) supply. The power consumption is approximately 4W.

CAUTION: This equipment is designed for installation in an enclosure which provides adequate protection against electric shock. Local regulations regarding electrical installation should be rigidly observed. Consideration should be given to prevention of access to the power terminations by unauthorized personnel. Power should be connected via a two-pole isolating switch (preferably situated near the Controller) and a 1A fuse, as shown in Figure 2-2.




FIGURE 2-2 Mains (Line) Supply Connections

If the contacts of the relay output(s) are used to carry mains (line) voltage, it is recommended that the relay contacts mains (line) supply should be switched and fused in a similar manner but should be separate from the Controller mains (line) supply.

2.2 LOW VOLTAGE (24V AC/DC) SUPPLY - OPTION

This version of the Controller will operate on 12 - 24V AC 50/60Hz or 12 - 30V DC supply. The power consumption is approximately 4W. The connections are shown in Figure 2-3; these should be made via a two-pole isolating switch and a 315mA slow-blow (anti-surge Type T) fuse.




FIGURE 2-3 Low Voltage AC/DC Supply Connections

2.3 THERMOCOUPLE INPUT

The correct type of thermocouple extension leadwire or compensating cable must be used for the full distance between the Controller and the thermocouple, ensuring that the correct polarity is observed throughout. Joints in the cable should be avoided, if possible.

NOTE: Do not run the thermocouple cables adjacent to power-carrying conductors. If the wiring is run in a conduit, use a separate conduit for the thermocouple wiring. If the thermocouple is grounded, this must be done at one point only. If the thermocouple extension lead is shielded, the shield must be grounded at one point only.

2.4 RTD INPUTS

The compensating lead should be connected to Terminal 3. For two-wire RTD inputs, Terminals 2 and 3 should be linked. The extension leads should be of copper and the resistance of the wires connecting the resistance element should not exceed 5 ohms per lead (the leads should be of equal length).

2.5 DC INPUTS

DC (mV) inputs are connected to Terminals 2 and 3 in the polarity shown in Figure 2-1; DC (V) inputs are connected to the same terminals with the same polarity but require an external attenuator. DC (mA) inputs are connected to Terminals 3 and 4 in the polarity shown in Figure 2-1 with Terminals 2 and 4 linked externally.

2.6 RELAY OUTPUTS (OUTPUT 2 & OUTPUT 3)

The contacts are rated at 2A resistive at 120/240V AC.

2.7 dc PULSE OUTPUT (OUTPUT 1)

This output produces a time-proportioned non-isolated DC signal (0 or 10V nominal, into 500Ω minimum).

2.8 RS485 COMMUNICATIONS

The "A" terminal (Terminal 12) on the Controller should be connected to the "A" terminal on the master device; the "B" terminal (Terminal 11) on the Controller should be connected to the "B" terminal on the master device. This instrument uses standard RS485 devices, isolated from all other inputs and outputs. The devices present a 1/4-unit load to the RS485 line. Generally, termination will not be required but may be necessary for line lengths greater than 100 metres. Where termination is necessary, it is recommended that a 120Ω resistance in series with a $0.1\mu F$ capacitor be used at each end of the line (see Figure 2-4).





FIGURE 2-4 RS485 Line Termination

Front Panel

3.1 INDICATORS



3.2 KEYS




Scroll key All Modes except Calibration:

If parameter value displayed, shows parameter legend (for 1.5 seconds). If legend displayed, shows value of next parameter.

Calibration:

Starts calibration phase.



Down key

Normal Operation:

Decrements parameter value. With process variable displayed, dis-engages Pre-Tune*. Also confirms request for entry into *Instrument Configuration*.

Control Setup/Instrument Configuration:

Decrements parameter value.

Calibrations

Steps to previous calibration phase.



Up key

Normal Operation:

Decrements parameter value, With process variable displayed, requests Pre-Tune*.

Control Setup/Instrument Configuration: Decrements parameter value.

Calibration:

Steps to next calibration phase.



Scroll & Down keys

Normal Operation:

Enters Calibration.



Scroll & Up keys

Normal Operation:

Requests entry into Instrument Configuration.



Down & Up keys

Normal Operation:


Enters Control Setup.

Control Setup/Instrument Configuration/Calibration: Returns to Normal Operation.

Instrument Configuration

4.1 ENTRY INTO INSTRUMENT CONFIGURATION MODE


1. Hold down Scroll and Up keys simultaneously until the display begins to flash.



2. When display begins to flash, release the Scroll and up keys and press the Down key.


4.2 PARAMETER SEQUENCE

The Scroll key is used to step through the parameters in the following manner:



The parameter sequence is as follows:

Scroll key steps through displays; Up/Down keys adjust displayed values.



- 1. Appears only if sensor selected is DC (mA, Mv or V).
- 2. Appears only if Comms. configured and fitted.
- 3. Appears only if Output 3 configured and fitted.
- 4. Appears only if PID control is configured.

4.2.1 Adjustment Ranges

Parameter	Function	Adjustment Range	
Sensor Select	Selects input sensor type, resolution and input units (°F or °C) by means of a code number.	See Table 4-1	
Input Range Minimum	Defines minimum value of input range	Thermocouple/RTD inputs: Range Min. value for selected sensor (see Table 4-1) to 100 LSDs less than current input Range Max. setting. DC inputs: —1999 to 9999 with decimal point set according to Input Range Decimal Point Position parameter.	
Input Range Maximum	Defines maximum value of input range	Thermocouple/RTD inputs: 100 LSDs greater that current input Range Min. setting to Range Max. for selected sensor (see Table 4-1). DC inputs: -1999 to 9999 with decimal point set according to input Range Decimal Point Position parameter.	
Input Range Decimal Point Position	For DC inputs only, defines decimal point position	0 (xxxx), 1 (xxxx), 2 (xxxx) or 3 (xxxx)	
Output Selection	Links outputs to functions required by a 3-digit code (see Table 4-2)		
Communications Address	Defines unique communications address of Controller	1 to 128	
Communications Baud Rate	Selects Baud rate for serial communications	1200 Baud 2400 Baud 4800 Baud 9600 Baud	
Communications Parity	Defines parity for serial communications	Odd parity EuEn Even parity No parity	
Single/Dual Setpoint Select	Selects Single Setpoint or Dual Setpoint operation	Single setpoint Dual setpoint	

Continued on next page

Continued from previous page

Parameter	Function		Adjustment Range
Alarm 1 Type	Selects type of alarm for Alarm 1	PHd	Process High, direct-acting
		PLd	Process Low, direct-acting
		dEd_	Deviation, direct-acting
		ЬЯ₫∞	Band, direct-acting
,		PHE	Process High, reverse-acting
	9	PLC	Process Low, reverse-acting
		dEr_	Deviation, reverse-acting
		ЬЯг∴	Band, reverse-acting
Alarm 2 Type	Selects type of alarm for Alarm 2	As for Alam	n 1 Type.
Control Select	Selects the control action and	r_P	Reverse-acting PID
	algorithm	d_P	Direct-acting PiD
		,r_0	Reverse-acting On/Off
		d_o	Direct-acting On/Off
Tuning Select	Selects Manual Tuning or	ER54	Easy Tune
	Hands-off Tuning (Easy Tune)	rnAn	Manual Tuning (with Pre-Tune available)

TABLE 4-1 Sensor Selection Codes

g jilo	Co	de	[
Input Type	°C	°F	Range Min. (°C)	Range Max. (°C)	Range Min. (°F)	Range Max. (°F)
T/C-J	100 110	101 111	-200 -128.0	1200 537.0	-328 -198.4	2191 998.5
T/C-T	200 210	201 211	-240 -128.0	401 400.6	-400 -198.4	753 753.0
T/C-K	300 310	301 311	-240 -128.0	1371 536.7	-400 -198.4	2499 998.0
T/C - N	. 400	401	0	1399	32	2550
T/C - B	500	501	್ಷ 100	1824	211	3315
T/C-R	600	601	0	1759	.32	3198
T/C-S	700	701	0	1770	32	3217
RTD .	800 810	801 811	-199 -127.9	802 537.0	-327 -198.3	1475 998.5

DC Linear Input Type	Code	Range Min.	Range Max.
0 - 20mA	900	-1999	9999
4 - 20mA	1000	1999	9999
0 - 50mV	2000	-1999	9999
10 - 50mV	3000	-1999	9999

TABLE 4-2 Output Selection Codes




Proc	ess Output	Alar	m 1 Output		Option
Code	Meaning	⊴Còde	Meaning.	Code	Meaning 💉
0	Not fitted	0	Not fitted	0	Not fitted
1	Relay	1	Relay	1	Second Relay Output fitted
2	dc Pulse	2	dc Pulse	2	Comms. (MODBUS) fitted

4.2.2 DEFAULT VALUES

Parameter	Default Value		
Sensor Select	100 - Thermocouple Type J (-200 to 1200°C)		
Input Range Minimum	For Thermocouple/RTD Input: Input Range Minimum For DC Linear Input: 0		
Input Range Maximum	For Thermocouple/HTD input: input Range Maximum For DC Linear input: 1000		
Input Range Decimal Point Position	0		
Output Selection	021 - Relay control output, SSR Drive, no option		
Communications Address	1		
Communications Baud Rate	4800		
Communications Parity	None		
Single/Dual Setpoint Select	1 - Single Setpoint operation		
Alarm 1 Type	Process High Alarm		
Alarm 2 Type	Process Low Alarm		
Control Select	Reverse-acting PID control		
Tuning Select	Easy Tune		

4.3 EXIT FROM INSTRUMENT CONFIGURATION MODE


To exit from Instrument Configuration Mode:



The instrument will then return to Normal Operation Mode via an instrument reset and self-test sequence.

NOTE: If there is no key activity for five minutes in Instrument Configuration Mode, an automatic return is made to Normal Operation Mode (via an instrument reset and self-test sequence).

Operation Mode



INDICATORS

Green: OFF

- Process Variable less than Setpoint

ON

- Process Variable equals Setpoint

Flashing - Process Varible greater than Setpoint

Yellow:

OFF ON


Normal OperationControl Setup

Red:


Flashing - Alarm(s) active

5.1 NORMAL OPERATION (Yellow LED OFF)

In this mode, the display normally shows the process variable value. Use the Scroll key to step through a sequence of parameters as follows:



The following parameters are available in Normal Operation.



5.1.1 EASY TUNE

If the Controller has been configured for Easy Tune operation, all tuning is executed automatically; no operator action is required.

5.2.2 MANUAL TUNING WITH PRE-TUNE

When the Controller is configured for Manual Tuning, the Pre-Tune facility is available. Pre-Tune is used to optimise system start-up (normally after power-up or after a major change to the process being controlled). To activate Pre-Tune:

1. Select the Process Variable display.



This decimal point indicator will flash whilst Pre-Tune is active.

2. Press the Up key.

NOTE: Pre-Tune cannot be activated if the Process Variable is within 5% of input span from the setpoint.

To dis-engage Pre-Tune:

1. Select the Process Variable display.




2. Press the Down key.

NOTE: Pre-Tune is a single-shot operation and, therefore, when it is completed, Pre-Tune will dis-engage itself automatically.

Control Setup (Yellow LED ON)

To enter Control Setup mode, press the Up and Down keys simultaneously for more than three seconds. The same key action exits this mode. The parameters are as follows:



6.1 ADJUSTMENT RANGES

Parameter	Adjustment Range			
Setpoint(s)	Input Range Min. to Input Range Max. NOTE: Negative values limited by display to -1999			
Proportional Band_	1.0% to 999.9% (0.1% increments)			
Reset	1 sec. to 99 min. 59 sec. and OFF (> 99min. 59 secs.)			
Rate	0 (OFF) to 99 min. 59 sec.			
Bias (Manual Reset)	0% to 100%			
ON/OFF Hysteresis	0.1% to 10.0% of input span			
Alarm (1 & 2) level	Process High: Input Range Min. to Input Range Max. Process Low: Input Range Min. to Input Range Max. Deviation (High or Low): –(input span) to + (input span) Band: 1 LSD to Input Span NOTE: Negative values limited by display to –1999			
Input Filter Time Constant	Osec. to 100sec.			
Input Offset	± input span NOTE: Negative values limited by display to -1999			
Output Cycle Time	0.5 (SSR only), 1, 2, 4, 8, 16, 32, 64, 128, 256 & 512 sec.			
Setpoint Lock	adjustment enabled in Normal Operation adjustment disabled in Normal Operation			
Alarm Value Display Enable/Disable	Enfb display/adjustment enabled in Normal Operation a SH display/adjustment disabled in Normal Operation			

6.2 DEFAULT VALUES/SETTINGS

Parameter	Default Value/Setting		
Setpoint(s)	Input Range Min.		
Proportional Band	10.0%		
Reset	5 minutes		
Rate	1 minute 15 seconds		
Bias (Manual Reset)	25%		
ON/OFF Hysteresis	0.5% of input span		
Alarm (1 & 2) level	Alarm 1 Process High: Input Range Max. Alarm 2 Process Low: Input Range Min.		
Input Filter Time Constant	2 seconds		
Input Offset	0		
Output Cycle Time	16 seconds		
Setpoint Lock	(adjustment enabled)		
Alarm Value Display Enable/Disable	Enflb (enabled)		

Calibration Mode

The Controller is shipped from the factory ready-calibrated and normally does not need further calibration. However, some users may have a legal requirement for annual calibration. The procedures set out in this Section serve that purpose.

7.1 PREREQUISITES

The Calibration Mode has four phases. In addition to the Controller to be calibrated, each phase requires the appropriate input to be fitted before that phase is executed. These prerequisites are shown in the box below.

NOTE: These procedures should be implemented only by personnel competent and authorized to do so.

CALIBRATION PREREQUISITES

Phase 1 - DC mV Linear Input:

50mV DC across Terminals 2 & 3 in the

polarity shown in Figure 2-1.

Phase 2 - RTD Input:

200W across Terminals 1 & 2 with com-

pensating lead connected to Terminal 3.

Phase 3 - DC mA Input:

20mA current source connected to Termi-

nals 3 & 4 in the polarity shown in Figure

2-1.

Phase 4 - Thermocouple Input/CJC:

0°C reference facility, Type K thermo-

couple leads (or equivalent) connected to


Terminals 2 & 3.

7.2 Entry into Calibration Mode

To enter Calibration Mode:

1. Power-down the Controller.

2. Power-up the Controller.



3. As the first key action after power-up, hold down the Scroll and Down keys for at least six seconds.


The Controller will then enter the Calibration Mode and will display:



indicating that the first calibration phase is ready to be executed.


7.3 Calibration Procedure

- Use Up key (step forward) or Down key (step backward) to select required phase.
- Use Scroll key to start selected phase.
- If FAIL displayed, use Up or Down key to return to start of failed phase.



7.4 EXITING CALIBRATION MODE

To exit Calibration Mode:



The Controller will then return to Normal Operation Mode

NOTE: If there is no key activity for five minutes in Calibration Mode, an automatic return is made to Normal Operation Mode.

Appendix A Product Specification

UNIVERSAL INPUT

Sample Rate:

4 samples/second

Digital Filter:

Filter time constant selectable from front panel. Adjust-

ment range 0.0 to 100.0 seconds in 0.5 second

increments.

Input Resolution:

14-bit resolution approximately. Always at least four

times better than the display resolution.

Input Impedance:

 $>10M\Omega$ resistive.

Isolation:

240V ac isolation from all outputs except dc Pulse.

Input Offset:

Adjustable ± input span, subject to display limit on

negative values (-1999).

Thermocouple Input

Ranges selectable from the front panel are:

			_		Code	
Input Type	Range Min. (°C)	Range Max. (°C)	Range Min. (°F)	Range Max. (°F)	°C	°F
J	-200 -128.0	1200 537.0	-328 -198.4	2191 998.5	100 110	101 111
Ţ	-240 -128.0	401 400.6	-400 -198.4	753 753.0	200 210	201 211
К	-240 -128.0	1371 536.7	-400 -198.4	2499 998.0	300 310	301 311
. N .	0	1399	32	2550	400	401
В	100	1824	211	3315	500	501
R	0	1759	32	3198	600	601
S	0	1760	32	3217	700	701_

Calibration:

Complies with BS4937, NBS125 and IEC584.

Sensor Break Detection:

Break detected within two seconds.

RTD Input

Ranges selectable from the front panel are:

·	:		<u> </u>	Co	de
Range Min. (°C)	Range Max. (°C)	Range Min. (°F)	Range Max. (°F)	°C	°F
-199	802	-327	1475	800	801
-127.9	537.0	-198.3	998.5	810	811

Type and Connection:

Three-wire Pt100.

Calibration:

Complies with BS1904 and DIN43760.

Lead Compensation:

Automatic scheme.

RTD Sensor Current:

150µA approximately.

Sensor Break detection:

Break detected within two seconds.

DC Input

Ranges selectable from the front panel are:

Input Type	Range Min.	Range Max.	Code
0 - 20mA	-1999	9999	900
4 - 20mA	-1999	9999	1000
0 - 50mV	-1999	9999	2000
10 - 50mV	-1999	9999	3000

OUTPUTS

Output 1 - dc Pulse (Standard)

Usage:

Selectable - may be used as Control Output

or Alarm 1 Output.

Drive Capability:

>10Vdc into 500 Ω minimum (50mA

maximum).

Isolation:

Not isolated from input.

Output 2 - Relay (Standard)

Usage:

Selectable - may be used as Control Output

or Alarm 1 Output.

Contact Type:

Single pole, single throw (SPST).

Rating:

2A resistive at 120/240V ac.

Life:

>500,000 operations at rated voltage &

current.

Isolation:

Inherent.

Output 3 - Relay or Communications (Options)

Relay Output

Usage:

Selectable - may be used as Alarm 2.

Contact Type:

Single pole, single throw (SPST).

Rating:

2A resistive at 120/240V ac.

Life:

>500,000 operations at rated voltage &

current.

Isolation:

Inherent.

Communications Port

Type:

Serial Asynchronous UART-to-UART link.

Data Format:

1 start bit, selectable parity (odd, even or

none), 8 data bits, 1 stop bit.

Physical Layer:

RS485 (two-wire).

Transmitter Drive Capability:

32 standard RS485 unit loads.

Receiver Bus Loading:

0.25 standard RS485 unit load.

Presentation Layer:

MODBUS RTU protocol.

Maximum Number of Zones: 128.

Baud Rate:

Selectable from front panel in the range

9600, 4800, 2400 and 1200.

Zone Address Range:

1 to 128.

LOOP CONTROL

Control Algorithms:

Direct/reverse-acting PID or On/Off.

Automatic Tuning Types:

Pre-Tune or Hands-OFF EASY TUNE.

Proportional Band:

0.5% to 999,9% at 0.1% resolution.

Reset

(Integral Time Constant):

1 second to 99 minutes 59 seconds and OFF

(greater than 99 minutes 59 seconds).

Rate

(Derivative Time Constant:

0 (OFF) to 9 minutes 59 seconds.

Bias (Manual Reset):

0 to 100%.

On/Off Hysteresis:

0.1% to 10.0% of input span.

Output Cycle Time:

Selectable from 0.5sec. (SSR Drive only), 1,

2, 4, 8, 16, 32, 64, 128, 256, 512 secs.

Setpoint Range:

Bounded by Input Range Maximum and Input

Range Minimum. Setpoint lockable.

ALARM CONTROL

Max. Number of Alarms:

Two, if two physical outputs are available.

Alarm Types-

Process High:

Input Range Minimum to Input Range

Maximum.

Process Low:

Input Range Minimum to Input Range

Maximum.

Deviation (High/Low):

±input span (negative values limited by dis-

play to -1999).

Band:

1 LSD to input span.

PERFORMANCE Reference Conditions

Generally as BS5558.

Ambient Temperature:

20°C±2°C.

Relative Humidity:

60 to 70% non-condensing.

Supply Voltage:

90 to 254V ac 50Hz æ 1%.

Source Resistance:

 $<10\Omega$ for thermocouple.

Lead Resistance:

 $<0.1\Omega$ /lead balanced (Pt100).

Performance Under Reference Conditions

Common Mode Rejection:

>120dB @ 50/60Hz giving negligible effect at

up to 264V at 50/60Hz.

Series Mode Rejection:

>500% of input span at 50/60Hz giving negli-

gible effect.

Thermocouple Inputs

0.1% of input span ±1 LSD typical (0,25% for Measurement Accuracy:

Types J and T). NOTE: Reduced performance

for Type B 100 to 600°C (and °F equivalent).

Better than ±0.2°C at any point for any 0.1°C Linearisation Accuracy:

range (±0.05°C typical).

Better than ±0.5°C at any point for any 1°C

range.

Cold Junction Compensation: Better than ±0.7°C.

RTD Inputs

±0.1% of input span ±1 LSD. Measurement Accuracy:

Better than ±0.2°C at any point for any 0.1°C Linearisation Accuracy:

range (±0.05°C typical).

Better than ±0.5°C at any point for any 1°C

range.

DC mA/mV Inputs

±0.1% of input span ±1 LSD. Measurement Accuracy:

Operating Conditions

Ambient Temperature

(Operating):

0°C to 55°C.

Ambient Temperature

(Storage):

-20°C to 80°C.

Relative Humidity:

20% to 95% non-condensing.

Supply Voltage:

90 to 264V ac 50/60Hz.

Source Resistance:

 1000Ω maximum (thermocouple).

Lead Resistance:

50Ω/lead maximum (Pt100).

Performance Under Operating Conditions:

Temperature Stability:

0.01% on input span/°C change in ambient temperature (RTD and DC mA/mV 0.005% of

span/°C).

Cold Junction Compensation: Better than ±1°C.

Supply voltage Influence:

Negligible.

Relative Humidity Influence:

Negligible.

Sensor Resistance Influence: Thermocouple 1000 Ω <0.1% of span error.

RTD Pt100 50Ω/lead <0.25% of span error.

ENVIRONMENTAL

Operating Conditions:

See PERFORMANCE.

EMI Immunity:

Complies with BS EN 50082 Parts 1 (1992)

and 2 (1995).

EMI Emissions:

Complies with BS EN 50081 Parts 1 (1992)

and 2 (1994).

Safety Considerations:

Complies with BS EN 61010 Part 1 (1993) in

so far as it applies.

Supply Voltage:

90 - 264V ac 50/60Hz (standard);

12 - 24V ac 50/60Hz or 12 - 30V dc (option).

Power Consumption:

4W maximum.

Front Panel Sealing:

To IP66 (similar to NEMA4).

PHYSICAL

Dimensions:

Behind-panel depth 100mm, Front face

25mm high x 49 mm wide.

Mounting:

Plug-in with panel-mounting sleeve. Panel

cutout 45mm x 22.5mm.

Terminals:

Screw type.

Weight:

100a.

WIDE BAND SIGNAL GENERATOR

Operation Wanual

CONTENTS

1.	SPECIFICATION
2.	OPERATION
3.	CURCUIT DIAGRAM

SPECIFICATION

Frequency Range

100KHz - 300KHz

B 300KHz - 1000KHz

C 1MHz - 3.2MHz

D 3.0MHz - 10MHz -

E 10MHz - 35MHz

F 32MHz - 150MHz

(up to 450MHz on third-harmonics)

Frequency Accuracy

: ±3%

RF Output

: 100mV, rms. Approx. (up to 35MHz)

Output Control

: HIGH-LOW switch and fine adjuster

Modulation

: Internal 1KHz

External 50Hz - 20KHz, at less than 1V. RMS.

Audio Output

: 1KHz, M IN. 1V. rms. (fixed)

Crystal Oscillator 4C-6/u

For 1 -15 MHz use crystall in Type HC-6u holder (not included)

holder

Power Requirement

: 110V or 220V AC 50Hz or 60Hz

Dimension & Weight

: 150(H) x 250(W) x 130(D)mm.

approx. 2.5kg.

1. FREQUENCY dial

Set the RF output frequency in the range selected by th

1. FREQUENCY dial

Set the RF output frequency in the range selected by the FREQ RANGE

switch.

2. FREQ RANGE switch

Has six positions for RF output frequency range.

3. XTAL socket

For insertion of quartz crystal, 1-15MHz, in Type HC-6/u holder.

4. PWR switch

For turning on the AC power.

5. PILOT lamp

Indicates when Ac power is on.

6.MODE switch

EXT MOD: For modulation of carrier with an external source.

INT MOD: Use of internal 1kHz for modulation of external circuit testing.

XTAL: Crystal oscillator output Frequency depends on crystal used.

7. INPUT-OUTPUT

For external modulation input or output from internal 1kHz oscillator.

8. FINE control.

Continuous RF output voltage adjuster.

9. RF LOW-HIGH switch

Sets the RF output level; at LOW, output is lowered by 10%.

10. OUTPUT terminals

For connection to RF output leads.

OPÉRATION

1. Preparation

- (1) Set the POWER switch at OFF.
- (2) Connect the AC plug to the AC supply.
- (3) Connect the RF output leads to OUTPUT terminals.
- (4) Set the FINE control at center and the RF slide switch at LOW.

 During the tests, this switch is set at LOW or HIGH as required.
- (5) Set the FREQ RANGE switch at the operating band and rotate the frequency dial knob to the desired frequency.

2. Connections

The RF leads are connected to the input of the circuit under test. The red terminal is at high potential, or "hot", and black is at earth potential for chassis connection.

For the RF signal at the receiver antenna input, connect a 50 to 2000 resistro, 1/4W, in series. When checking sets with a rod antenna, connect leads to a coil with a few turns of wire and couple the coil to the antenna.

In checking RF and IF amplifier circuits, connection should be made through a small capacitor, 1-5pF, in order to prevent detuning effects.

NOTE: When connecting directly to the input circuit, make certain the there is no high DC voltage present. Otherwise, connect a blocking capacitor, $0.05\mu F - 100pF$, depending on the frequency.

3

3. Modulated Carrier, Internal Source

Set the mode switch at INT. MOD.

By tuning the receiver to the generator frequency, or vice versa, an audio tone will be heard in the loudspeaker. An audio voltmeter should be connected across the speaker terminals when aligning the internal circuits. A dummy resistor with suitable power rating can be used in place of the moving coil.

It is advisable to keep the RF signal level as low as possible in order to prevent overloading the transistors or electron tubes in the circuit. Excessive input voltage will cause AGC action and/or two resonance points to appear and proper alignment or adjustment would be impossible.

4. Modulated Carrier, External Source

Set the mode switch at EXT. MOD.

Connect leads from an external audio generator to the INPUT.

Frequencies up to 15KHz can be used for modulation at RF above 3MHz. The audio input voltage should not exceed 2V; this is to prevent modulation distortion.


- (5) In the following example, use of a 1MHz crystal will be given.
- (6) Tune the receiver to 5MHz, or 5th harmonic of 1MHz. Then by carefully tuning both the oscillator and is adjusted to zero beat and the dial reading is noted. At other frequencies spaced 1MHz apart, the same procedure is repeated, namely, oscillator setting tuning the receiver retuning oscillator and noting the reading on the dial.

Practical use of harmonics up to the tenth or higher is possible. However, care must be exercised in selecting the proper harmonic, especially at high RF when a relatively low frequency crystal is used.

NOTE: When a receiver equipped with a best frequency oscillator is used the measurements can be simplified. The "zero-best" condition is at the point where the steady best is heard most clearly.

9. Exposing the chassis

REMOVE PLUG FROM POWER SOURCE.
LOOSEN TWO SCREWS AT FRONT PART OF TOP COVER.
REMOVE TWO SCREWS ON THE BOTTOM SIDE.
REMOVE ONE SCREW AT THE BACK.
TAKE OFF THE COVER.



CURCUIT DIAGRAM

