AM5450 Assignment 7

Q1)

Plots from MATLAB Code:




Fig 1: Contours of U and V displacements of the beam




Fig 2: Strain components ($\epsilon_{11},\,\epsilon_{11},\,\Upsilon_{12})$ for the deformed beam




Fig 3: Stress components (σ_{11} , σ_{22} , τ_{12}) for the deformed beam

Plots from ABAQUS Simulation:




Fig 4: Contours of U and V displacements of the beam




Fig 5: Strain components (E11, E22, E12) for the deformed beam




Fig 6: Stress components (S11, S22, S12) for the deformed beam

- The MATLAB code, excel sheet with mesh data from ABAQUS (Q1_Mesh) and tabulated comparison of displacement, strain and stress between the MATLAB code and ABAQUS (Q1_Comparison) are attached in the submission.
- The table below summarizes the percentage absolute error for all fields between the ABAQUS simulation and MATLAB Code which is calculated in the attached excel sheet.

Field	Absolute Mean % Error
U displacement	25.08
V displacement	39.33
S11	7.15
S22	14.2
S12	11.7
E11	7.37
E22	10.7
E12	11.7

Table 1: Percentage Error between MATLAB and ABAQUS results

Q2)

- The MATLAB code and mesh data from ABAQUS (Q2_Mesh) is attached to the submission.
- We consider only one fourth of the cylinder and apply symmetry boundary conditions at the ends. Following are the plots for the displacement, stress and strain in the cylinder obtained from the MATLAB code.




Fig 7: U and V displacements for the pressure vessel




Fig 8: Strain components (ϵ_{11} , ϵ_{11} , γ_{12}) for the deformed pressure vessel




Fig 9: Stress components (σ_{11} , σ_{22} , τ_{12}) for the deformed pressure vessel

- As we are using constant strain triangular elements (CST), the strain over each element is constant.
- We calculate the hoop stress as the maximum absolute value of the σ_{11} stress component in the domain and similarly the longitudinal stress is calculated as maximum absolute value of the σ_{22} .
- Using the theory of thin-walled cylindrical pressure vessels, we can calculate the hoop and longitudinal stresses as Pt/2d and Pt/4d respectively. Following is the code output which shows a comparison of both

```
The hoop stress calculated is 3511018.219436 N
The longitudinal stress calculated is 2439734.355765 N
The analytical hoop stress assuming thin walled vessel is 133333.33333 N
The analytical longitudinal stress assuming thin walled vessel is 66666.666667 N

fx >> |
```

The values do not match well with each other. There are two possible reasons for this

- Firstly, the mesh is coarse and a better result can be obtained for a finer mesh.
- Secondly, the d/t ratio for this vessel (5.33) is less than 20, so it does not satisfy the
 criteria for a thin-walled vessel (d/t > 20). Hence, the equation for a thick-walled
 pressure vessel should be used.

Hence, if we use a finer mesh by increasing the number of elements and calculate the analytical stresses using the formulation for a thick cylindrical pressure vessel, more accurate results can be obtained.

Q3)

- 3 different levels of mesh density are used 6 elements, 54 elements and 216 elements.
- The MATLAB Code and excel sheets (Q3_Mesh) containing the mesh data are attached to the submission.
- Following are the plots of temperature distribution as we increase the number of elements and the grid convergence plot considering the temperature at (3,3).




Fig 10: Temperature distribution in the domain with 6 elements




Fig 11: Temperature distribution in the domain with 54 elements




Fig 12: Temperature distribution in the domain with 216 elements




Fig 13: Temperature at (3,3) vs Number of elements

- From the above figure, we can see that as the number of elements is increased, the temperature at the fixed point (3,3) is converging to around 149.2 degrees.
- Using a few more mesh densities greater than 216 elements can show this mesh convergence in an even better way.

MATLAB Codes:

Q1)

```
clc; clear all; close all; format compact; format shortg;
%Constants
Fs = 500*10^3; %Surface Shear Force
Ft = 600; %Tip load
E = 80*10^9; %Young's Modulus
nu = 0.3; %Poisson Ratio
L = 1; w = 0.1; %Dimensions of domain
%Importing Mesh data
connectivity = readmatrix("Q1_Mesh.xlsx","Sheet",1);
coords = readmatrix("Q1_Mesh.xlsx","Sheet",2);
X = coords(:,2); Y = coords(:,3);
%Boundary nodes
EBC_nodes = [1, 27, 53, 79];
Ft node = 26;
Fs_nodes = [79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95,
96, 97, 98, 99, 100, 101, 102, 103, 104];
N = size(connectivity,1); %Number of elements;
n = size(coords,1); %Number of nodes
A = L*w/N; %Area of each element
%Assembling global stiffness matrix
k_k_global = zeros(2*n, 2*n);
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X(nodes);
    y = Y(nodes);
    k_k = stiffness_k(x,y,A,E,nu);
    for j = 1:numel(nodes)
        k_k_global([2*nodes(j),2*nodes(j)-1],2*nodes-1) =
k_k_global([2*nodes(j),2*nodes(j)-1],2*nodes-1) + k_k([2*j,2*j-1],[1,3,5]);
        k_k_global([2*nodes(j),2*nodes(j)-1],2*nodes) =
k_k_global([2*nodes(j),2*nodes(j)-1],2*nodes) + k_k([2*j,2*j-1],[2,4,6]);
    end
end
%Shear Force boundary
r q global = zeros(2*n,1);
for i = 1:numel(Fs nodes)-1
    node1 = Fs_nodes(i); node2 = Fs_nodes(i+1);
    x1 = X(node1); x2 = X(node2);
    y1 = Y(node1); y2 = Y(node2);
    L = ((x1-x2)^2 + (y1-y2)^2)^0.5;
    r_q_global(2*node1-1) = r_q_global(2*node1-1) + (L/2)*Fs;
    r_q_global(2*node2-1) = r_q_global(2*node2-1) + (L/2)*Fs;
```

end

```
%Applying EBC by removing corresponding equations
k_r = k_k_{global};
k_r(2*EBC_nodes,:) = [];
k_r(2*EBC_nodes-1,:) = [];
k_r(:,2*EBC_nodes) = [];
k r(:,2*EBC nodes-1) = [];
r_r = r_q_global;
%Adding point load to r vector
r_r(2*Ft_node) = r_r(2*Ft_node) + Ft;
r_r(2*EBC_nodes) = [];
r_r(2*EBC_nodes-1) = [];
%Solving for d vector
d_r = k_r r_r;
d = zeros(2*n,1);
idx = 1:1:2*n;
idx([2*EBC nodes, 2*EBC nodes-1]) = [];
d(idx) = d_r;
%For plotting we are multiplying the displacementns by 100
%Otherwise the displacements are very small to be seen on the plot
X_{new} = X + 100*d(1:2:end);
Y_{new} = Y + 100*d(2:2:end);
%Plotting the displacement field
figure(1);
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X_new(nodes); y = Y_new(nodes);
    subplot(2,1,1), fill(x,y,d(2*nodes-1)); hold on;
    subplot(2,1,2), fill(x,y,d(2*nodes)); hold on;
end
subplot(2,1,1), xlabel("X"); ylabel("Y"); title("U displacement");
colormap("jet"); colorbar
subplot(2,1,2), xlabel("X"); ylabel("Y"); title("V displacement");
colormap("jet"); colorbar
%Strain Calculation
e11 = zeros(N,1); e22 = zeros(N,1); gamma12 = zeros(N,1);
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X(nodes);
    y = Y(nodes);
    dl = zeros(6,1);
    dl([1,3,5]) = d(2*nodes-1);
    d1([2,4,6]) = d(2*nodes);
    e = strain(x,y,dl,A);
```

```
e11(i) = e(1); e22(i) = e(2); gamma12(i) = e(3);
%Plotting strain field
figure;
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X_new(nodes); y = Y_new(nodes);
    subplot(3,1,1), fill(x,y,e11(i)*ones(3,1)); hold on;
    subplot(3,1,2), fill(x,y,e22(i)*ones(3,1)); hold on;
    subplot(3,1,3), fill(x,y,gamma12(i)*ones(3,1)); hold on;
subplot(3,1,1), xlabel("X"); ylabel("Y"); title("\epsilon_{11}");
colormap("jet"); colorbar
subplot(3,1,2), xlabel("X"); ylabel("Y"); title("\epsilon_{22}");
colormap("jet"); colorbar
subplot(3,1,3), xlabel("X"); ylabel("Y"); title("\gamma_{12}"); colormap("jet");
colorbar
%Calculating and plotting stress field
sigma11 = zeros(N,1); sigma22 = zeros(N,1); tau12 = zeros(N,1);
figure;
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X_new(nodes); y = Y_new(nodes);
    C = (E/(1-nu^2))*[1, nu, 0;
                     nu, 1, 0;
                     0, 0 , (1-nu)/2];
    stress = C*[e11(i);e22(i);gamma12(i)];
    sigma11(i) = stress(1); sigma22(i) = stress(2); tau12(i) = stress(3);
    subplot(3,1,1), fill(x,y,sigma11(i)); hold on;
    subplot(3,1,2), fill(x,y,sigma22(i)); hold on;
    subplot(3,1,3), fill(x,y,tau12(i)); hold on;
end
subplot(3,1,1), xlabel("X"); ylabel("Y"); title("\sigma {11}"); colormap("jet");
colorbar;
subplot(3,1,2), xlabel("X"); ylabel("Y"); title("\sigma_{22}"); colormap("jet");
colorbar
subplot(3,1,3), xlabel("X"); ylabel("Y"); title("\tau_{12}"); colormap("jet");
colorbar
%Function to calculate stiffness matrix k k
function k_k = stiffness_k(x,y,A,E,nu)
    x1 = x(1); x2 = x(2); x3 = x(3);
    y1 = y(1); y2 = y(2); y3 = y(3);
    b1 = y2-y3; b2 = y3-y1; b3 = y1-y2;
    c1 = x3-x2; c2 = x1-x3; c3 = x2-x1;
    B = (1/(2*A))*[b1, 0, b2, 0, b3, 0]
                0, c1, 0, c2, 0, c3;
                c1, b1, c2, b2, c3, b3]';
```

```
C = (E/(1-nu^2))*[1, nu, 0;
                      nu, 1, 0;
                      0, 0, (1-nu)/2];
    k_k = A^*(B^*C^*B');
end
function e = strain(x,y,d,A)
    x1 = x(1); x2 = x(2); x3 = x(3);
    y1 = y(1); y2 = y(2); y3 = y(3);
    b1 = y2-y3; b2 = y3-y1; b3 = y1-y2;
    c1 = x3-x2; c2 = x1-x3; c3 = x2-x1;
    B = (1/(2*A))*[b1, 0, b2, 0, b3, 0;
                0, c1, 0, c2, 0, c3;
                c1, b1, c2, b2, c3, b3]';
    e = B'*d;
end
Q2)
clc; clear all; close all; format compact; format shortg;
%Constants
P = 50*10^3; %Pressure in the vessel
E = 200*10^9; %Young's Modulus
nu = 0.3; %Poisson Ratio
%Importing Mesh data
connectivity = readmatrix("Q2_Mesh.xlsx","Sheet",1);
coords = readmatrix("Q2_Mesh.xlsx","Sheet",2);
X = coords(:,2); Y = coords(:,3);
%Boundary nodes
Xsym_nodes = [4, 36, 35, 34, 5];
Ysym_nodes = [1, 7, 8, 9, 2];
P_vertical_nodes = [1, 13, 12, 11, 10, 3];
P_horizontal_nodes = [4, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27,
28, 29, 30, 31, 32, 33, 3];
N = size(connectivity,1); %Number of elements;
n = size(coords,1); %Number of nodes
%Assembling global stiffness matrix
k \ k \ global = zeros(2*n,2*n);
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X(nodes);
    y = Y(nodes);
    k_k = stiffness_k(x,y,E,nu);
    for j = 1:numel(nodes)
```

```
k k global([2*nodes(j), 2*nodes(j)-1], 2*nodes-1) =
k_k_global([2*nodes(j),2*nodes(j)-1],2*nodes-1) + k_k([2*j,2*j-1],[1,3,5]);
        k_k_global([2*nodes(j), 2*nodes(j)-1], 2*nodes) =
k_k_global([2*nodes(j),2*nodes(j)-1],2*nodes) + k_k([2*j,2*j-1],[2,4,6]);
    end
end
%Horizontal Pressure Boundary
r p global = zeros(2*n,1);
for i = 1:numel(P_horizontal_nodes)-1
    node1 = P horizontal nodes(i); node2 = P horizontal nodes(i+1);
    x1 = X(node1); x2 = X(node2);
    y1 = Y(node1); y2 = Y(node2);
    L = ((x1-x2)^2 + (y1-y2)^2)^0.5;
    r_p_global(2*node1-1) = r_p_global(2*node1-1) + (L/2)*P;
    r_p_global(2*node2-1) = r_p_global(2*node2-1) + (L/2)*P;
end
%Vertical Pressure Boundary
for i = 1:numel(P_vertical nodes)-1
    node1 = P_vertical_nodes(i); node2 = P_vertical_nodes(i+1);
    x1 = X(node1); x2 = X(node2);
    y1 = Y(node1); y2 = Y(node2);
    L = ((x1-x2)^2 + (y1-y2)^2)^0.5;
    r_p_global(2*node1) = r_p_global(2*node1) - (L/2);
    r_p_global(2*node2) = r_p_global(2*node2) - (L/2);
end
%Applying symmetry conditions by removing corresponding equations
k r = k k global;
k_r([2*Ysym_nodes-1,2*Xsym_nodes],:) = [];
k_r(:,[2*Ysym_nodes-1,2*Xsym_nodes]) = [];
r r = r p global;
r r([2*Ysym nodes-1,2*Xsym nodes]) = [];
%Solving for d vector
d_r = k_r r_r;
d = zeros(2*n,1);
idx = 1:1:2*n;
idx([2*Ysym_nodes-1,2*Xsym_nodes]) = [];
d(idx) = d_r;
%For plotting we are multiplying the displacementns by 1000
%Otherwise the displacements are very small to be seen on the plot
X_{new} = X + 1000*d(1:2:end);
Y_{new} = Y + 1000*d(2:2:end);
%Plotting the displacement field
figure(1);
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X_new(nodes); y = Y_new(nodes);
```

```
subplot(1,2,1), fill(x,y,d(2*nodes-1)); hold on;
    subplot(1,2,2), fill(x,y,d(2*nodes)); hold on;
end
subplot(1,2,1), xlabel("X"); ylabel("Y"); title("U displacement");
colormap("jet"); colorbar;
subplot(1,2,2), xlabel("X"); ylabel("Y"); title("V displacement");
colormap("jet"); colorbar;
%Strain Calculation
e11 = zeros(N,1); e22 = zeros(N,1); gamma12 = zeros(N,1);
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X(nodes);
    y = Y(nodes);
    dl = zeros(6,1);
    dl([1,3,5]) = d(2*nodes-1);
    d1([2,4,6]) = d(2*nodes);
    e = strain(x,y,dl);
    e11(i) = e(1); e22(i) = e(2); gamma12(i) = e(3);
end
%Plotting strain field
figure;
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X_new(nodes); y = Y_new(nodes);
    subplot(1,3,1), fill(x,y,e11(i)); hold on;
    subplot(1,3,2), fill(x,y,e22(i)); hold on;
    subplot(1,3,3), fill(x,y,gamma12(i)); hold on;
subplot(1,3,1), xlabel("X"); ylabel("Y"); title("\epsilon_{11}");
colormap("jet"); colorbar
subplot(1,3,2), xlabel("X"); ylabel("Y"); title("\epsilon_{22}");
colormap("jet"); colorbar
subplot(1,3,3), xlabel("X"); ylabel("Y"); title("\gamma_{12}"); colormap("jet");
colorbar
%Calculating and plotting stress field
sigma11 = zeros(N,1); sigma22 = zeros(N,1); tau12 = zeros(N,1);
figure;
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4);
    nodes = [node1,node2,node3];
    x = X \text{ new(nodes)}; y = Y \text{ new(nodes)};
    C = (E/(1-nu^2))*[1, nu, 0;
                     nu, 1, 0;
                     0, 0 , (1-nu)/2];
    stress = C*[e11(i);e22(i);gamma12(i)];
    sigma11(i) = stress(1); sigma22(i) = stress(2); tau12(i) = stress(3);
```

```
subplot(1,3,1), fill(x,y,sigma11(i)); hold on;
    subplot(1,3,2), fill(x,y,sigma22(i)); hold on;
    subplot(1,3,3), fill(x,y,tau12(i)); hold on;
end
subplot(1,3,1), xlabel("X"); ylabel("Y"); title("\sigma_{11}"); colormap("jet");
colorbar
subplot(1,3,2), xlabel("X"); ylabel("Y"); title("\sigma {22}"); colormap("jet");
colorbar
subplot(1,3,3), xlabel("X"); ylabel("Y"); title("\tau_{12}"); colormap("jet");
colorbar
hoop = max(abs(sigma11));
long = max(abs(sigma22));
d = 0.4; t = 0.075;
hoop thin = P*d/(2*t);
long_thin = P*d/(4*t);
fprintf("The hoop stress calculated is %f N\n",hoop)
fprintf("The longitudinal stress calculated is %f N\n", long);
fprintf("The analytical hoop stress assuming thin walled vessel is %f
N\n", hoop thin)
fprintf("The analytical longitudinal stress assuming thin walled vessel is %f
N\n", long_thin);
%Function to calculate stiffness matrix k k
function k_k = stiffness_k(x,y,E,nu)
    x1 = x(1); x2 = x(2); x3 = x(3);
    y1 = y(1); y2 = y(2); y3 = y(3);
    f1 = x2*y3-x3*y2; f2 = x3*y1-x1*y3; f3 = x1*y2-x2*y1;
    A = 0.5*(f1+f2+f3);
    b1 = y2-y3; b2 = y3-y1; b3 = y1-y2;
    c1 = x3-x2; c2 = x1-x3; c3 = x2-x1;
    B = (1/(2*A))*[b1, 0, b2, 0, b3, 0]
                0, c1, 0, c2, 0, c3;
                c1, b1, c2, b2, c3, b3]';
    C = (E/(1-nu^2))*[1, nu, 0;
                      nu, 1, 0;
                      0, 0, (1-nu)/2;
    k_k = A^*(B^*C^*B');
end
function e = strain(x,y,d)
    x1 = x(1); x2 = x(2); x3 = x(3);
    y1 = y(1); y2 = y(2); y3 = y(3);
    f1 = x2*y3-x3*y2; f2 = x3*y1-x1*y3; f3 = x1*y2-x2*y1;
    A = 0.5*(f1+f2+f3);
    b1 = y2-y3; b2 = y3-y1; b3 = y1-y2;
    c1 = x3-x2; c2 = x1-x3; c3 = x2-x1;
    B = (1/(2*A))*[b1, 0, b2, 0, b3, 0;
```

```
0, c1, 0, c2, 0, c3;
                c1, b1, c2, b2, c3, b3]';
    e = B'*d;
end
Q3)
clc; clear all; close all; format compact; format shortg;
%Constants
% L = 0.015; %For 6 elements
% L = 0.005; %For 54 elements
L = 0.0025; %For 216 elements
a = L/2; b = L/2; %a and b for the square element
k = 45; %Thermal Conductivity
q0 = 8000; %Heat flux of left boundary
Q = 5*10^6; %Constant heat generation in the domain
h = 55; %Convective heat transfer coefficient
T0 = 110; %Essential BC at bottom boundary
Tamb = 20; %Ambient temperature
alpha1 = -h; %alpha for convective NBC
beta1 = h*Tamb; %beta for convective NBC
beta2 = q0; %beta for constant heat flux NBC
%Importing Mesh data from excel
% connectivity = readmatrix("Q3_Mesh1.xlsx","Sheet",1); %For 6 elements
% connectivity = readmatrix("Q3 Mesh2.xlsx"); %For 54 elements
connectivity = readmatrix("Q3_Mesh3.xlsx"); %For 216 elements
% coords = readmatrix("Q3_Mesh1.xlsx","Sheet",2);
% coords = readmatrix("Q3_Mesh2.xlsx","Sheet",2);
coords = readmatrix("Q3_Mesh3.xlsx","Sheet",2);
X = coords(:,2); Y = coords(:,3);
elements = connectivity(:,1);
N = numel(elements); %Number of elements
n = size(coords,1); %Number of nodes
%Boundary nodes
% % Using 6 elements
% left_NBC_nodes = [7, 11, 6]; %Constant heat flux q0
% right_NBC_nodes1 = [3, 4]; %Insulated
% top_NBC_nodes1 = [6, 10, 5]; %Convective
% top_NBC_nodes2 = [1, 9, 4]; %Convective
% right_NBC_nodes2 = [1, 5]; %Convective
% EBC_nodes = [7, 12, 2, 8, 3]; %Fixed temperature
% % Using 54 elements
% left_NBC_nodes = [7, 33, 32, 31, 30, 29, 6]; % Constant heat flux q0
% right NBC nodes1 = [3, 15, 16, 4];
                                               % Insulated
% top_NBC_nodes1 = [6, 28, 27, 26, 25, 24, 5]; % Convective
% top_NBC_nodes2 = [1, 21, 20, 19, 18, 17, 4]; % Convective
% right_NBC_nodes2 = [1, 22, 23, 5];
                                               % Convective
% EBC_nodes = [7, 34, 35, 36, 37, 38, 2, 10, 11, 12, 13, 14, 3]; % Fixed
temperature
```

```
%Using 216 elements
left_NBC_nodes = [7, 66, 65, 64, 63, 62, 61, 60, 59, 58, 57, 56, 6]; % Constant
heat flux q0
right_NBC_nodes1 = [3, 24, 25, 26, 27, 28, 4];
                                                                       % Insulated
top_NBC_nodes1 = [6, 55, 54, 53, 52, 51, 50, 49, 48, 47, 46, 45, 5];
                                                                      % Convective
top_NBC_nodes2 = [1, 39, 38, 37, 36, 35, 34, 33, 32, 31, 30, 29, 4];
                                                                      % Convective
right_NBC_nodes2 = [1, 40, 41, 42, 43, 44, 5];
                                                                       % Convective
EBC nodes = [7, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 2, 13, 14, 15, 16, 17,
18, 19, 20, 21, 22, 23, 3]; % Fixed temperature
%Assembling global k k matrix and r q vector
k_k_global = zeros(n,n);
r_q_global = zeros(n,1);
for i = 1:N
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4); node4 = connectivity(i,5);
    nodes = [node1,node2,node3,node4];
    k_k = stiffness_k(k,k,a,b);
    for j = 1:4
    k k global(nodes(j),nodes) = k k global(nodes(j),nodes) + k k(j,:);
    r_q_global(nodes(j)) = r_q_global(nodes(j)) + a*b*Q;
end
%Assembling k_alpha matrix and r_beta vector for NBCs
k_alpha_global = zeros(n,n);
r_beta_global = zeros(n,1);
%NBC on left boundary
%This method will work only when the boundary nodes are given sequentially,
%in the same order as they lie in the domain
for i = 1:numel(left_NBC_nodes)-1
    node1 = left_NBC nodes(i);
    node2 = left NBC nodes(i+1);
    r beta = [b*beta2; b*beta2];
    r_beta_global([node1,node2]) = r_beta_global([node1,node2]) + r_beta;
end
%NBC on top boundary part 1
for i = 1:numel(top NBC nodes1)-1
    node1 = top NBC nodes1(i);
    node2 = top_NBC_nodes1(i+1);
    k_alpha = [-2*b*alpha1/3, -b*alpha1/3;
               -b*alpha1/3, -2*b*alpha1/3];
    k_alpha_global([node1,node2],[node1,node2]) =
k_alpha_global([node1,node2],[node1,node2]) + k_alpha;
    r beta = [a*beta1; a*beta1];
    r beta global([node1,node2]) = r beta global([node1,node2]) + r beta;
end
%NBC for top boundary part 2
for i = 1:numel(top_NBC_nodes2)-1
    node1 = top NBC nodes2(i);
    node2 = top NBC nodes2(i+1);
```

```
k_alpha = [-2*b*alpha1/3, -b*alpha1/3;
               -b*alpha1/3, -2*b*alpha1/3];
    k_alpha_global([node1,node2],[node1,node2]) =
k_alpha_global([node1,node2],[node1,node2]) + k_alpha;
    r beta = [a*beta1; a*beta1];
    r_beta_global([node1,node2]) = r_beta_global([node1,node2]) + r_beta;
end
%NBC for convective right side boundary
for i = 1:numel(right NBC nodes2)-1
    node1 = right_NBC_nodes2(i);
    node2 = right_NBC_nodes2(i+1);
    k_alpha = [-2*b*alpha1/3, -b*alpha1/3;
                -b*alpha1/3, -2*b*alpha1/3];
    k_alpha_global([node1,node2],[node1,node2]) =
k alpha global([node1,node2],[node1,node2]) + k alpha;
    r beta = [b*beta1; b*beta1];
    r_beta_global([node1,node2]) = r_beta_global([node1,node2]) + r_beta;
end
%Adding all the terms
k_global = k_k_global + k_alpha_global;
r_global = r_q_global + r_beta_global;
k_r = k_global;
r_r = r_global;
%Removing equations (rows) corresponding to EBCs
k r(EBC nodes,:) = [];
%Removing the rows corresponding to the EBCs
r_r(EBC_nodes) = [];
%Adjusting the RHS using the EBCs
r_r = r_r - k_r(:,EBC_nodes)*T0*ones(numel(EBC_nodes),1);
%Removing the columns corresponding to the EBCs
k r(:,EBC nodes) = [];
%Solving for the temperature field
T = zeros(n,1);
T_r = k_r r_r;
%Combining the calculated T values and known T values from EBCs
idx = 1:1:n;
idx(EBC_nodes) = [];
T(idx) = T_r;
T(EBC_nodes) = T0;
%Plotting Temperature distributions
figure; hold on;
for i = 1:N
    %Using Fill to color each element with the temperature
    node1 = connectivity(i,2); node2 = connectivity(i,3); node3 =
connectivity(i,4); node4 = connectivity(i,5);
```

```
nodes = [node1,node2,node3,node4];
    fill(X(nodes),Y(nodes),T(nodes))
end
colormap("jet")
colorbar
scatter(X,Y,10,"filled",'ok')
xlabel("X (cm)"); ylabel("Y (cm)");
title("Temperature Distribution")
axis equal;
xlim([0,6]); ylim([0,3]);
%Plotting T at (3,3) with different number of elements
T vec = [148.67, 149.07, 149.23];
N_{\text{vec}} = [6,54,216];
%Function to calculate k_k
function k_k = stiffness_k(kx,ky,a,b)
    k_k = [ky*a/(3*b) + kx*b/(3*a),
                                      ky*a/(6*b) - kx*b/(3*a),
                                                                   -ky*a/(6*b) -
kx*b/(6*a),
              kx*b/(6*a) - ky*a/(3*b);
          ky*a/(6*b) - kx*b/(3*a),
                                      ky*a/(3*b) + kx*b/(3*a),
                                                                   kx*b/(6*a) -
               -ky*a/(6*b) - kx*b/(6*a);
ky*a/(3*b),
         -ky*a/(6*b) - kx*b/(6*a),
                                      kx*b/(6*a) - ky*a/(3*b),
                                                                   ky*a/(3*b) +
             ky*a/(6*b) - kx*b/(3*a);
kx*b/(3*a),
                                       -ky*a/(6*b) - kx*b/(6*a),
          kx*b/(6*a) - ky*a/(3*b),
                                                                   ky*a/(6*b) -
              ky*a/(3*b) + kx*b/(3*a);
kx*b/(3*a),
end
```