Organization & Architecture

Architecture: Computer Architecture refers to those attributes of a system visible to a programmer or, put another way, those attributes that have direct impact on the logical execution of a program.

Examples include the instruction set, the number of bits used to represent various data types (e.g., number, character), I/O mechanisms and techniques for addressing memory.

Organization: Computer Organization refers to the operational units and their Interconnections that realize the architectural specifications


Examples include those hardware details transparent to the programmer, such as control signals, interfaces between the computer and peripherals and memory technology used.

INTRODUCTION

Introduction to digital computer

A computer is an electronic device which works under the given instruction. it takes the input from the user process that input and gives the output.

- ▶ **Input device:-**used to give input to the computer.
- **Output device**:-gives pressed data to the user.
- Memory:- it is a storage unit which stored data and information in the foam of binary(0,1).
- **Control unit**:-it controls all the components of the computer i.e it devices when to start receiving data, when to stop it where to store data etc.
- Arithmetic logical unit(A.L.U):- all the arithmetic and logical operation are perform here.
- **C.P.U**:- control process unit is the brain of the computer. It combine CU+ALU.



Digital computer

1. Input Unit:

- The input unit consists of input devices that are attached to the computer.
- These devices take input and convert it into binary language that the computer understands.
- Common input devices are keyboard, mouse, joystick, scanner etc.

2. Central Processing Unit (CPU):

- The CPU is called the brain of the computer because it is the control centre of the computer.
- It first fetches instructions from memory and then interprets them so as to know what is to be done.
- CPU executes or performs the required computation and then either stores the output or displays on the output device

3. Arithmetic and Logic Unit (ALU):

- It performs mathematical calculations and takes logical decisions.
- Arithmetic calculations include addition, subtraction, multiplication and division.
- Logical decisions involve comparison of two data items to see which one is larger or smaller or equal.

4. Control Unit:


- It coordinates and controls the data flow in and out of CPU and also controls all the operations of ALU, memory registers and input/output units.
- It decodes the fetched instruction, interprets it and sends control signals to input/output devices until the required operation is done properly by ALU and memory.

5. Memory:

- Memory attached to the CPU is used for storage of data and instructions and is called internal memory.
- The internal memory is divided into many storage locations, each of which can store data or instructions

6. Output Unit:

- The output unit consists of output devices that are attached with the computer.
- It converts the binary data coming from CPU to human understandable form.
- The common output devices are monitor, printer, plotter etc.



1. Primary / Main memory:

- The memory unit that establishes direct communication with the CPU is called **Main Memory**. The main memory is often referred to as RAM (Random Access Memory).
- It holds the data and instructions that the processor is currently working on.

2. Secondary Memory / Mass Storage:

- The contents of the secondary memory first get transferred to the primary memory and then are accessed by the processor, this is because the processor does not directly interact with the secondary memory.
- The memory units that provide backup storage are called Auxiliary Memory. For instance, magnetic disks and magnetic tapes are the most commonly used auxiliary memories.

The AND gate



(a) Circuit symbol

A	В	C
0	0	0
0	1	0
1	0	0
1	1	1

(b) Truth table

$$C = A \cdot B$$

The OR gate




(a) Circuit symbol

A	В	C
0	0	0
0	1	1
1	0	1
1	1	1

(b) Truth table

$$C = A + B$$


The NOT gate (or inverter)



$$B = \overline{A}$$

- (b) Truth table
- (c) Boolean expression

A logic buffer gate



$$B = A$$

- (b) Truth table
- (c) Boolean expression

The NAND gate



(a) Circuit symbol

A	В	C
0	0	1
0	1	1
1	0	1
1	1	0

(b) Truth table

$$C = \overline{A \cdot B}$$

The NOR gate



(a) Circuit symbol

P	1	В	C
()	0	1
()	1	0
1	l	0	0
1	l	1	0

(b) Truth table

$$C = \overline{A + B}$$

The Exclusive OR gate




(a) Circuit symbol

A	В	C
0	0	0
0	1	1
1	0	1
1	1	0

(b) Truth table

$$C = A \oplus B$$

The Exclusive NOR gate



(a) Circuit symbol

A	В	C
0	0	1
0	1	0
1	0	0
1	1	1

(b) Truth table

$$C = \overline{A \oplus B}$$

Multiplexer


Multiplexer (MUX)

- It is a combinational circuit that has maximum of 2ⁿ data inputs, 'n' selection lines and single output line.
- One of these data inputs will be connected to the output based on the values of selection lines.
- Multiplexers are also known as "Data n selector, parallel to serial convertor, many to one circuit, universal logic circuit"

4x1 Multiplexer

4x1 Multiplexer

- 4x1 Multiplexer has four data inputs I_3 , I_2 , I_1 & I_0 , two selection lines s_1 & s_0 and one output Y.
- The block diagram of 4x1 Multiplexer is shown in the following figure.



4x1 Multiplexer

- One of these 4 inputs will be connected to the output based on the combination of inputs present at these two selection lines.
- Truth table of 4x1 Multiplexer is shown below.


Selection Lines		Output
S ₁	S ₀	Υ
0	0	I ₀
0	1	I ₁
1	0	l ₂
1	1	I ₃

4x1 Multiplexer

• From Truth table, we can directly write the **Boolean function** for output, Y as

$$Y = S_1' S_0' I_0 + S_1' S_0 I_1 + S_1 S_0' I_2 + S_1 S_0 I_3$$

• This Boolean function can be implemented using Inverters, AND gates & OR gate. The **circuit diagram** of 4x1 multiplexer is shown in the following figure.




De-Multiplexer (De-MUX)

- It is a combinational circuit that performs the reverse operation of Multiplexer.
- It has single input, 'n' selection lines and maximum of 2ⁿ outputs.
- The input will be connected to one of these outputs based on the values of selection lines.
- They are also known as "Data distributor, serial to parallel convertor, one to many circuit"

1x4 De-Multiplexer

- 1x4 De-Multiplexer has one input I, two selection lines, $s_1 \& s_0$ and four outputs $Y_3, Y_2, Y_1 \& Y_0$.
- The **block diagram** of 1x4 De-Multiplexer is shown in the following figure.



- The single input 'I' will be connected to one of the four outputs, Y_3 to Y_0 based on the values of selection lines $s_1 \& s_0$.
- The **Truth table** of 1x4 De-Multiplexer is shown below.

Selectio	Selection Inputs		Outputs		
S ₁	S ₀	Y ₃	Y ₂	Y ₁	Y ₀
0	0	0	0	0	I
0	1	0	0	I	0
1	0	0	I	0	0
1	1	I	0	0	0

• From the above Truth table, we can directly write the **Boolean** functions for each output as


$$Y_3 = s_1 s_0 I$$

$$Y_2 = s_1 s_0{'}I$$


$$Y_1 = s_1{}'s_0I$$

$$Y_0 = s_1' s_0' I$$

- These Boolean functions are implemented using Inverters & 3-input AND gates.
- The circuit diagram of 1x4 De-Multiplexer is shown in the following figure.



- Let 2 to 4 Decoder has two inputs $A_1 \& A_0$ and four outputs Y_3 , Y_2 , $Y_1 \& Y_0$.
- The **block diagram** of 2 to 4 decoder is shown in the following figure.



- One of these four outputs will be '1' for each combination of inputs when enable, E is '1'.
- The Truth table of 2 to 4 decoder is shown below-

Enable	Inp	uts		Out	puts	
E	A ₁	A_0	Y ₃	Y ₂	Y ₁	Υ ₀
0	x	x	0	0	0	0
1	0	0	0	0	0	1
1	0	1	0	0	1	0
1	1	0	0	1	0	0
1	1	1	1	0	0	0

• From Truth table, the **Boolean functions** for each output is


$$Y_3 = E. A_1. A_0$$

$$Y_2=E.\,A_1.\,{A_0}'$$

$$Y_1=E.\,{A_1}'.\,A_0$$


$$Y_0 = E. A_1'. A_0'$$

• The circuit diagram of 2 to 4 decoder is shown in the following figure




Encoder

- An **Encoder** is a combinational circuit that performs the reverse operation of Decoder.
- It has maximum of 2ⁿ input lines and 'n' output lines.
- It will produce a binary code equivalent to the input, which is active High.
- Therefore, the encoder encodes 2ⁿ input lines with 'n' bits. It is optional to represent the enable signal in encoders.



- Let 4 to 2 Encoder has four inputs Y_3 , Y_2 , Y_1 & Y_0 and two outputs A_1 & A_0 .
- The block diagram of 4 to 2 Encoder is shown in the following figure.



- At any time, only one of these 4 inputs can be '1' in order to get the respective binary code at the output.
- The Truth table of 4 to 2 encoder is shown below


	Inputs			Out	puts
Y ₃	Y ₂	Y ₁	Y_0	A ₁	A_0
0	0	0	1	0	0
0	0	1	0	0	1
0	1	0	0	1	0
1	0	0	0	1	1

• From Truth table, the Boolean functions for each output is

$$A_1 = Y_3 + Y_2$$

$$A_0 = Y_3 + Y_1$$

- We can implement the above two Boolean functions by using two input OR gates.
- The circuit diagram of 4 to 2 encoder is shown in the following figure



HALFADDER

- •Half Adder is a combinational logic circuit.
- •It is used for the purpose of adding two single bit numbers.
- •It contains 2 inputs and 2 outputs (sum and carry).




Inp	outs	Outp	outs
Α	В	C (Carry)	S (Sum)
0	0	0	0
0	1	0	1
1	0	0	1
1	1	1	0

Truth Table

HALF ADDER

Limitation of Half Adder-


- •Half adders have no scope of adding the carry bit resulting from the addition of previous bits.
- •This is a major drawback of half adders.
- •This is because real time scenarios involve adding the multiple number of bits which can not be accomplished using half adders.



Half Adder Logic Diagram

FULL ADDER

- •Full Adder is a combinational logic circuit.
- •It is used for the purpose of adding two single bit numbers with a carry.
- •Thus, full adder has the ability to perform the addition of three bits.
- •Full adder contains 3 inputs and 2 outputs (sum and carry) as shown-




FULL ADDER

Inputs			Outputs	
Α	В	C _{in}	C _{out} (Carry)	S (Sum)
0	0	0	0	0
0	0	1	0	1
0	1	0	0	1
0	1	1	1	0
1	0	0	0	1
1	0	1	1	0
1	1	0	1	0
1	1	1	1	1

Truth Table


FULL ADDER



Full Adder Logic Diagram

HALF SUBTRACTOR

- •Half Subtractor is a combinational logic circuit.
- •It is used for the purpose of subtracting two single bit numbers.
- •It contains 2 inputs and 2 outputs (difference and borrow).




Inputs		Outputs	
Α	В	D (Difference)	b (Borrow)
0	0	0	0
0	1	1	1
1	0	1	0
1	1	0	0

Truth Table

HALF SUBTRACTOR


- •Half Subtractor is a combinational logic circuit.
- •It is used for the purpose of subtracting two single bit numbers.
- •It contains 2 inputs and 2 outputs (difference and borrow).



Half Subtractor Logic Diagram

FULL SUBTRACTOR

- •Full Subtractor is a combinational logic circuit.
- •It is used for the purpose of subtracting two single bit numbers.
- •It also takes into consideration borrow of the lower significant stage.
- •Thus, full subtractor has the ability to perform the subtraction of three bits.
- •Full subtractor contains 3 inputs and 2 outputs (Difference and Borrow) as shown-




FULL SUBTRACTOR

Inputs			Outputs	
Α	В	B _{in}	B _{out} (Borrow)	D (Difference)
0	0	0	0	0
0	0	1	1	1
0	1	0	1	1
0	1	1	1	0
1	0	0	0	1
1	0	1	0	0
1	1	0	0	0
1	1	1	1	1


Truth Table

FULL SUBTRACTOR




Full Subtractor Logic Diagram

- **BUS**: A **bus** is a **common pathway** through which information flows from one computer component to another.
- It is a subsystem that is used to transfer data and other information between devices.
- Means various devices in computer like(Memory, CPU, I/O and Other) are communicate with each other through buses.
- A shared communication path consisting of one or more connections lines is known as bus and the transfer of data through this bus is known as bus transfer.



A system bus is a single computer bus that connects the major components of a computer system, combining the functions of a data bus to carry information, an address bus to determine where it should be sent or read from, and a control bus to determine its operation.



Types of Computer BUS:

- 1. Data Bus
- 2. Address Bus
- 3. Control Bus

Data bus

- It is a **bidirectional** pathway that carries the actual data (information) to and from the main memory.
- Data Lines provide a path for moving data between system modules.
- It is bidirectional which means data lines are used to transfer data in both directions.
- CPU can read data on these lines from memory as well as send data out of these lines to a memory location or to a port.
- The no. of lines in data lines are either 8,16,32 or more depending on architecture.

2. Address bus

- Address Lines are collectively called as address bus.
- It is a **unidirectional** pathway that allows information to travel in only one direction.
- No. of lines in address are usually 16,20,24, or more depending on type and architecture of bus
- It is an internal channel from CPU to Memory across which the address of data(not data) are transmitted.
- It is used to identify the source or destination of data.
- Here the communication is one way that is, the address is send from CPU to Memory and I/O Port but not Memory and I/O port send address to CPU on that line and hence these lines are unidirectional.

3. Control bus

- It carries the control and timing signals needed to coordinate the activities of the entire computer.
- They are used by CPUs for Communicating with other devices within the computer.
- They are bidirectional.
- Typical Control Lines signals are Memory Read
 Memory Write
 I/O Read
 I/O Write ,etc

Single Bus Structure –

All units are connected to the same bus.


2. Multiple Bus Structure

a) Traditional Configuration


Uses three buses - local bus, system bus and expanded bus.

a) High Speed BUS Configuration

Uses high speed bus along with three buses - local bus, system bus and expanded bus used in traditional configuration.



Traditional Bus Configuration



BUS: A shared communication path consisting of one or more connections lines is known as bus and the transfer of data through this bus is known as bus transfer.

Memory Transfer: When a data is read from the memory or is stored in memory is referred to as memory transfer.

Def.: A bidirectional bus used to carry **data between two units is data bus**.

Def.: A unidirectional bus used to carry **memory addresses is called memory**

bus.

Def.: The way in which different bus are connected to form common bus, so that CPU, memory and I/O devices can used common bus(Using multiplexer) when required is called **bus organization.**

For a general Bus organization System:-

In general a bus system will multiplex K registers of N bits each.

No of Multiplexers =N

Size of multiplexers $=K \times 1$.

No of selection Lines =m (2 $^{\text{m}}$)=K

Size of decoder will be m× K.


Example: Construct a common bus of 4 registers of 4 bits.

No of Multiplexers =4

Size of multiplexers $=4 \times 1$.


No of selection Lines = $2(2^2 = 4(\text{size of Multiplexer}))$

Size of decoder will be 2×4 .



Functional Table for Register Selection


S1	S0	Register Selected
0	0	A
0	1	В
1	0	C
1	1	D
1	0 1	D




Three-State Bus Buffers



Bus line with three-state buffers





BUS ARBITRATION: refers to the process by which the a device accesses and then leaves the control of the bus and passes it to another bus requesting processor unit. The controller that has access to a bus at an instance is known as a **Bus master**.

OR

The process by which the requesting process may be granted the access to the bus.

There are two approaches to bus arbitration:

Centralized bus arbitration –

A single bus arbiter performs the required arbitration.

- (i) Daisy Chaining method
- (ii) Polling or Rotating Priority method
- (iii) Fixed priority or Independent Request method

Distributed bus arbitration –


All devices participating in the selection of the next bus master.

Centralized bus arbitration

i) Daisy Chaining method –

It is a simple and cheaper method where all the bus masters use the same line for making bus requests. The bus grant signal serially propagates through each master until it encounters the first one that is requesting access to the bus. This master blocks the propagation of the bus grant signal, therefore any other requesting module will not receive the grant signal and hence cannot access the bus.

During any bus cycle, the bus master may be any device – the processor or any DMA controller unit, connected to the bus.



Advantages –


- a) Simple design
- b) Less no. of controllines.

Disadvantages-

- a) Priority depends on the physical location of master.
- b) Propagation delay due to serially granting of bus.
- c) Failure of one of the devices may fail entire system.

(ii) Polling or Rotating Priority method –

Here all bus masters use the same line for bus request. Here controller generate binary address for the master. (To connect 8 bus master we need 3 address lines 2323 = 8). In response to a bus request, the controller "polls" the bus masters by sending a sequence of bus master address on address lines. When requesting master recognizes its address, it activates the bus busy lines and takes control of the bus.



Advantage:


- a) Priority flexible.
- b) One module fails, entire system does not fail.

Disadvantage:

a) Adding bus masters is different as increases the number of address lines of the circuit.

(iii) Fixed priority or Independent Request method

All bus masters have their individual bus request and bus grant lines. The controller thus knows which master has requested, so bus is granted t that master. Priorities of the masters are predefined so on simultaneous bus requests, the bus is granted based on the priority, provided the bus busy line is not active. The controller consists of encoder and decoder logic for priorities



Advantages:


- a) Bus arbitration is fast.
- b) Speed independent of no. of devices connected.

Disadvantages:

a) No. of controllines required is more. Hence connecting a large number of bus masters is difficult.

Distributed bus arbitration –

Here, all the devices participate in the selection of the next bus master. Each device on the bus is assigned a 4 bit identification number. When one or more devices request a control of the bus, they assert the start arbitration signal and place their 4-bit identification numbers on arbitration lines through ARB3. Each device compares the code and changes its bit position accordingly. It does so by placing a 0 at the input of their drive. The distributed arbitration is highly reliable because the bus operations are not dependent on devices.




- What is the difference between centralized processing and distributed processing?
- In centralized computing all the processing is handled by a central system. It is more secure as all the data and processing is handled at single place. But if the central system is down the whole system crashes.
- In distributed computing a problem is divided into many tasks and these task are completed by different systems connected through each other over the network. It is less secure than centralized computing as data is distributed across several computers. But even if one or two computer goes down the entire system does not crash. The other computers continue their work. So you can upgrade your system without completely shutting it down.

Register

- They are used to quickly accept, store, and transfer data and instructions that are being used immediately by the CPU.
- They are used to hold the temporary data.
- There are various types of Registers those are used for various purpose.


Register Symbol	Number of bits	Register Name	Register Function
DR	16	Data register	Holds memory operands
AR	12	Address register	Holds address for memory
AC	16	Accumulator	Processor register
IR	16	Instruction register	Holds instruction code
PC	12	Program counter	Holds address of instruction
TR	16	Temporary register	Holds temporary data
INPP	8	Input register	Holds input character
OUTR	0	Output register	Holds output character

Rotating Daisy-chain: Rotating daisy-chain is the dynamic version of the static daisy-chain algorithm. In this algorithm, the priority line is connected to the priority out (PO) of the last processor which is connected to the priority-in of the first processor forming a loop. The processor that has the access to the system bus acts as bus controller. Each arbiter priority is determined by its position along the bus priority line from the arbiter whose processor is using the system bus. Once the arbiter releases the system bus, it has the lowest priority.



Register

- Computer registers are designated by capital letters (sometimes followed by numerals) to denote the function of the register.
- The register that holds an address for the memory unit is memory address register and is designated by the name MAR.
- The program counter register is called **PC**, **IR** is the instruction register and **R1** is a processor register




Register Transfer


• Information transfer from one register to another is designated in symbolic form by means of a replacement operator.

$$R2 \leftarrow R1$$

- It denotes a transfer of the content of register R1 into register R2. It designates a replacement of the content of R2 by the content of R1 without changing the content of R1 after transfer.
- If the Register transfer is to occur only under a predetermined control condition, this can be shown by means of an *if-then* statement.
- If (P = 1) then (R2 R1)
- P: R2 **R**1,

where **P** is a control function that can be either 0 or 1






Basic Symbols for Register Transfers

Symbol	Description	Examples
Letters (and numerals)	Denotes a register	MAR, R2
Parentheses () Arrow ← Comma,	Denotes a part of a register Denotes transfer of information Separates two microoperations	R2(0-7), $R2(L)R2 \leftarrow R1R2 \leftarrow R1, R1 \leftarrow R2$

Memory Transfer

Memory Transfer Block diagram



Above Diagram showing connections to memory unit.

Write: $M[AR] \leftarrow DR$


Read: DR \leftarrow M[AR]

Memory Transfer

6. Show the block diagram of the hardware that implements the following register transfer statement.

 $yT_2: R_2 \leftarrow R_1, R_1 \leftarrow R_9$

Solution:



8. Represent the following conditional, control statement by two register transfer statements with control functions.

If
$$(P=1)$$
 then
$$(R_1 \leftarrow R_2)$$
 else if $(Q=1)$ then
$$(R_1 \leftarrow R_3)$$
 Solution :

Clock


$$\begin{aligned} P: R_1 \leftarrow R_2 \\ P'Q: R_1 \leftarrow R_3 \end{aligned}$$

Memory Transfer

13. Draw the block diagram for the hardware that implements the following statements : $x + yz : AR \leftarrow AR + BR$


where AR and BR are two n-bit registers and x, y and z are control variables. Include the logic gates for the control function. (Remember that the symbol + designates an OR operation in a control or Boolean function but that it represents an arithmetic plus in a microoperation.)

Solution:



14. Show the hardware that implements the following statement. Include the logic gates for the control function and a block diagram for the binary counter with a count enable input.

Solution:



Memory Transfer

- 11. A digital computer has a common bus system for 16 registers of 32 bits each. The bus is constructed with multiplexers.
 - (a) How many selection inputs are there in each multiplexer?
 - (b) What size of multiplexers are needed?
 - (c) How many multiplexers are there in the bus?

Solution:

- (a) 4 selection lines to select one of 16 registers.
- (b) 16 × 1 multiplexers are needed.
- (c) 32 multiplexers, one for each bit of the registers.
- 12. The following transfer statements specify a memory. Explain the memory operation in each case.
 - (a) $R_2 \leftarrow M[AR]$
 - (b) $M[AR] \leftarrow R_3$
 - (a) $R_5 \leftarrow M[R_5]$

Solution:

- (a) Read memory word specified by the address in AR into register R_2 .
- (b) Write content of register R_3 into the memory word specified by the address in AR.
- (c) Read memory word specified by the address in R_5 and Transfer content to R_5 (destroys previous value).

MAJOR COMPONENTS OF CPU

•Storage Components

Registers

Flags

Execution (Processing) Components

Arithmetic Logic Unit(ALU)

Arithmetic calculations, Logical computations, Shifts/Rotates

• Transfer Components

Bus


Control Components


Control Unit

In Basic Computer, there is only one general purpose register, the Accumulator (AC) In modern CPUs, there are many general purpose registers

It is advantageous to have many registers

Transfer between registers within the processor are relatively fast Going "off the processor" to access memory is much slower





The control unit

Directs the information flow through ALU by

- Selecting various *Components* in the system
- Selecting the Function of ALU

Control Word : The group of binary bits assigned to perform a specified operation is known as control word

To perform ANY operation, the control must provide

- (i) SELA: place the contents of Any Register R into bus A.
- (ii) SELB: place the contents of Any Register R into bus B.
- (iii) ALU operation selector OPR: provide the arithmetic operation
- (iv) SELD: transfer the contents of the output bus into any destination Register R.



Encoding of Register Selection Fields

Encoding of ALU

Binary code	SELA	SELB	SELD
000	input	input	none
001	R1	<i>R</i> 1	R1
010	R2	R2	R2
011	R3	R3	R3
100	R4	R4	R4
101	R5	R5	R5
110	R6	R6	R6
111	R7	R7	R7

OPR	Operation	Symbol	
00000	Transfer A	TSFA	
00001	Increment A	INCA	
00010	Addition	ADD	
00101	Subtract	SUB	
00110	Decrement A	DECA	
01000	AND A and B	AND	
01010	OR A and B	OR	
01100	$XOR\ A$ and B	XOR	
01110	Complement A	COMA	
10000	Shift right A	SHRA	
11000	Shift left A	SHLA	

Let the operation be

 $R5 \leftarrow R1.R4$

To perform this operation, the control must provide


- (i) SELA: place the contents of R1 into bus A.
- (ii) SELB: place the contents of *R4* into bus *B*.
- (iii) ALU operation selector OPR: provide the arithmetic multiplication A AND B.
- (iv) SELD: transfer the contents of the output bus into R5.

SELA	SELB	SELD	OPR
R1	R4	R_5	AND
001	100	101	01000

PROBLEMS

- 8-1. A bus-organized CPU similar to Fig. 8-2 has 16 registers with 32 bits in each, an ALU, and a destination decoder.
 - **a.** How many multiplexers are there in the A bus, and what is the size of each multiplexer?
 - b. How many selection inputs are needed for MUX A and MUX B?
 - c. How many inputs and outputs are there in the decoder?
 - d. How many inputs and outputs are there in the ALU for data, including input and output carries?
 - e. Formulate a control word for the system assuming that the ALU has 35 operations.
- 8-2. The bus system of Fig. 8-2 has the following propagation delay times: 30 ns for the signals to propagate through the multiplexers, 80 ns to perform the ADD operation in the ALU, 20 ns delay in the destination decoder, and 10 ns to clock the data into the destination register. What is the minimum cycle time that can be used for the clock?

Sep 8-1



- K- Registers of n- bits broduce n-line common bus. (A Common Bus System Rowing # New of multiplexus needed = n Spe of each multiplease = KXI.
- (a) No of mulliflen = 32 (n-No of bits), size = 16 ×1 (1×x1).
- (b) 4 Anputs to each to Selection one amongs 16 Reg.
- (C) H to 16 (to Select one amongs 16).
- 32 (A) + 32 (B) +1 (INPUT) = 65 (d) 32 (0) + 1 (0. (0.33) = 33
- = 18 bits TRELA CELE SEL D OPR (2)

Central Processing Unit

- 8-3. Specify the control word that must be applied to the processor of Fig. 8-2 to implement the following microoperations.
 - **a.** $R1 \leftarrow R2 + R3$
 - **b.** $R4 \leftarrow R4$
 - c. $R5 \leftarrow R5 1$
 - **d.** $R6 \leftarrow \text{shl } R1$
 - **e.** $R7 \leftarrow \text{input}$
- 8-4. Determine the microoperations that will be executed in the processor of Fig. 8-2 when the following 14-bit control words are applied.
 - a. 00101001100101
 - **b.** 000000000000000
 - c. 01001001001100
 - **d.** 00000100000010
 - e. 11110001110000
- 8-5. Let SP = 0000000 in the stack of Fig. 8-3. How many items are there in the stack if:
 - **a.** FULL = 1 and EMTY = 0?
 - **b.** FULL = 0 and EMTY = 1?
- 8-6. A stack is organized such that SP always points at the next empty location on the stack. This means that SP can be initialized to 4000 in Fig. 8-4 and the first item in the stack is stored in location 4000. List the microoperations for the push and pop operations.

OPR. 8.3 SELD SELB SELA 00010 011 001 010 ADD 00000 23 RI @ RI + R2+R3 83 XXX IDD TRANSF. 100 00110 R4 24 124 101 B R4 +R4 101 DEC 25 XXX 110 11600 RS R5 + R5-1 Sufferfl OOI 26 00000 @ R6 + She RI XX | | | | RI Traye A 000 Q7 Input @ R7 & infruit

84 (Control word Microoperation OPR SELB SELD SELA R3 + R1 - R2 A3 SUB @ 001 010 011 00101 RZ output + Input Transfer. Input Trout டு என்ன R2 + R2 BR2 XOR R2 @ 610 010 010 01150 RZ Output - Input + R1 Input ADD RI @ 000 001 000 00010 R3 R3 + R7, R4 R4 SURA (E) 111 100 011 1000 R7 ERROY.

STACK ORGANIZATION


A stack is an ordered collection of item which permits the insertion or detection of an item to occur only at one end. The stack is also known as last-in first-out list. The stack can be considered as a storage method in which the items that stored last is the first item to be removed ex: stack of tray. Operations performed on Stack are:

PUSH: The insertion operation is known as push.

POP: The deletion operation is known as pop.

The stack in a digital computer is a part of memory unit. Also, with the stack an address register is associated that holds the address of the last element stored in the stack. This address register is known as Stack Pointer (SP). Thus, the stack pointer always points to the top most element of the stack.

STACK ORGANIZATION



REGISTER STACK ORGANIZATION

Initially, the SP is cleared to 0 so the stack pointer points to the word at address 0. Also, the one-bit register FULL is cleared to 0, indicating that the stack is not full and the register EMPTY is set to 1. A new item is inserted into the stack by push operation. The PUSH operation will be the set of following micro operations:

 $SP \leftarrow SP + 1$ Increment stack pointer

 $M[SP] \leftarrow DR$ Add item on the top of stack

If (SP = 0) then $(FULL \leftarrow 1)$ Check if stack is full

EMPTY $\leftarrow 0$ Mark the stack not empty.

If the stack is not empty, an item can be deleted from the stack using the POP operation. The POP operation is implemented by the following set of micro operations.

 $DR \leftarrow M [SP]$ Read item from the top of stack

 $SP \leftarrow SP - 1$ Decrement stack pointer


If (SP = 0) then $(EMPTY \leftarrow 1)$ Check if stack is empty

FULL $\leftarrow 0$ Mark the stack not full.

The top item is read from the stack into DR, then the SP is decremented by 1 so that it points to top of stack. The SP is checked whether it is zero on not. If zero, EMPTY sets to 1 indicating that the stack is empty.

MEMORY STACK ORGANIZATION

Memory with Program, Data, and Stack Segments



- A portion of memory is used as a stack with a processor register as a stack pointer

Stack grows
In this direction

- PUSH: SP \leftarrow SP - 1

 $M[SP] \leftarrow DR$

- POP: $DR \leftarrow M[SP]$

 $SP \leftarrow SP + 1$

- Most computers do not provide hardware to check stack overflow (full stack) or underflow (empty stack) → must be done in software

REVERSE POLISH NOTATION

- Arithmetic Expressions: A + B
 - A + B Infix notation
 - + A B Prefix or Polish notation
 - AB + Postfix or reverse Polish notation
 - The reverse Polish notation is very suitable for stack manipulation
- Evaluation of Arithmetic Expressions

Any arithmetic expression can be expressed in parenthesis-free Polish notation, including reverse Polish notation

PROCESSOR ORGANIZATION

- In general, most processors are organized in one of 3 ways
 - Single register (Accumulator) organization
 - Basic Computer is a good example
 - Accumulator is the only general purpose register
 - General register organization
 - Used by most modern computer processors
 - Any of the registers can be used as the source or destination for computer operations
 - Stack organization
 - All operations are done using the hardware stack
 - For example, an OR instruction will pop the two top elements from the stack, do a logical OR on them, and push the result on the stack

INSTRUCTION FORMAT

Instruction Fields

OP-code field - specifies the operation to be performed

Address field - designates memory address(es) or a processor register(s)

Mode field - determines how the address field is to be interpreted (to get effective address or the operand)

• The number of address fields in the instruction format depends on the internal organization of CPU

 $/* TOS \leftarrow M[X] */$

• The three most common CPU organizations:

Single accumulator organization:

ADD

```
ADD
           X
                              /* AC \leftarrow AC + M[X] */
General register organization:
  ADD
           R1, R2, R3
                               /* R1 \leftarrow R2 + R3 */
  ADD R1, R2
                         /* R1 \leftarrow R1 + R2 */
  MOV R1, R2
                         /* R1 \leftarrow R2 */
  ADD
           R1, X
                             /* R1 \leftarrow R1 + M[X] */
Stack organization:
  PUSH
```

THREE, AND TWO-ADDRESS INSTRUCTIONS

• Three-Address Instructions

```
Program to evaluate X = (A + B) * (C + D):

ADD R1, A, B /* R1 \square M[A] + M[B] */

ADD R2, C, D /* R2 \square M[C] + M[D] */

MUL X, R1, R2 /* M[X] \square R1 * R2 */
```

- Results in short programs
- Instruction becomes long (many bits)

Two-Address Instructions

Program to evaluate X = (A + B) * (C + D):

```
MOV
       R1, A
                                            */
                      /* R1 \square M[A]
ADD
        R1, B
                      /* R1 \square R1 + M[A]
                                            */
       R2, C
MOV
                      /* R2 \square M[C]
                                            */
ADD
        R2, D
                       /* R2 \square R2 + M[D]
                                            */
MUL
       R1, R2
                       /* R1 □ R1 * R2
                                            */
MOV
        X, R1
                      /* M[X] \square R1
                                             */
```

ONE, AND ZERO-ADDRESS INSTRUCTIONS

- One-Address Instructions
- Use an implied AC register for all data manipulation
- Program to evaluate X = (A + B) * (C + D):

```
LOAD
                /* AC \square M[A]
ADD
                /* AC \square AC + M[B] */
               /* M[T] \square AC
STORE T
LOAD C
                /* AC \square M[C]
ADD
                /* AC \square AC + M[D]
                                           */
MUL
        T /* AC \square AC * M[T]
                                           */
STORE X
                /* M[X] \square AC
```

- Zero-Address Instructions
 - Can be found in a stack-organized computer
 - Program to evaluate X = (A + B) * (C + D):

```
PUSH
                                                            */
               A
                              /* TOS \Box A
PUSH
               B
                                  TOS \sqcap B
                              /* TOS \square (A + B)
                                                            */
PUSH
                              /* TOS \sqcap C
                                                            */
                                                            */
PUSH
                                  TOS \square D
                                  TOS \Box (C + D)
                              /* TOS \Box (C + D) * (A + B) */
POPX
               /* M[X] \square TOS
```

INSTRUCTION FORMAT

Q. Convert the Arithernatic enp (3+4) [10(2+6)+8] in Revuse Polish Notation and Show the Stack implementation.

$\frac{Q}{-} \text{ WAP to evaluate } X = A - B + C \times (D \times E - F)$ $\frac{G + H \times K}{G}$

(a) 3 Address Instruction format.

MUL RI, D
$$\star$$
, E RI \leftarrow M[D] \star M[E]
SUB RI, RI, F RI \leftarrow RI \rightarrow M[F]
MUL RI, RI, C RI \leftarrow RI \star M[C]
ADD RI, RI, B RI \leftarrow RI $+$ M[B]
SUB RI, \rightarrow RI RI \leftarrow RM \rightarrow M[A] \rightarrow RI
MUL R2, \rightarrow N, \rightarrow R2 \leftarrow M[N] \star M[K]
ADD R2, R2, G R2 \leftarrow R2 \rightarrow M[A].
DIV X, RI, R2 M[X] \leftarrow RI/R2.

(b) 2- Address Instruction format.

RIZM[D] RI.D mov RI < RI x m[E] RI,E MUL RI + RI -M[F] RI, F SUB RI + RI * M[c] RI, C MUL RI + RI +M[B] RI, B ADD M[A] < M[A]-RI. A, RI SUB RI < M[A] RI, A mov RX + m[K] R2, K mov RZ < RZ * m[H] Ra, H R2 + R2 +m[6]. MUL R2, G ADD RI + RI/RZ RI, RZ DIV M[x] + RI. X, RI mov

2) 1-Address Instruction format: LOAD D AC < m[D] MUL E AL < AC * m[E] SUB F AC < AC- m[F] MUL AC < AC * m[c] AC LAC+M[B] ADD B SUBA AL WATm[T] +AC STORE T AC < m[A] LOAD A AC < AC -m[T] SUB T m[T] + AC STORET AC < m[K] LOAD AC < AC * m[H] MUL H AC + AC+ M[G] ADD G m[TI] < AC STORE RI AC + m[T] LOAD T AL + AL/ m[TI] DIV RI MIXJEAC. STORE X

Jero Address Instruction Everat: 11 Post fin Conversion (A+B)+(C* (D*E-F)) => (AB-) + (C*(DE*F-)) GRAKIX G+HKX => (AB-) * (CDE *F-*+ => AB-CDEXF-X+GNKX+/

```
PUSH
           TOP &A
PUSH
     B
           TOP + B
SUB
           TOP < A-B
     C
           TOP +C
PUSH
     D
           TOP &D
PUSH
           TOP 4E
     E
PUSH
           TOP LDXE
MUL
           TOP + F
     F
PUSH
           TOP + D#E-F
SUB
           TOP < C x (D*E-F)
MUL
           TOP < (A-B) + (C * (D*E-F))
 ADD
       6,
           TOP + 6
 PUSH
          TOP 4 H
 PUSH
        4
          TOP 4 K
        K
 PUSH
           TOP = (N*K)
 MUL
            TOP + BOD G+ (H+K)
 ADD
            TOP < (A-B) + (C*(D*E-F))
 DIV
                         G+(N*K)
 POP
             M[x] + TOP.
        X
```

ADDRESSING MODES

• Addressing Modes: - Specifies a rule for interpreting or modifying the address field of the instruction (before the operand is actually referenced)

Advantage of addressing modes

- to give programming flexibility to the user
- to use the bits in the address field of the instruction efficiently
- •Implied Mode: Address of the operands are specified implicitly in the definition of the instruction. Ex:- CLA, CME, INP
- Immediate Mode: Instead of specifying the address of the operand, operand itself is specified in the instruction. No need to specify address in the instruction. MVI A,34H

- Register Mode or Register Direct: The operands are in the register that reside within the CPU. Faster to acquire an operand than the memory addressing
- **Register Indirect Mode:**-Instruction specifies a register in the CPU whose contents give the address of the operand in memory.
- Autoincrement or Autodecrement Mode:-Similar to register Indirect Mode except that the register is incremented or decremented after (or Before) by 1 automatically when its value is used to access memory.
- •Direct Address Mode: In this the effective address is equal to the address part of the instruction. Faster than the other memory addressing modes
- **Indirect Addressing Mode :-** In this the address field of the instruction gives the address where the effective address is stored in the memory.

• Relative Addressing Modes :-

(R = PC, where PC: Program Counter)

-EA = PC + IR(address)

•Indexed Addressing Mode :-

(R = IX, where IX: Index Register)

-EA = IX + IR(address)

Base Register Addressing Mode:-

(R = BAR, where BAR: Base Address Register)

-EA = BAR + IR(address)

ADDRESSING MODE EXAMPLES

PC = 200

R1 = 400

XR = 100

AC

Addressing Mode	Effective Address			Content of AC
Direct address	500	/* AC ← (500)	*/	800
Immediate operand	_	/* AC ← 500 [^]	*/	500
Indirect address	800	/* AC ← ((500))	*/	300
Relative address	702	$/* AC \leftarrow (PC+500)$	*/	325
Indexed address	600	/* AC \leftarrow (RX+500)	*/	900
Register	-	/* AC ← R1	*/	400
Register indirect	400	/* AC ← (R1)	*/	700
Autoincrement	400	$/* AC \leftarrow (R1)+$	*/	700
Autodecrement	_399	/* AC ← -(R)	*/	450

Addres	s Memory
200	Load to AC Mode
201	Address = 500
202	Next instruction
399	450
400	700
500	800
600	900
702	325
800	300

ADDRESSING MODES - EXAMPLES

9. An instruction is stored at location 300 with its address field at location 301. The address field has the value 400. A peacusoe Register RI Contains the number 200. Evaluate the effective address if the addersing mode of the instruction is

- (a) Direct
- (b) Immediate

- register.
- (a) Direct: 400
- (b) Immediate: 301
- (c) Relative : 302+400=702
- (d) Register indirect: 200
 - (e) Indexed: 200 + 400 = 600

