https://www.markdownguide.org/cheat-sheet/

Testarea Automată a Circuitelor

--- Îndrumar de Laborator ---

Lucrarea nr. 5 - Caracterizarea Filtrului trece Jos

5.1.1 Montajul experimental:

CH1 Osc **Fgen** CH2 Osc C1 Cap1 **C3** 22n R1 < 。OUT 10K INo √/√ R3 R2 R4 10K Cap2 10K 10n

5.1.2 Procedura de masurare: Montajul experimental se bazează pe un filtru trece jos. Acesta este configurabil din punct de veder al ordinului (1 sau 2) și al frecvenței de tăiere (prin selectare R1 sau R2).

Prin intermediul conectorului C4 intrarea filtrului este legata la canalul 1 al osciloscopului si generatorul de semnal (CH1_osc, Fgen) iar iesirea acestuia, la canalul 2 al osciloscopului. C1 si C2 configureaza frecventa de

taiere a filtrului, iar C3, ordinal acestuia. Circuitul poate fi configurat pentru 3 frecvente de taiere pentru fiecare ordin. Folosind o buclă de tip "for" se va varia frecventa unui semnal sinusoidal si se va monitoriza cu osciloscopul amplitudinea semnalului de la iesirea respectiv intrarea amplificatorului. Raportul celor doua amplitudini

In []:

#using TIVM; # Libraria responsabila de comunicatia cu instrumentele si cu interfetele grafice(front panels) #using Plots; # Libraria responsabila de generarea de grafice

5.2.1 Initializarea instrumentelor si a interfetelor grafice

reprezinta castigul amplificatorului. Se va trasa caracteristica castig vs. frecventa a FTJ.

#using DataFrames; # #using CSV; # Libraria responsabila de salvarea datelor in format .csv In [96]: # dmm_handle = connect!("ASRL1::INSTR")
psu_handle = connect!("ASRL5::INSTR")
scope_handle = connect!("BSB::0*IAB1::0*04CE::DS1ZD211200258::INSTR")
fgen_handle = scope_handle

dmm = TIVM.GDM8246(dmm_handLe);
psu = TIVM.PST3201(psu_handLe);
fgen = TIVM.DS1000Z_FGEN(fgen_ha andle);#scope has integrated fgen scope = TIVM.DS1000Z(scope_handle);

5.2.2 Connfigurarea instrumentelor # Generatorul de semnal
TIVM.write(fgen_handle, ":SOURce1:OUTPut1:STATe 0") #disable to reset

Panouri frontale pentru instrumente
#experience | #Panouri frontale | #Panouri front

sleep(1)
set_wfm(fgen, "C1", "sinusoid")
TIVM.write(fgen_handle, ":SOURce1:OUTPut1:IMPedance FIFTy") #set output impedance to 50

#sleep(1)
set_freq(fgen, "C1", 1000) #sleep(1)
set_amplit(fgen, "C1", 1)

In [8]: # #

In [97]:

In [106...

In [107...

In [108...

#sleep(1)
set_offs(fgen, "C1", 0) #sleep(1)
set_duty(fgen, "C1", 50)
TIVM.write(fgen_handle, ":SOURce1:OUTPut1:STATe 1")#turn output on
sleep(1) # Osciloscopul #autoset is hidden :P #ch coupling - WIP In [98]: #th coupling - WIP
set_h_position(scope, "CH1", 0)
set_h_position(scope, "CH2", 0)
#th probe - do we need this?
set_vertical_scale(scope, "CH2", 0.5)
set_vertical_scale(scope, "CH2", 0.5)
set_horizontal_scale(scope, 0.001)

set_horizontal_scale(scope, 0.001)
set_triag_ch(scope, "CH1")
set_triag_mode(scope, "NORMAL") # "NORMAL"/"AUTO"
set_triag_lovel(scope, 0.001)
do we need trigger coupling or slope?
Masuratori - se pot configura maxim 5 pt ambele canale impreuna
set_meas(scope, "MEAS1", "CH1", "FREQuency")
set_meas(scope, "MEAS2", "CH1", "PKZpk")
set_meas(scope, "MEAS3", "CH2", "FREQuency")
set_meas(scope, "MEAS3", "CH2", "FREQuency")
set_meas(scope, "MEAS4", "CH2", "FREQuency") 5.2.3 Definirea stimulilor si a variabilelor auxiliare In [99]: freq = 100:200:3500# create a vector of frequencies Out[99]: 100:200:3500

5.2.4 Bucla de masurare

in_freq = []
in_amplit_meas = []
out_amplit_meas = []
gain = [] gain = []
crt_meas_amplit_out = 0
crt_meas_amplit_in = 0
fcut=0
fcut=0
for crt_freq in freq
set_freq(fgen, "C1", crt_freq)
tbase = 1/crt_freq
set_horizontal_scale(scope, tbase)
sleep(1) sleep(1)
crt_meas_amplit_in = get_meas_data(scope, "MEAS2")
crt_meas_amplit_out = get_meas_data(scope, "MEAS4") crt_gain = crt_meas_amplit_out/crt_meas_amplit_in # store crt stimuli valu
push!(in_freq, crt_freq) # store crt measurement value
push!(in_amplit_meas, crt_meas_amplit_in)
push!(out_amplit_meas, crt_meas_amplit_out)
push!(gain, crt_gain) # print info to console @info "crt_freq=\$crt_freq, crt_meas_amplit_in=\$crt_meas_amplit_in, crt_meas_amplit_out=\$crt_meas_amplit_out,crt_gain=\$crt_gain" Info: crt_freq=100, crt_meas_amplit_in=2.1, crt_meas_amplit_out=2.28,crt_gain=1.0857142857142856
@ Main In[106]:27
Info: crt_freq=300, crt_meas_amplit_in=2.14, crt_meas_amplit_out=2.24,crt_gain=1.046728971962617
@ Main In[106]:27
Info: crt_freq=500, crt_meas_amplit_in=2.12, crt_meas_amplit_out=2.18,crt_gain=1.028301886792453
@ Main In[106]:27

 @ Main In[106]:27
 Info: crt_freq=2700, crt_meas_amplit_in=2.2, crt_meas_amplit_out=1.28,crt_gain=0.5818181818181818
 @ Main In[106]:27
 Info: crt_freq=2900, crt_meas_amplit_in=2.22, crt_meas_amplit_out=1.26,crt_gain=0.5675675675675675675
 @ Main In[106]:27
 Info: crt_freq=3100, crt_meas_amplit_in=2.22, crt_meas_amplit_out=1.18,crt_gain=0.5315315315315315314
 @ Main In[106]:27 5.2.5 Oprirea instrumentelo set_amplit(fgen, "C1", 0.02)
TIVM.write(fgen_handle, ":SOURce1:OUTPut1:STATE 0") #disable to reset 5.2.6 Generarea caracteristicilor, dupa incheierea masuratorilor # castig vs freeventa
hl=plot(in_freq, gain; xaxis=:log, markershape=:circle, label="castig vs. freeventa");
title!("castig vs. freeventa");
xlabel!("Freeventa [Hz]");
ylabel!("Castig [V/V]");
display(h1)

1.1 - castig vs. frecventa 1.0 Castig IV/V 0.7 0.6 Frecventa [Hz]

castig vs. frecventa

CSV.write("0005_FTJ.csv", df)

5.2.7 Salvarea datelor in fisierul .csv

Out[11]: "0005_FTJ.csv" 5.2.8 Deconectarea instrumentelor In [109...

5.3 Desfasurarea lucrarii:

else

In []:

1. Reduceti perioada de asteptare dintre setarea instrumentelor si masuratoare la 0.5s sleep(2) -> sleep(0.5). Ce observati?

Indicație: Este suficient jumătate de secundă timp de achiziție pentru osciloscop?

2. Măriți precizia măsurătorilor.

Indicație: Ajustați pasul folosit de funcția for.

3. Afișați caracteristica filtrului in decibeli.

Indicație: regain = 20 ** logl0.(crr.meas.amplit_out./crt_meas_amplit_in)

4. Afisati caracteristica filtrului folosind o scara dublu logaritmica.

5. Determinați (în scripti) frevvența de tăiore. 5. Determinați (în script) frecvența de tăiere. Indicație: Atentie la ordinul filtrului. if crt_gain > -3 fcut=crt_freq @info "taiere taiere" One.

Determinați și afișați panta filtrului (în decibeli).
Indicație: Panta poate fi aproximată folosind două puncte situate după frecvența de tăiere(unul dintre acestea poate fi chiar frecvența de tăiere).
7. Adăugați la fișierul cu datele masurate o coloană pentru atenuarea filtrului în decibeli.
8. Modificați script-ul pentru a măsura două din cele 4 configurații de filtre. Introduceți datele măsurate într-un fișier.