
## Female, Sub-D, 9 Pin Connector, Rear side (view to soldering pins)

## Vario/S2F Switch



1 = GND In Out Temp-Sensor DS1820B black cable from sensor 6 = GND 2 = Data In Temp-Sensor yellow 7 = +3.3V Out Temp-Sensor red 3 = VaSo In Vario/S2F Switch for Audio GND Level=S2F, Open=Vario Internal Pull-Up 8 = Aux1 future use, e.g. Gear warning do not connect 4 = Aux2 dito do not connect 9 = NC

5 = VIN In Power +12 Volt, supported range: 8..24 V