

LD1, LD2, R5 and R6 are for 'diagnostics' only.

CAN_USB2 CAN to USB interface

M P Bolton 13/05/08

