

Microfilm Guide

Position Film


Pull the film carrier all the way towards you.

2 Insert the reel of microfilm all the way through the left spindle.


Thread the film between the first two small rollers.

Slide the film between the two glass plates.















4




Position Film

Thread the film between the next two spindles.

- Place the film through the gap in the right film spool. Press the top and bottom of the spool together to hold the film and start rotating the spool.
- Rotate the spool carefully to the right, holding the top and bottom of it until you are sure the film will not slip from the spool.
- Once the film is tight in the right spool, you can let go of the top and bottom, but continue to rotate until the film is about to start. This is noted by different colors in the film.
- You can now use the forward and rewind knob to move through the film. Caution: rotate the knob slowly as it can move through the film at high speeds.





6



7



8





9



Align, Zoom, Rotate, Focus

- Pull or push the film carrier towards or away from you as necessary to align the image on the screen and bring it to view.
- 2 Move the blue wheel slowly left or right to zoom in and out as necessary.
- Rotate the knob to rotate the image on the screen and center it.
- Once the image has been centered from step 3, press the AF button to auto focus the image if necessary.
- Use the gray wheel to focus the image if it is blurry.





Printing

- The green lights mark the print area. Make sure the image on the screen fits within these lights.
- Press the paper size button to select another available paper in the printer. The lights will change according to the paper size that is selected.
- 3 Select the number of prints by using the 1 button. Press C to return to 1. Press the start button to print. Make sure the printer is plugged in and turned o n.

